

ภาคผนวก จ

---

ใบแสดงการตรวจเทียบเครื่องมือ



# CONTROL UNIT CALIBRATION

(Metric units, mm)

Date 25 Jan 22

Initial Final Average

Barometric press, Pb 758 758 758 mmHg

## Dry Gas Meter Data

Console No. M50-06

Metering System ID

DGM Number 333249

DGM Model ES-110

Calibrated by : Montri P.

## Reference Dry Gas Meter Data

Serial No. 358794

Model S110

Correction factor (Yr) 0.9966

Last Calibration Date 8 Jan 22

Orifice manometer setting, ΔH mm H2O	Ref. DGM Volume V <sub>r</sub> Liters	DGM Volume V <sub>m</sub> Liters	Temperature (°C)				Time Θ min	DGM Correction factor (Y)	ΔH@ mm
			Ref DGM T <sub>r</sub>	Dry Gas Meter					
				Inlet T <sub>i</sub>	Outlet T <sub>o</sub>	Avg T <sub>m</sub>			
12.5	100.1	100.6	24	24	23	23.5	8.58	0.9887	42.5446
25.0	100.2	100.2	24	24	23	23.5	6.00	0.9921	41.5532
50.0	100.1	99.7	24	24	23	23.5	4.32	0.9941	43.1019
76.0	100.1	100.9	24	24	23	23.5	3.52	0.9805	43.4295
100.0	100.2	99.6	24	24	23	23.5	3.52	0.9904	42.9584
150.0	100.2	100.5	24	24	23	23.5	2.47	0.9784	42.0708
Average								0.9874	42.6097

Approved by :

( Miss Katesarin Vorradetwittaya )



## PITOT TUBE CALIBRATION

Calibration Location: SECOT

Calibration Date : 14/01/2022

Calibrated duct No.: 1

Calibration Standard Pitot tube data

Pitot No. : Std-01

Coefficient (Cp) : 1

Type S Pitot No. : PS20-01

Calibrated by : Mr. Montri P.

## A Side Calibration

Run No.	$\Delta P_{std}$ (mm H <sub>2</sub> O)	$\Delta P_s$ (mm H <sub>2</sub> O)	Cp(s)	Deviation, $\delta$ Cp(s) - Cp(A)
1	7.55	10.50	0.8480	0.0066
2	7.55	10.75	0.8380	-0.0033
3	7.55	10.75	0.8380	-0.0033

 $C_{P(A),avg}$  0.8414

## B Side Calibration

Run No.	$\Delta P_{std}$ (mm H <sub>2</sub> O)	$\Delta P_s$ (mm H <sub>2</sub> O)	Cp(s)	Deviation, $\delta$ Cp(s) - Cp(B)
1	7.55	10.75	0.8380	-0.0033
2	7.55	10.75	0.8380	-0.0033
3	7.55	10.50	0.8480	0.0066

 $C_{P(B),avg}$  0.8414 $|C_{P(A)} - C_{P(B)}| = 0.0000$  $C_{P(Avg)} = 0.8414$ 

Approved by :   
( Miss Katesarin Vorradetwittaya )

\*\*\*  $\delta$  must be  $\leq 0.01$  for the test to be acceptable \*\*\*  
 \*\*\*  $|C_{P(A)} - C_{P(B)}|$  must also be  $< 0.01$  if average of  $C_{P(A)}$  and  $C_{P(B)}$  is to be used \*\*\*

THE LINDE GROUP

Linde

# Certificate Of Analysis

## Special Gases Mixture

### Customer Details

Name:

SECOT CO.,LTD.

Address:

House number.239 Rimklongprapa Rd,Bangsue  
Bang Su Bangkok 10800

Customer Tag No.:

### Certificate Details

Number:

0303/19

Date of Issue:

4-Feb-2019

Expired date:

3-Feb-2023

Material Details

Production Order:

90152418

Material Code:

478100-J-62

Cylinder No.:

85432

Gas content:

6.52 M<sup>3</sup> (normal)

Filling pressure:

145 bar (g)

Valve:

CGA 590 BRASS

Cylinder Owner:

LINDE

Cylinder Material:

STEEL

Cylinder Size:

47 L

### Laboratory Report

Component

Normal Concentration

Analysis Result<sup>1</sup>Uncertainty<sup>2</sup>Method of Analysis<sup>3</sup>

Oxygen

8.00%

8.07%

± 2% relative

(1) SG-O-01

Nitrogen

Balance

### Recommend usage condition

Minimum utilization:

5% of actual content or before expire date whichever comes first.

Storage condition:

Keep in well ventilation and secure area.

Comments

### Note:

1. All results expressed in this report are on mole/mole basis, unless otherwise specified.
2. The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a level of confidence of approximately 95%. The measurement of this material is traceable to the SI through the reference gas standard which is traceable to Swiss National Standard of Mass or other recognised national metrology institutes.
3. (1) Gas Chromatography, (2) Paramagnetic Oxygen Analyzer, (3) Electrochemical Oxygen Analyzer,
- (4) Electrochemical Moisture Analyzer, (5) Total Hydrocarbon Analyzer, (6) Other - Specified

Sukanya Parinyasontorn

Signatory for and on behalf of Linde (Thailand) Co., Ltd.

Page 1 of 1

This report shall not be reproduced except in full

บริษัท ลินด์ (ประเทศไทย) จำกัด (มหาชน)

เลขที่ใบแจ้งหนี้: 0107537000785

วันที่ 15 มกราคม 2562 เลขที่ 2/3 หมู่ 14 ถนนบางนา-ตราด กม. 6.5 ต.บางนา

เลขหมายติดต่อ: 10540 โทรสาร (66) 2338-6100 โทรสาร (66) 2338-6333

เลขหมายติดต่อ: 105 หมู่ 5 ต.บางนาจันทน์ อ.บางนาจันทน์ จ.สมุทรปราการ 24180

โทรสาร (66) 38.570-479-93

โทรสาร (66) 38.570-323

Linde (Thailand) Public Company Limited

PLC Registration no.0107537000785

15<sup>th</sup> Floor, Bangna Tower A, 2/3 Moo 14, Bangna Trad Km. 6.5 Road, Bangkaew

Bangplee, Samutprakarn 10540, Tel (66) 2338-6100 Fax (66) 2338-6333

Wellgrow Plant: 105 Moo 5, T.Bangsamak, A.Bangpakong, Chachoengsao 24180

Thailand, Tel (66) 38.570-479-93

Fax (66) 38.570-323

PB-002/F004

Iss:H/2, 01 March 2018

THE LINDE GROUP

Linde

## Certificate Of Analysis

### Special Gases Mixture

**Customer Details**

Name:

Secot Co., Ltd.

Address:

239, Rimklongprapa Rd., Bangsue, Bangkok  
10800

Customer Tag No.:

**Certificate Details**

Number: 2946/21

Date of Issue:

13-Jul-2021

Expiry date:

13-Jul-2023

**Material Details**

Production Order: 90166595

Material Code:

640300-SK-44

Cylinder No.:

A007535K

Gas content: 5.52 M<sup>3</sup>

Filling pressure:

145.0 bar

Valve:

CGA 660 SS

Cylinder Owner: LINDE

Cylinder Material:

Spectra seal

Cylinder Size:

40 L

**Laboratory Report****Analytical Result**

Component	Nominal Concentration	Analysis Result <sup>1</sup>	Uncertainty <sup>2</sup>	Method of Analysis <sup>3</sup>	Assay Date
Nitric Oxide	40.0 ppm	39.4 ppm	± 1% relative	(6) I-PB-352	6-Jul & 13-Jul-21
Other NOx impurity in Nitrogen		Less than 1.9 ppm			

**Reference Standard used in Assay**

Reference Standard

Nitric Oxide

in Nitrogen

Cylinder number

2660645G

Concentration

25.65 ± 0.26 ppm

Expiry date:

6-Aug-2021

**Analytical Instruments used in Assay**Instrument/Make/Model  
FTIR Spectrometers Nicolet iS50Analytical Principle  
FTIR-NOLast Multipoint Calibration  
24-Jun-2021**Recommend usage condition**

Minimum utilization: 5% of actual content or before expire date whichever comes first.

Storage condition: Keep in well ventilation and secure area.

**Comments**

When reordering, please quote the material number

**Note:**

1. All results expressed in this report are on mole/mole basis, unless otherwise specified. The Assay of this Standard has been performed in accordance with the EPA Traceability Protocol EPA-600/R-12/531 for the Assay and Certification of Gaseous Calibration Standards using procedure G1.
2. The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor  $k=2$ , providing a level of confidence of approximately 95%. The measurement of this material is traceable to the SI through the reference gas standard which is traceable to Swiss National Standard of Mass or other recognised national metrology institutes.
3. (1) Gas Chromatography, (2) Paramagnetic Oxygen Analyzer, (3) Electrochemical Oxygen Analyzer, (4) Electrochemical Moisture Analyzer, (5) Total Hydrocarbon Analyzer, (6) Other - Specified

Page 1 of 1

This report shall not be reproduced except in full  
ฉบับนี้ (ฉบับนี้) ห้าม (ห้าม)

รหัสเอกสาร: 0107537000785

วันที่ 15 มกราคม 2565 ถึง 2/3 หมู่ 14 ถนนพหลโยธิน-ตราด กม. 6.5 ต.บางพลี

ขอสงวนลิขสิทธิ์ 10540 โทร (66) 2338-6100 โทรสาร (66) 2338-6333

โรงงานผลิต: 105 หมู่ 5 ต.บางพลี อ.บางพลี จ.สมุทรปราการ 24180

โทร (66) 38.570-479-93

โทรสาร (66) 38.570-323

Sukanya Parinyasoonporn

Signatory for and on behalf of Linde (Thailand) Co., Ltd.

PB-002/F006

Linde (Thailand) Public Company Limited

ISS: K/1, 01 July 2021

PLC Registration no. 0107537000785

15<sup>th</sup> Floor, Bangna Tower A, 2/3 Moo 14, Bangna Trad KM. 6.5 Road, Bangkaew

Bangplee, Samutprakarn 10540, Tel (66) 2338-6100

Fax (66) 2338-6333

Wellgrow Plant: 105 Moo 5, T.Bangsamak, A.Bangpakong, Chachoengsao 24180

Thailand, Tel (66) 38.570-479-93

Fax (66) 38.570-323

THE LINDE GROUP

Linde

## Certificate Of Analysis

### Special Gases Mixture

**Customer Details**

Name: Secot Co., Ltd. Address: 239, Rimklongprapa Rd., Bangsue, Bangkok 10800 Customer Tag No.:

**Certificate Details**

Number:	2972/20	Date of issue:	18-Jul-2020	Expiry date:	18-Jul-2024
Material Details					
Production Order:	90159708	Material Code:	608400-SK-44	Cylinder No.:	95078
Gas content:	5.52 M <sup>3</sup>	Filling pressure:	145.0 bar	Valve:	CGA 660 SS
Cylinder Owner:	LINDE	Cylinder Material:	Spectra seal	Cylinder Size:	40 L

**Laboratory Report***Analytical Result*

Component	Nominal Concentration	Analysis Result <sup>1</sup>	Uncertainty <sup>2</sup>	Method of Analysis <sup>3</sup>	Assay Date
Sulphur Dioxide in Nitrogen	40.0 ppm	41.7 ppm	± 1% relative	(6) I-PB-352	11-Jul & 18-Jul-20

*Reference Standard used in Assay*

Reference Standard	Cylinder number	Concentration	Expiry date:
Sulphur Dioxide in Nitrogen	76626756	51.48 ± 0.41 ppm	17-Apr 2021

*Analytical Instruments used in Assay*

Instrument/Make/Model	Analytical Principle	Last Multipoint Calibration
FTIR Spectrometers Nicolet i550	FTIR-SO2	16-Jun & 17-Jul-20

**Recommend usage condition**

Minimum utilization: 5% of actual content or before expire date whichever comes first.  
Storage condition: Keep in well ventilation and secure area.

**Comments**

When reordering, please quote the material number

**Note:**

- All results expressed in this report are on mole/mole basis, unless otherwise specified. The assay of this Standard has been performed in accordance with the EPA Traceability Protocol EPA-600/R-12/531 for the Assay and Certification of Gaseous Calibration Standards using procedure G1.
- The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a level of confidence of approximately 95%. The measurement of this material is traceable to the SI through the reference gas standard which is traceable to Swiss National Standard of Mass or other recognised national metrology institutes.
- (1) Gas Chromatography, (2) Paramagnetic Oxygen Analyzer, (3) Electrochemical Oxygen Analyzer, (4) Electrochemical Moisture Analyzer, (5) Total Hydrocarbon Analyzer, (6) Other - Specified

Page 1 of 1

This report shall not be reproduced except in full

บริษัท ลินด์ (ประเทศไทย) จำกัด (มหาชน)

โทรสาร 02-570-479-93

ชั้น 15 อาคารทาวเวอร์ เอ 2/3 หมู่ 14 ถนนบางนา-ตราด กม. 6.5 บางนา กรุงเทพฯ

อ.บางพลี จ.สมุทรปราการ 10540 โทรศัพท์ (66) 2338-6100 โทรสาร (66) 2338-6333

โรงงานเวลโกรว์ 105 หมู่ 5 ต.บางพลีใหญ่ อ.บางพลี จ.สมุทรปราการ 24180

โทรศัพท์ (66) 38 570-479-93

โทรสาร (66) 38 570-323

Sukanya Parinyasoonorn

Signatory for and on behalf of Linde (Thailand) Co., Ltd.

Linde (Thailand) Public Company Limited

PLC Registration no 010753700765

15<sup>th</sup> Floor, Bangna Tower A, 2/3 Moo 14, Bangna Trad KM. 6.5 Road, Bangkaew

Bangplee, Samutprakarn 10540, Tel (66) 2338-6100 Fax (66) 2338-6333

Wellgrow Plant : 105 Moo 5, T.Bangsamak, A.Bangpakong, Chachoengsao 24180

Thailand, Tel (66) 38 570-479-93

Fax (66) 38 570-323

PB-007/F006



14/1, 01 October 2019



THE LINDE GROUP

Linde

## CERTIFICATE OF ANALYSIS

<b>Customer Detail:</b> <b>Secot Co., Ltd.</b>		<b>Production Order Number:</b> 90133629 <b>Material Number:</b> 433000-AL-44 <b>Certification Date:</b> 10-Feb-2016 <b>Expiry Date:</b> 10-Feb-2024	
<b>Cylinder Description:</b> <b>Aluminum 50 L</b>		The measurement of this reference material is traceable to SF through the reference standard which is traceable to Swiss National Standard of Mass. The Assay of this Standard has been performed in accordance with the EPA Traceability Protocol EPA-600/R-12/531 for the Assay and Certification of Gaseous Calibration Standards using procedure G1. The results are expressed on a mole/mole basis, unless otherwise specified. The reported uncertainty is based on a standard uncertainty multiplied by coverage factor k=2, providing a level of confidence of approximately 95%.	
<b>Certificate Number:</b> <b>0349/16</b>		<b>Analyst:</b>   <b>THITIRAT LOYRAT</b>	
<b>Cylinder Number:</b> <b>D595101</b>			
<b>Nominal Cylinder Content:</b> <b>6.900 M<sup>3</sup></b>		<b>Approve:</b>   <b>SUKANYA KAMUTHARAT</b>	
<b>Nominal Pressure:</b> <b>145.0 Bar</b>			
<b>Valve Outlet:</b> <b>CGA 350 Brass</b>		<b>To Re-Order Please Quote:</b> <b>433000-AL-44</b>	
<b>Comment:</b>		<ul style="list-style-type: none"> <li>● It is recommended that this product be not used below 5% of actual contents or should not be used when its gas pressure is below 150psig.</li> <li>● Other impurities that detect by analytical condition of this mixture shall be report if it is more than 10% of minimum minor component.</li> <li>● Keep and use in well-ventilated and secure area.</li> </ul>	

Page 1 of 2

บริษัท ลินด์ (ประเทศไทย) จำกัด (มหาชน)

เบอร์โทรติดต่อ: 0107537000785

ชั้น 15 อาคารทาวเวอร์ เอ 2/3 หมู่ 14 ถนนบางนา-ตราด กม. 6.5 คลองแก้ว

อ.บางพลี จ.สมุทรปราการ 10540 โทรศัพท์ (66) 2338-6100 โทรสาร (66) 2338-6333

โรงงานเวลโกรว์: 105 หมู่ 5 ต.บางสนธิ์ อ.บางปะกง จ.ฉะเชิงเทรา 24180

โทรศัพท์ (66) 38.570-479-93

โทรสาร (66) 38.570-323

Linde (Thailand) Public Company Limited

P.L.C. Regd. Udon no. 0107537000785

15<sup>th</sup> Floor, Bangna Tower A, 2/3 Moo 14, Bangna Trad KM. 6.5 Road, Bangkaew

Bangplee, Samulprakarn 10540, Tel (66) 2338-6100 Fax (66) 2338-6333

Wellgrow Plant: 105 Moo 5, T.Bangsamak, A.Bangpakong, Chachoengsao 24180

Thailand, Tel (66) 38.570-479-93

Fax (66) 38.570-323

THE LINDE GROUP

Linde

## CERTIFICATE OF ANALYSIS

*Analytical Result*

<u>Component</u>	<u>Request Concentration</u>	<u>Certified Concentration</u>	<u>Certified Uncertainty</u>	<u>Method</u>	<u>Assay Date</u>
Carbon Monoxide In Nitrogen	40.0 ppm	40.1 ppm	± 1 % relative	(6) I-PB-352	09-Feb-2016

*Reference Standard used in Assay*

<u>Reference Standard</u>	<u>Cylinder No.</u>	<u>Concentration</u>	<u>Expired Date</u>
Carbon Monoxide In Nitrogen	103090SG	50.02 ± 0.25 ppm	26-Nov-2019

*Analytical Instruments used in Assay*

<u>Instrument/Make/Model</u>	<u>Analytical Principle</u>	<u>Last Multipoint Calibration</u>
Digi LAB Excalibur HE Series	FTIR-CO	25-Jan-2016

## Method of Analysis

1. Gas Chromatograph
2. Paramagnetic Oxygen Analyser
3. Electrochemical Oxygen Analyser
4. Electrochemical Moisture Analyser
5. Total Hydrocarbon Analyser
6. Other specified

Cylinder Number D595101  
Production Order Number 90133629

Certification Date: 10-Feb-2016  
Expiration Date: 10-Feb-2024

บริษัท ลินด์ (ประเทศไทย) จำกัด (มหาชน)

ทิวทัศน์/สำนักงานใหญ่ 0107537000785

ชั้น 15 ทางเข้าอาคาร 2/3 หมู่ 14 ถนนบางนา-ตราด กม. 6.5 ต.บางแก้ว

อ.บางพลี จ.สมุทรปราการ 10540 โทรศัพท์ (66) 2338-6100 โทรสาร (66) 2338-6333

โรงงานเวลโกรว์ : 105 หมู่ 5 ต.บางสมัคร อ.บางพลี จ.สมุทรปราการ 24180

โทรศัพท์ (66) 38.570-479-93

โทรสาร (66) 38.570-323

Linde (Thailand) Public Company Limited

PLC Registration No. 0107537000785

15<sup>th</sup> Floor, Bangna Tower A, 2/3 Moo 14, Bangna Trad KM. 6.5 Road, Bangkaew

Bangplee, Samutprakarn 10540, Tel (66) 2338-6100 Fax (66) 2338-6333

Wellgrow Plant: 105 Moo 5, T.Bangsamak, A.Bangpakong, Chachoengsao 24180

Thailand, Tel (66) 38.570-479-93

Fax (66) 38.570-323



THE LINDE GROUP

Linde

Certificate Of Analysis  
Special Gases Mixture

## Customer Details

Name:

Secot Co.,Ltd.

Address:

239, Rimklongprapa Rd., Bangsue, Bangkok  
10800

Customer Tag No.:

## Certificate Details

Number:

0225/22

Date of Issue:

31-Jan-2022

Expiry date:

31-Jan-2024

Material Details

Production Order:

90169721

Material Code:

614500-SK-44

Cylinder No.:

A00932SK

Gas content:

5.52 M<sup>3</sup>

Filling pressure:

145.0 bar

Valve:

CGA 660 SS

Cylinder Owner:

LINDE

Cylinder Material:

Spectra seal

Cylinder Size:

40 L

## Laboratory Report

## Analytical Result

Component	Normal Concentration	Analysis Result <sup>1</sup>	Uncertainty <sup>2</sup>	Method of Analysis <sup>3</sup>	Assay Date
Nitric Oxide	80.0 ppm	83.3 ppm	± 1% relative	(6) I-PB-352	24-Jan & 31-Jan-22
Other NOx impurity In Nitrogen		Less than 4.1 ppm			

## Reference Standard used in Assay

Reference Standard

Nitric Oxide  
In Nitrogen

Cylinder number

122820SG

Concentration

50.87 ± 0.25 ppm

Expiry date:

6-May-2023

## Analytical Instruments used in Assay

Instrument/Make/Model  
FTIR Spectrometers Nicolet iS50Analytical Principle  
FTIR-NOLast Multipoint Calibration  
10-Jan-2022

## Recommend usage condition

Minimum utilization: 5% of actual content or before expire date whichever comes first.

Storage condition: Keep in well ventilation and secure area.

## Comments

When reordering, please quote the material number

## Note:

1. All results expressed in this report are on mole/mole basis, unless otherwise specified. The Assay of this Standard has been performed in accordance with the EPA Traceability Protocol EPA-600/R-12/531 for the Assay and Certification of Gaseous Calibration Standards using procedure G1
2. The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a level of confidence of approximately 95%. The measurement of this material is traceable to the SI through the reference gas standard which is traceable to Swiss National Standard of Mass or other recognised national metrology institutes.
3. (1) Gas Chromatography, (2) Paramagnetic Oxygen Analyzer, (3) Electrochemical Oxygen Analyzer, (4) Electrochemical Moisture Analyzer, (5) Total Hydrocarbon Analyzer, (6) Other - Specified

Sukanya Parinyasontorn

Signatory for and on behalf of Linde (Thailand) Co., Ltd.

Page 1 of 1

This report shall not be reproduced except in full

PB-002/F006

Iss:K/2, 15 Oct 2021

บริษัท ลินด์ (ประเทศไทย) จำกัด (มหาชน)

เลขที่ใบอนุญาตประกอบธุรกิจ 0107537000785

ชั้น 15 อาคารทาวเวอร์ เอ 2/3 หมู่ 14 ถนนบางนา-ตราด กม. 6.5 ตำบลบางนา

อ.บางพลี จ.สมุทรปราการ 10540 โทรศัพท์ (66) 2338-6100 โทรสาร (66) 2338-6333

โรงงานเวลโกรว์: 105 หมู่ 5 ตำบลสปอ อ.บางปะกง จ.ฉะเชิงเทรา 24180

โทรศัพท์ (66) 38.570-479-93

โทรสาร (66) 38.570-323

Linde (Thailand) Public Company Limited

PLC Registration no. 0107537000785

15<sup>th</sup> Floor, Bangna Tower A, 2/3 Moo 14, Bangna Trad KM. 6.5 Road, Bangkaew

Bangplee, Samutprakarn 10540, Tel (66) 2338-6100 Fax (66) 2338-6332

Wellgrow Plant: 105 Moo 5, T.Bangsamak, A.Bangpakong, Chachoengsao 24180

Thailand, Tel (66) 38.570-479-93

Fax (66) 38.570-323

THE LINDE GROUP

Linde

# Certificate Of Analysis

## Special Gases Mixture

## Customer Details

Name:

Secot Co., Ltd.

Address:

239, Rimklongprapa Rd., Bangsue, Bangkok  
10800

Customer Tag No.:

## Certificate Details

Number:	2926/21	Date of Issue:	13-Jul-2021	Expiry date:	13-Jul-2029
Material Details					
Production Order:	90166593	Material Code:	445100-SK-44	Cylinder No.:	A00925SK
Gas content:	5.52 M <sup>3</sup>	Filling pressure:	145.0 bar	Valve:	CGA 660 SS
Cylinder Owner:	LINDE	Cylinder Material:	Spectra seal	Cylinder Size:	40 L

## Laboratory Report

## Analytical Result

Component	Normal Concentration	Analysis Result <sup>1</sup>	Uncertainty <sup>2</sup>	Method of Analysis <sup>3</sup>	Assay Date
Sulphur Dioxide In Nitrogen	80.0 ppm	81.4 ppm	± 1% relative	(6) I-PB-352	5-Jul & 12-Jul-21

## Reference Standard used in Assay

Reference Standard	Cylinder number	Concentration	Expiry date:
Sulphur Dioxide In Nitrogen	1331885G	50.50 ± 0.40 ppm	16-Oct-2021

## Analytical Instruments used in Assay

Instrument/Make/Model	Analytical Principle	Last Multipoint Calibration
FTIR Spectrometers Nicolet iS50	FTIR-SO2	7-Jun & 10-Jul-21

## Recommend usage condition

Minimum utilization: 5% of actual content or before expire date whichever comes first.

Storage condition: Keep in well ventilation and secure area.

## Comments

When reordering, please quote the material number

## Note:

- All results expressed in this report are on mole/mole basis, unless otherwise specified. The Assay of this Standard has been performed in accordance with the EPA Traceability Protocol EPA-600/R-12/531 for the Assay and Certification of Gaseous Calibration Standards using procedure G1.
- The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a level of confidence of approximately 95%. The measurement of this material is traceable to the SI through the reference gas standard which is traceable to Swiss National Standard of Mass or other recognised national metrology institutes.
- (1) Gas Chromatography, (2) Paramagnetic Oxygen Analyzer, (3) Electrochemical Oxygen Analyzer, (4) Electrochemical Moisture Analyzer, (5) Total Hydrocarbon Analyzer, (6) Other - Specified

Page 1 of 1

This report shall not be reproduced except in full

บริษัท ลินด์ (ประเทศไทย) จำกัด (มหาชน)

เลขที่ใบอนุญาตประกอบอาชีพ 0107887000785

ชั้น 15 อาคารทาวเวอร์ เอ 2/3 หมู่ 14 ถนนบางนา-ตราด กม. 6.5 ต.บางนา

อ.บางพลี จ.สมุทรปราการ 10540 โทรศัพท์ (66) 2338-6100 โทรสาร (66) 2338-6333

โรงงานผลิตก๊าซ: 105 หมู่ 5 ต.บางพลี อ.บางพลี จ.สมุทรปราการ 24180

โทรศัพท์ (66) 38.570-479-93

โทรสาร (66) 38.570-323

Sukanya Parinyasoonorn

Signatory for and on behalf of Linde (Thailand) Co., Ltd.

PB-002/F006

Linde (Thailand) Public Company Limited Iss: K/1, 01 July 2021

PLC Registration No. 0107537000785

15<sup>th</sup> Floor, Bangna Tower A, 2/3 Moo 14, Bangna Trad KM. 6.5 Road, Bangkaew

Bangplee, Samutprakarn 10540, Tel (66) 2338-6100 Fax (66) 2338-6333

Wellgrow Plant: 105 Moo 5, T.Bangsamak, A.Bangpakong, Chachoengsao 24180

Thailand, Tel (66) 38.570-479-93

Fax (66) 38.570-323

## CERTIFICATE OF ANALYSIS

Customer Details: <b>Secot Co., Ltd.</b>		Production Order Number: <b>90145140</b> Material Number: <b>533100-AL-44</b> Certification Date: <b>23-Nov-2017</b> Expiry Date: <b>23-Nov-2025</b>	
Cylinder Description: <b>Aluminum 50 L</b>			
<p>The measurement of this cylinder content is to be made in 5L through the cylinder number which is marked on the cylinder. The Assay of this standard has been performed in accordance with the IFA Analytical Protocol IFA-600 (Rev. 12/13) for the assay and certification of Gaseous Carbon Monoxide Standards using procedure 6.1. This assay is performed on a gas sample system as specified. The reported concentration is based on a standard uncertainty, defined for concentration, given in parentheses at a confidence of approximately 95%.</p>			
Certificate Number: <b>3785/17</b>	Analyst:  <b>ARISSARA THONGNUE</b>		
Cylinder Number: <b>290206</b>	Approved:  <b>SRANYA SAMUTTAHAKI</b>		
Nominal Cylinder Content: <b>6.900 MP</b>	To Re-Order Please Quote: <b>533100-AL-44</b>		
Nominal Pressure: <b>145.0 Bar</b>			
Valve Outlet: <b>CGA 350 BRASS</b>			
Comments:	<ul style="list-style-type: none"> <li>It is recommended that this product be not used below 95% of nominal contents or should not be used when its gas pressure is below 1.50 MPa.</li> <li>Other impurities that detect by analytical condition of this mixture shall be report if it is more than 10% of minimum without comment.</li> <li>Keep and use in well ventilated and secure area.</li> </ul>		

## CERTIFICATE OF ANALYSIS

Analytical Result					
Component	Request Concentration	Certified Concentration	Certified Uncertainty	Method	Assay Date
Carbon Monoxide In Nitrogen	80.0 ppm	80.1 ppm	± 1 % relative	(6) I-PB-352	21-Nov-2017
Reference Standard used in Assay					
Reference Standard	Cylinder No.	Concentration	Expired Date		
Carbon Monoxide In Nitrogen	184194SG	98.72 ± 0.39 ppm	08-Sep-2018		
Analytical Instruments used in Assay					
Instrument Make/Model	Analytical Principle	Last Calibration Certificate			
Digi LAB Excalibur HE Series	FTIR-CO	25-Oct-2017			
<p>Methods of Analysis:</p> <ol style="list-style-type: none"> <li>Gas Chromatography</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> <li>Gas Chromatography/Mass Spectrometry</li> </ol>					
Cylinder Number: <b>290206</b> Production Order Number <b>90145140</b>			Certification Date: <b>23-Nov-2017</b> Expiration Date: <b>23-Nov-2025</b>		



THAILAND INSTITUTE OF SCIENTIFIC AND TECHNOLOGICAL RESEARCH (TISTR)

Mechanical Engineering Standards Laboratory Soi 1, Bangpoo Industrial Estate, Muang, Samutprakan 10280, Thailand.

Request No.23-65/0223

MTC.No.23-65/0223-02

Number of page(s) 2

## CALIBRATION CERTIFICATE

### Nomenclature : DRYCAL

Manufacturer : Mesa Labs

Serial No.: 160100

Model : Defender 520-L

Scale range : 5 ml/min to 500 ml/min

Subdivision : ( 0.001, 0.01) ml/min

Submitted by : SECOT CO.,LTD.

239, Rimklongprapa Road, Bangsue,  
Bangkok 10800, Thailand.

Received date : 26 January 2022

Condition of measured item : Normal

Calibration date : 3 February 2022

### Standard :

Standard	Certificate No.	Date due	Traceability
RTD Thermometer	PSL-T 336/63	6-Apr-22	TISTR
Molbox/Pressure Transducer/UpStream	MP-0013-21	25-Jan-23	NIMT
Primary Flow Calibrator S/N 117982	MW-0011-21	8-Apr-23	NIMT

Calibrated by :

*Terasak Panna*

(Mr.Terasak Panna)

Approved by

*(Ms.Kirana Luanghirun)*

Director  
TISTR

Mechanical Engineering Standards Laboratory

Ref. 2013265012600367002

Issued Date 3 February 2022

The results relate only to the items tested/calibrated or value assigned.

Advertising the Report/Certificate and publicity of the results except in full are prohibited unless written permission is obtained from the governor of TISTR.

FM.BL.MTC.002 Rev.4

#### Head Office

35 Mu 3 Tambon Khlong Ha, Amphoe Khlong Luang,  
Changwat Pathumthani 12120, Thailand

Tel. (66) 0 2577 9000

Fax. (66) 0 2577 9009

E-mail : rumpai@tistr.or.th Website:www.tistr.or.th

#### Office/Laboratory

Soi 1C, Bangpoo Industrial Estate, Sukhumvit Road,  
Amphoe Muang, Changwat Samutprakan 10280, Thailand

Tel. (66) 0 2323 1672-80 ext. 115, 116

Fax. (66) 0 2323 9165

E-mail : mtc@tistr.or.th

#### Office

196 Phahonyothin Road, Chatuchak, Bangkok 10900,  
Thailand

Tel. (66) 0 2579 1121-30 ext. 5219, 5225, 5217

Fax. (66) 0 2579 8592

E-mail : sumalee@tistr.or.th





THAILAND INSTITUTE OF SCIENTIFIC AND TECHNOLOGICAL RESEARCH (TISTR)

Mechanical Engineering Standards Laboratory Soi 1, Bangpoo Industrial Estate, Muang, Samutprakan 10280, Thailand.

Request No.23-65/0223

2/2

MTC.No.23-65/0223-02

**Calibration point :** (20, 50, 100, 200, 400) ml/min

**Ambient condition :** Temperature (  $23 \pm 3$  ) °C , Relative humidity (  $55 \pm 15$  ) %

Atmospheric pressure (  $1010 \pm 13$  ) hPa

**Calibration method :** The flowmeter (UUC) was calibrated by comparison method with standard flowmeter according to CP-370.01.

The reported value is the value that converted to value at reference condition within pressure and temperature of the actual gas entering the UUC

**Measurement data :**

UUC Value (ml/min)	Standard Value (ml/min)	Temperature (°C)	Pressure (hPa)	Deviation (%)	Uncertainty (%)
*22.473	22.553	25.071	1009.97	-0.35	1.08
53.343	53.559	25.077	1009.93	-0.40	1.01
102.11	103.17	25.075	1010.08	-1.02	1.04
199.33	202.02	25.035	1010.16	-1.33	1.06
404.44	411.64	24.950	1010.43	-1.75	1.00

The reported expanded uncertainties are based on standard uncertainties multiplied by a coverage factor  $k=2$ , which provides a level of confidence of approximately 95%.

\* : The calibration point is not the scope of accreditation.

The end of calibration certificate.

Ts

The results relate only to the items tested/calibrated or value assigned.  
The Report/Certificate and publicity of the results except in full are prohibited unless written permission is obtained from the governor of TISTR.

FM.BL.MTC.002 Rev

Office/Laboratory  
nbon Khlong Ha, Amphoe Khlong Luang,

Office/Laboratory  
Soi 1C, Bangpoo Industrial Estate, Sukhumvit Road,

Office  
196 Phahonyothin Road, Chatuchak, Bangkok 10900

**SOUND LEVEL METER CALIBRATION**Calibration Location: **SECOT**Calibration Date: **Mar 3, 22****SOUND LEVEL CALIBRATOR**

Brand	Model	Serial No.	Calibrated (dB)	Frequency (Hz)		
CASELLA	CEL120/2	2839225	114.0	1000		
No.	Brand	Model	Serial No.	Microphone Serial No.	SLM Reading (dB)	dB Adjust
3	CASELLA	CEL-246	1443758	1443758	113.8	0.2
5	CASELLA	CEL-246	1443838	1443838	114.0	0.0
9	CASELLA	CEL-246	3173156	3173156	113.9	0.1
10	CASELLA	CEL-246	3173161	3173161	114.0	0.0
11	CASELLA	CEL-246	3173243	3173243	113.9	0.1
15	CASELLA	CEL-246	3173311	3173311	113.7	0.3
16	CASELLA	CEL-246	3173312	3173312	114.0	0.0
18	CASELLA	CEL-246	3173324	3173324	114.1	-0.1
20	CASELLA	CEL-246	3173336	3173336	114.2	-0.2
21	CASELLA	CEL-246	3173337	3173337	113.9	0.1
23	CASELLA	CEL-246	3173339	3173339	113.8	0.2
24	CASELLA	CEL-246	3173343	3173343	114.2	-0.2
25	CASELLA	CEL-246	3173350	3173350	113.8	0.2

Calibrated by :

Approved by :



**SOUND LEVEL METER CALIBRATION**Calibration Location: **SECOT**Calibration Date: **May 5, 22****SOUND LEVEL CALIBRATOR**

Brand	Model	Serial No.	Calibrated (dB)	Frequency (Hz)		
CASELLA	CEL120/2	2839225	114.0	1000		
No.	Brand	Model	Serial No.	Microphone Serial No.	SLM Reading (dB)	dB Adjust
2	CASELLA	CEL-246	1443618	1443618	114.0	0.0
4	CASELLA	CEL-246	1443817	1443817	114.0	0.0
5	CASELLA	CEL-246	1443838	1443838	114.2	-0.2
6	CASELLA	CEL-246	3173108	3173108	113.6	0.4
8	CASELLA	CEL-246	3173135	3173135	113.7	0.3
11	CASELLA	CEL-246	3173243	3173243	113.5	0.5
14	CASELLA	CEL-246	3173306	3173306	114.0	0.0
17	CASELLA	CEL-246	3173318	3173318	113.7	0.3
20	CASELLA	CEL-246	3173336	3173336	113.8	0.2
21	CASELLA	CEL-246	3173337	3173337	114.0	0.0
23	CASELLA	CEL-246	3173339	3173339	114.0	0.0
24	CASELLA	CEL-246	3173343	3173343	114.0	0.0
25	CASELLA	CEL-246	3173350	3173350	114.0	0.0

Calibrated by :

Approved by :



**ELECTRICAL AND ELECTRONICS INSTITUTE  
FOUNDATION FOR INDUSTRIAL DEVELOPMENT**

975 Moo 4, Bangpoo Industrial Estate, Soi 8, Sukhumvit Road km 37,

Phraek Sa, Mueang Samut Prakan, Samut Prakan 10280

Tel: +66 2709 4860-8 Fax: +66 2324 0917-8



Certificate No.: CP20210096EA  
Operation No.: CP2021120017

## Certificate of Calibration

Equipment: Sound Calibrator  
Manufacturer: CASELLA  
Model/Type: CEL-120/2  
Serial No.: 2839225  
ID No.:  
Customer: SECOT Co.,Ltd.  
Address: 239 Rimklongprapa Rd., Bangsue,  
Bangkok 10800 Thailand  
Received Date: 21 December 2021  
Calibrated Date: 24 December 2021  
Issued Date: 28 December 2021  
Calibrated by: Ms. Juntaporn Kunhakom

Approved by: \_\_\_\_\_

( Mr. Sittichai Swaksuriyawong )  
Group Manager

This report was prepared electronically using applicable electronic signature. Printing or copy of file are considered as a copy of the document.

The reported uncertainty of measurement was based on standard uncertainty multiplied by a coverage factor  $k = 2.00$ , providing a level of confidence of approximately 95%. This certificate may not be reproduced other than in full except with the prior written approval of the Electrical and Electronics Institute, Foundation for Industrial Development.

Certificate No.: CP20210096EA

### Calibration Report

Equipment: Sound Calibrator  
Manufacturer: CASELLA  
Model/Type: CEL-120/2  
Serial No.: 2839225  
ID No.:  
Ambient Temperature: ( 23 ± 2 ) °C  
Relative Humidity: ( 50 ± 15 ) %  
Pressure: (101.3 ± 1.5) kPa

Method of Calibration :-

IEC 60942:2017

#### Condition of this result of calibration

1. Reference standards instrument :-

Instrument	Model	Serial No.	Cert. No.	Due Date
1) Standard microphone	4180	2661000	AA-1010-21	13 June 2022
2) Waveform Generator	33511B	MY52302264	0144RF21	17 June 2022
3) Audio Analyzing DMM	2015-P	4079144	E1U210398	2 February 2022
4) Pressure humidity and Temperature Transmitter	PTU301	F0640002	CL1-P210047 0255TE21	16 June 2022 7 July 2022

2. This result of calibration was found accurate as shown on date and place of calibration only.

3. This certification is traceable to the international system of unit maintained at :-

Reference standards instrument for Acoustic function

- National Institute of Metrology (Thailand)

Reference standards instrument for Electrical function

- Electrical and Electronics Institute; ONSC Accredited Calibration No.0119

#### Result of Calibration:-

1. Function : Sound pressure level

Norminal Frequency (Hz)	Specified Sound Pressure level (dB)	Measured value (dB)	Deviated value <sup>[1]</sup> (dB)	Acceptance limit <sup>[3]</sup> (dB)
1000	114	114.20	0.20	±0.40

2. Function : Frequency

Norminal Sound Pressure level (dB)	Specified Frequency (Hz)	Measured value (Hz)	Deviated value <sup>[2]</sup> (%)	Acceptance limit <sup>[3]</sup> (%)
114	1000	1000.0	0.0	±1.7

Certificate No.: CP20210096EA

### Calibration Report

#### 3. Function : Total distortion + noise

Norminal Sound Pressure level (dB)	Norminal Frequency (Hz)	Measured value <sup>[4]</sup> (%)	Acceptance limit <sup>[5]</sup> (%)
114	1000	0.4	3.0

#### Uncertainty of measurement

Function	Uncertainty	Maximum-permitted uncertainty of measurement
Sound pressure level	0.10 dB	0.35 dB
Frequency	0.10 %	0.20 %
Total distortion + noise	0.40 %	1.00 %

- Note:
- [1] The deviated value is the absolute value of the difference between the measured value and the corresponding specified sound pressure level.
  - [2] The deviated value is the absolute value of the difference in percent between the measured value and the corresponding specified frequency.
  - [3] The acceptance limit is for the deviated value.
  - [4] The measured value is the total distortion + noise, measured over the frequency range from 20 Hz to 20 kHz.
  - [5] The acceptance limit is for the Measured value.

Remarks: 1. Acceptance limit was IEC 60942:2017 Class 2.

-- End of Report --

ภาคผนวก จ

---

ใบอนุญาตขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน  
จากกรมโรงงานอุตสาหกรรม



ที่ อก ๐๓๑๐(๑)/ ๑๗๕ ๕

กรมโรงงานอุตสาหกรรม  
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท  
เขตราชเทวี กรุงเทพฯ ๑๐๔๐๐

๐๕ กุมภาพันธ์ ๒๕๖๕

เรื่อง เปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์

เรียน กรรมการผู้จัดการ บริษัท ซีคอฟ จำกัด

อ้างถึง คำขอขึ้นทะเบียน/ต่ออายุ/เปลี่ยนแปลงบุคลากร และชนิดสารมลพิษของห้องปฏิบัติการวิเคราะห์เอกชน

ลงวันที่ ๒๘ มกราคม ๒๕๖๕

ตามหนังสือที่อ้างถึง บริษัท ซีคอฟ จำกัด ห้องปฏิบัติการวิเคราะห์เอกชน เลขทะเบียน ว-๒๓๔  
สถานที่ตั้งเลขที่ ๒๓๔ ถนนริมคลองประปา แขวงบางซื่อ เขตบางซื่อ กรุงเทพมหานคร ขอเปลี่ยนแปลง  
บุคลากรของห้องปฏิบัติการวิเคราะห์ ความละเอียดแจ้งแล้ว นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว มีความเห็นดังนี้

๑. ให้อยกเลิกเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๔ ราย

- |                                     |                            |
|-------------------------------------|----------------------------|
| ๑) นางสาวโชติมาส ไทยเจริญ           | ทะเบียนเลขที่ ว-๒๓๔-จ-๖๐๐๖ |
| ๒) นางสาวณัฐศิริ เลิศธีรพัฒน์       | ทะเบียนเลขที่ ว-๒๓๔-จ-๖๔๒๓ |
| ๓) นางสาวเกษวรินทร์ ศิลศึก          | ทะเบียนเลขที่ ว-๒๓๔-จ-๖๔๒๔ |
| ๔) นางสาวจิรนนท์ จิตตะศรี ปิยะธนากร | ทะเบียนเลขที่ ว-๒๓๔-จ-๗๒๓๒ |

๒. ให้เพิ่มผู้ควบคุมดูแลห้องปฏิบัติการวิเคราะห์ จำนวน ๑ ราย

- |                            |                            |
|----------------------------|----------------------------|
| นางสาวณัฐศิริ เลิศธีรพัฒน์ | ทะเบียนเลขที่ ว-๒๓๔-จ-๐๐๐๑ |
|----------------------------|----------------------------|


๓. ให้เพิ่มเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๒ ราย

- |                                    |                            |
|------------------------------------|----------------------------|
| ๑) นางสาวสุศุภาพร สุนทร            | ทะเบียนเลขที่ ว-๒๓๔-จ-๐๐๐๑ |
| ๒) นางสาวลัญญลักษณ์ อินทรประสิทธิ์ | ทะเบียนเลขที่ ว-๒๓๔-จ-๐๐๐๒ |

อนึ่ง หนังสือฉบับนี้จะหมดอายุพร้อมหนังสือต่ออายุรับขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน  
ที่ อก ๐๓๑๐(๑)/๑๑๘๐๔ ลงวันที่ ๒๑ ตุลาคม ๒๕๖๓ คือในวันที่ ๒ พฤษภาคม ๒๕๖๖ ทั้งนี้ สามารถยื่นคำ  
ขอผ่านระบบอิเล็กทรอนิกส์ได้ที่หน้าเว็บไซต์กรมโรงงานอุตสาหกรรม ตาม QR Code ท้ายหนังสือฉบับนี้

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

  
(นางจันทา เดชะศรีนทร์)

ผู้อำนวยการกองวิจัยและเตือนภัยมลพิษโรงงาน  
ปฏิบัติการตามแผนปฏิบัติการกรมโรงงานอุตสาหกรรม



ยื่นคำขอผ่านระบบอิเล็กทรอนิกส์

กองวิจัยและเตือนภัยมลพิษโรงงาน

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษและทะเบียนห้องปฏิบัติการ

โทร. ๐ ๒๕๓๐ ๖๓๑๒ ต่อ ๒๑๐๓-๕

โทรสาร ๐ ๒๕๓๐ ๖๓๑๒ ต่อ ๒๑๙๙

ไปรษณีย์อิเล็กทรอนิกส์ saraban@diw.mail.go.th



ที่ อก ๐๓๑๐(๑)/ ๑๑ ๘ ๐ ๕

กรมโรงงานอุตสาหกรรม  
ถนนพระรามที่ ๖ เขตราชเทวี  
กรุงเทพมหานคร ๑๐๔๐๐

๒๑ ตุลาคม ๒๕๖๓

เรื่อง ต่ออายุหนังสือรับขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน

เรียน กรรมการผู้จัดการ บริษัท ซีคอฟ จำกัด

อ้างถึง คำขอขึ้นทะเบียน/ต่ออายุ/เปลี่ยนแปลงบุคลากร และชนิดสารมลพิษของห้องปฏิบัติการวิเคราะห์เอกชน  
ลงวันที่ ๒๔ มีนาคม ๒๕๖๓

สิ่งที่ส่งมาด้วย ๑. รายชื่อผู้ควบคุมดูแลห้องปฏิบัติการวิเคราะห์ จำนวน ๑ แผ่น

๒. รายชื่อเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๑ แผ่น

๓. ขอบข่ายสารมลพิษที่ได้รับขึ้นทะเบียนจากกรมโรงงานอุตสาหกรรม จำนวน ๓๒ แผ่น

ตามหนังสือที่อ้างถึง บริษัท ซีคอฟ จำกัด ขอต่ออายุหนังสือรับขึ้นทะเบียนห้องปฏิบัติการ  
วิเคราะห์เอกชน เลขทะเบียน ว-๒๓๔ สถานที่ตั้งเลขที่ ๒๓๔ ถนนริมคลองประปา แขวงบางซื่อ เขตบางซื่อ  
กรุงเทพมหานคร ต่อกรมโรงงานอุตสาหกรรม นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว ให้บริษัท ซีคอฟ จำกัด ต่ออายุหนังสือรับขึ้นทะเบียน  
ห้องปฏิบัติการวิเคราะห์เอกชน โดยมีองค์ประกอบดังนี้

ก. ผู้ควบคุมดูแลห้องปฏิบัติการวิเคราะห์ จำนวน ๑๐ ราย ตามสิ่งที่ส่งมาด้วย ๑

ข. เจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๓๑ ราย ตามสิ่งที่ส่งมาด้วย ๒

ค. ขอบข่ายสารมลพิษที่ได้รับขึ้นทะเบียนให้วิเคราะห์ในน้ำเสีย จำนวน ๔๖ รายการ น้ำใต้ดิน  
จำนวน ๑๒๓ รายการ อากาศเสีย จำนวน ๒๗ รายการ สิ่งปฏิกูลหรือวัสดุที่ไม่ใช้แล้ว จำนวน ๓๔ รายการ  
และดิน จำนวน ๑๒๒ รายการ รวมทั้งสิ้นจำนวน ๓๕๒ รายการ ตามสิ่งที่ส่งมาด้วย ๓

หนังสือฉบับนี้จะหมดอายุในวันที่ ๒ พฤษภาคม ๒๕๖๖ หากประสงค์จะต่ออายุหนังสือ  
รับขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน ให้ยื่นคำขอต่ออายุพร้อมเอกสารประกอบคำขอต่อ  
กรมโรงงานอุตสาหกรรมภายใน ๓๐ วัน ก่อนวันสิ้นสุดอายุของหนังสือรับขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน  
ซึ่งคำขอต่ออายุดังกล่าวขอรับได้ที่กรมโรงงานอุตสาหกรรม

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

  
(นางจันทา เดชะศรีนทร์)

ผู้อำนวยการกองวิจัยและเตือนภัยมลพิษโรงงาน  
ปฏิบัติการตามแผนปฏิบัติการกรมโรงงานอุตสาหกรรม

กองวิจัยและเตือนภัยมลพิษโรงงาน

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษและทะเบียนห้องปฏิบัติการ

โทร. ๐ ๒๒๐๒ ๔๐๐๒ ๐ ๒๒๐๒ ๔๑๔๖

โทรสาร ๐ ๒๓๕๕ ๓๒๐๘ ๐ ๒๓๕๕ ๓๔๑๕



เอกสารแนบท้ายหนังสือรับต่ออายุขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน

บริษัท ซีคอฟ จำกัด

เลขทะเบียน ว-๒๓๙

ที่ ออก ๐๓๑๐(๑)/ ๑ ๑ ๘ ๐ ๕

ลงวันที่ ๒๑ ตุลาคม ๒๕๖๓

ก. ผู้ควบคุมดูแลห้องปฏิบัติการวิเคราะห์ จำนวน ๑๐ ราย

๑) นางสาวฤดี เกรียงไกรอุดม	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๘๒๐
๒) นางสาวอารยา ทิพรัักษ์	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๘๖๓
๓) นายขรรชัย เกรียงไกรอุดม	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๙๗๕
๔) นางสาวเขมขุตา อินทร์ศร	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๙๗๖
๕) นางสาวปรีดา สมใจ	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๙๗๘
๖) นางสาวอรัญญา มาตา	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๙๗๙
๗) นางสาวลดาวัลย์ วงศ์เจริญ	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๙๘๐
๘) นางสาวมณีนวรัตน์ เกตะวันดี	ทะเบียนเลขที่ ว-๒๓๙-ค-๕๙๘๒
๙) นางสาวนริสา ภูวสรเพ็ชฌ์	ทะเบียนเลขที่ ว-๒๓๙-ค-๖๔๑๙
๑๐) นางสาวศิริวรรณ ฉิมสง่า	ทะเบียนเลขที่ ว-๒๓๙-ค-๖๔๒๐

เอกสารแนบท้ายหนังสือรับต่ออายุขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน

บริษัท ซีคอฟ จำกัด

เลขทะเบียน ว-๒๓๙

ที่ ออก ๐๓๑๐(๑)/ ๑ ๑ ๘ ๐ ๕

ลงวันที่ ๒๑ ตุลาคม ๒๕๖๓

ข. เจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๓๑ ราย

๑) นางสาวสุรัชวิ ศัยธรรม	ทะเบียนเลขที่ ว-๒๓๙-จ-๕๘๒๕
๒) นางสาวสุธาทิพย์ เทียนเตี้ย	ทะเบียนเลขที่ ว-๒๓๙-จ-๕๘๒๙
๓) นางสาวสุนันทา ศิริคุณานนท์	ทะเบียนเลขที่ ว-๒๓๙-จ-๕๙๘๓
๔) นายบวร ดีชัยยะ	ทะเบียนเลขที่ ว-๒๓๙-จ-๕๙๘๖
๕) นางสาวเกศรินทร์ วรเดชาวิทยา	ทะเบียนเลขที่ ว-๒๓๙-จ-๕๙๘๑
๖) นายอนันต์ พินวันนา	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๐๐๑
๗) นายชิตพล สมประสงค์	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๐๐๒
๘) นางสาวศศิธร พรหมประเสริฐ	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๐๐๓
๙) นายศิวนนท์ กลวงษ์	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๐๐๕
๑๐) นางสาวโซติมาส ไทยเจริญ	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๐๐๖
๑๑) นางสาวปิยขวัญ สุระโคตร	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๔๒๑
๑๒) นางสาวณัฐศิริ เลิศธีรพัฒน์	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๔๒๓
๑๓) นางสาวเกษวรินทร์ ศิลศักดิ์	ทะเบียนเลขที่ ว-๒๓๙-จ-๖๔๒๔
๑๔) นางสาวอลิษา คณิรานนท์	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๓๑
๑๕) นางสาวจิรนนท์ จัตุทะศรี ปิยะธนากร	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๓๒
๑๖) นางสาวสิริวรรณ แก้วชิงดวง	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๓๓
๑๗) นางสาวปัทมวรรณ สุวรรณวิโรจน์	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๓๔
๑๘) นางสาวกนิษฐา เจริญเชื้อ	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๓๖
๑๙) นายจิรากร ลิมศิลา	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๓๗
๒๐) นายชนาธิป สิงห์เกษมศักดิ์	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๓๘
๒๑) นายวัชรกานต์ ประมาคะเต	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๔๐
๒๒) นายทอง เสงฆ์กุล	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๒๔๒
๒๓) นางสาวกฤษณา จันทุม	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๘๐๒
๒๔) นางสาวพรนภา บุตรธรรม	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๘๐๓
๒๕) นางสาวธริณี อาจปลิว	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๘๐๔
๒๖) นายธนโชติ ช่างลื้อ	ทะเบียนเลขที่ ว-๒๓๙-จ-๗๘๐๖
๒๗) นางสาวพัชรา สมานฉันท	ทะเบียนเลขที่ ว-๒๓๙-จ-๘๑๓๓
๒๘) นางสาวจุฑารัตน์ แจ่มเรือน	ทะเบียนเลขที่ ว-๒๓๙-จ-๘๑๔๓
๒๙) นางสาวจณิสตา กุ้ยอ่อน	ทะเบียนเลขที่ ว-๒๓๙-จ-๘๑๓๗
๓๐) นางสาววรัญญา เขียนมน	ทะเบียนเลขที่ ว-๒๓๙-จ-๘๑๓๘
๓๑) นางสาวจิรารัตน์ นุริตมนต์	ทะเบียนเลขที่ ว-๒๓๙-จ-๘๑๓๙

เอกสารแนบท้ายหนังสือรับต่ออายุขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน

บริษัท ซีคอน จำกัด

เลขทะเบียน ว-๒๓๙

ที่ ออก ๐๓๑๐(๑)/ ๑๑ ๘ ๐๔

ลงวันที่ ๒๑ ตุลาคม ๒๕๖๓

ขอขยายสารมลพิษที่ได้รับขึ้นทะเบียนจากกรมโรงงานอุตสาหกรรม จำนวน ๓๕๒ รายการ

น้ำเสีย จำนวน 46 รายการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
1	Aldrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
2	Arsenic	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[4]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
3	Barium	1) Digestion, Direct Nitrous Oxide-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
4	α-BHC	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
5	β-BHC	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
6	γ-BHC	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
7	δ-BHC	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
8	Biochemical Oxygen Demand	1) 5-Day BOD Test, Azide Modification Method <sup>[4]</sup> 2) 5-Day BOD Test, Membrane Electrode Method <sup>[4]</sup>
9	Cadmium	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>

(นางริกาญจน์ ฉัตรสกุลโล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

10 Chemical...

-๒-

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
10	Chemical Oxygen Demand	1) Open Reflux, Titrimetric method <sup>[4]</sup> 2) Close Reflux, Colorimetric method <sup>[4]</sup> 3) Closed Reflux, Titrimetric Method <sup>[4]</sup>
11	Chlordane	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
12	Chromium	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
13	Color	ADMI Weighted-Ordinate Spectrophotometric Method <sup>[4]</sup>
14	Copper	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
15	Cyanide	Distillation, Colorimetric method <sup>[4]</sup>
16	2,4-D	Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
17	4,4'-DDD	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
18	4,4'-DDE	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
19	4,4'-DDT	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
20	Dieldrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>

(นางริกาญจน์ ฉัตรสกุลโล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

และทะเบียนห้องปฏิบัติการ

21 Endosulfan I...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
21	Endosulfan I	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
22	Endosulfan II	2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
23	Endosulfan Sulfate	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
24	Endrin	2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
25	Endrin Aldehyde	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
26	Formaldehyde	2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
27	Free Chlorine	Distillation, Colorimetric Method <sup>[3]</sup>
28	Heptachlor	1) Iodometric Method <sup>[4]</sup>
29	Heptachlor epoxide	2) DPD Colorimetric Method <sup>[4]</sup>
30	Hexavalent Chromium	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
31	Lead	2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[4]</sup>
		1) Colorimetric Method <sup>[4]</sup>
		2) Extraction, Air-Acetylene Flame Method <sup>[4]</sup>
		1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup>
		2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup>
		3) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>

(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

32 Manganese...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
32	Manganese	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup>
33	Mercury	2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup>
34	Methoxychlor	3) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
35	Nickel	Digestion, Cold-Vapor Atomic Absorption Spectrometric Method <sup>[4]</sup>
36	Oil & Grease	Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
37	pH	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup>
38	Phenols	2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup>
39	Selenium	3) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
40	Sulfide	1) Liquid-Liquid, Partition-Gravimetric Method <sup>[4]</sup>
41	Temperature	2) Soxhlet Extraction Method <sup>[4]</sup>
42	Total Dissolved Solids	Electrometric Method <sup>[4]</sup>
43	Total Kjeldahl Nitrogen	1) Distillation, Chloroform Extraction Method <sup>[4]</sup>
44	Total Suspended Solids	2) Distillation, Direct Photometric Method <sup>[4]</sup>
45	Trivalent Chromium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[4]</sup>
		2) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
		1) Iodometric method <sup>[4]</sup>
		2) Methylene blue method <sup>[4]</sup>
		Laboratory and Field Methods <sup>[4]</sup>
		Dried at 180 °C <sup>[4]</sup>
		1) Macro Kjeldahl Method <sup>[4]</sup>
		2) Semi-Micro Kjeldahl Method <sup>[4]</sup>
		Dried at 103-105 °C <sup>[4]</sup>
		1) Digestion, Direct Air-Acetylene Flame Method; Colorimetric Method; Calculation <sup>[4]</sup>
		2) Digestion, Electrothermal Atomic Absorption Spectrometric Method; Colorimetric Method; Calculation <sup>[4]</sup>
		3) Digestion, Inductively Coupled Plasma Method; Colorimetric Method; Calculation <sup>[4]</sup>
46	Zinc	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup>
		2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup>
		3) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>

(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

น้ำใต้ดิน...

น้ำใต้ดิน จำนวน 123 รายการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
1	Acenaphthene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
2	Acetone	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
3	Aldrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>(4)</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
4	Anthracene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
5	Antimony	Digestion, Inductively Coupled Plasma Spectrometric Method <sup>(4)</sup>
6	Arsenic	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>(4)</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>(4)</sup>
7	Atrazine	Liquid-Liquid Extraction, Gas Chromatographic Method <sup>(4)</sup>
8	Barium	1) Digestion, Direct Nitrous Oxide-Acetylene Flame Method <sup>(4)</sup> 2) Digestion, Inductively Coupled Plasma Spectrometric Method <sup>(4)</sup>
9	Benz(a)anthracene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
10	Benzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>(4)</sup>
11	Benzo(b)fluoranthene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
12	Benzo(k)fluoranthene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
13	Benzoic acid	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
14	Benzo(a)pyrene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
15	Benzo(g,h,i)perylene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>

วิภา

16 Beryllium...

(นางริกาญจน์ จักรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
16	Beryllium	Digestion, Inductively Coupled Plasma Spectrometric Method <sup>(4)</sup>
17	Bis(2-chloroethyl)ether	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
18	Bis(2-ethylhexyl)phthalate	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
19	Bromodichloromethane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>(4)</sup>
20	Bromoform	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>(4)</sup>
21	Butanol	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>(4)</sup>
22	Butyl benzyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
23	Cadmium	1) Digestion, Direct Air-Acetylene Flame Method <sup>(4)</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>(4)</sup> 3) Digestion, Inductively Coupled Plasma Spectrometric Method <sup>(4)</sup>
24	Carbazole	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
25	Carbon disulfide	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>(4)</sup>
26	Carbon tetrachloride	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>(4)</sup>
27	Chlordane	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>(4)</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
28	p-Chloroaniline	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>(4)</sup>
29	Chlorobenzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>(4)</sup>
30	Chlorodibromomethane	Purge and Trap Gas Chromatographic/Mass spectrometric Method <sup>(4)</sup>
31	Chloroform	Purge and Trap Gas Chromatographic/Mass spectrometric Method <sup>(4)</sup>

วิภา

32 2-Chlorophenol...

(นางริกาญจน์ จักรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ



ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
32	2-Chlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
33	Chromium	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Spectrometric Method <sup>[4]</sup>
34	Chromium (III)	1) Digestion, Direct Air-Acetylene Flame Method; Colorimetric Method; Calculation <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method; Colorimetric Method; Calculation <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Spectrometric Method; Colorimetric Method; Calculation <sup>[4]</sup>
35	Chromium (VI)	1) Colorimetric Method <sup>[4]</sup> 2) Extraction, Air-Acetylene Flame Method <sup>[4]</sup>
36	Chrysene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
37	Cyanide	1) Distillation, Titrimetric Method <sup>[4]</sup> 2) Distillation, Colorimetric Method <sup>[4]</sup>
38	2,4-D	Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
39	DDD	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
40	DDE	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
41	DDT	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>



(นางรียาญจน์ จิตรสกุลวิไล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ

42 Dibenz(a,h)...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
42	Dibenz(a,h)anthracene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
43	Di-n-butyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
44	1,2-Dichlorobenzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
45	1,3-Dichlorobenzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
46	1,4-Dichlorobenzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
47	3,3'-Dichlorobenzidine	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
48	1,1-Dichloroethane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
49	1,2-Dichloroethane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
50	1,1-Dichloroethylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
51	cis-1,2-Dichloroethylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
52	trans-1,2-Dichloroethylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
53	2,4-Dichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
54	1,2-Dichloropropane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
55	1,3-Dichloropropane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
56	1,3-Dichloropropene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
57	Dieldrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
58	Diethyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>



(นางรียาญจน์ จิตรสกุลวิไล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ

59 2,4-Dimethylphenol...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
59	2,4-Dimethylphenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
60	2,4-Dinitrophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
61	2,4-Dinitrotoluene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
62	2,6-Dinitrotoluene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
63	Di-n-Octyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
64	Endosulfan	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
65	Endrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
66	Ethylbenzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
67	Fluoranthene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
68	Fluorene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
69	Heptachlor	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
70	Heptachlor epoxide	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
71	Hexachlorobenzene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
72	Hexachloro-1,3-butadiene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>

วิทย์

73 n-Hexane...

(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
73	n-Hexane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
74	$\alpha$ -HCH	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
75	$\beta$ -HCH	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
76	$\gamma$ -HCH	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
77	Hexachlorocyclopentadiene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
78	Hexachloroethane	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
79	Indeno(1,2,3-cd)pyrene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
80	Isophorone	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
81	Lead	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Spectrometric Method <sup>[4]</sup>
82	Manganese	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Spectrometric Method <sup>[4]</sup>
83	Mercury	Digestion, Cold-Vapor Atomic Absorption Spectrometric Method <sup>[4]</sup>
84	Methanol	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>

วิทย์

85 Methoxychlor...

(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ



ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
85	Methoxychlor	Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
86	Methyl bromide	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
87	Methylene chloride	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
88	2-Methylphenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
89	2-Methylnaphthalene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
90	Methyl tert-butyl ether	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
91	Naphthalene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
92	Nickel	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Spectrometric Method <sup>[4]</sup>
93	Nitrobenzene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
94	N-Nitrosodiphenylamine	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
95	Polychlorinated Biphenyls - PCB-1016 - PCB-1221 - PCB-1232 - PCB-1242 - PCB-1248 - PCB-1254 - PCB-1260	Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup>
96	Pentachlorophenol	1) Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[4]</sup> 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>

97 pH...

(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
97	pH	Electrometric method <sup>[4]</sup>
98	Phenanthrene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
99	Phenol	1) Distillation, Chloroform Extraction Method <sup>[4]</sup> 2) Distillation, Direct Photometric Method <sup>[4]</sup> 3) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
100	Pyrene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
101	Selenium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[4]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
102	Silver	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[4]</sup>
103	Styrene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
104	1,1,2,2-Tetrachloroethane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
105	Tetrachloroethylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
106	Toluene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
107	TPH (C <sub>5</sub> -C <sub>8</sub> )	Purge and Trap, Gas Chromatographic/ Mass spectrometric Method <sup>[7,9]</sup>
108	TPH (C <sub>9</sub> -C <sub>16</sub> )	1) Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[6,8]</sup> 2) Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass spectrometric Method <sup>[6,9]</sup>
109	TPH (C <sub>16</sub> -C <sub>35</sub> )	1) Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[6,8]</sup> 2) Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass spectrometric Method <sup>[6,9]</sup>
110	1,2,4-Trichlorobenzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
111	1,1,1-Trichloroethane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>

112 1,1,2-Trichloroethane...


(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
112	1,1,2-Trichloroethane	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
113	Trichloroethylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
114	2,4,5-Trichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
115	2,4,6-Trichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[4]</sup>
116	1,3,5-Trimethylbenzene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
117	Vanadium	Digestion, Inductively Coupled Plasma Spectrometric Method <sup>[4]</sup>
118	Vinyl chloride	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
119	m-Xylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
120	o-Xylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
121	p-Xylene	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
122	Xylene (Total)	Purge and Trap Gas Chromatographic/ Mass spectrometric Method <sup>[4]</sup>
123	Zinc	1) Digestion, Direct Air-Acetylene Flame Method <sup>[4]</sup> 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method <sup>[4]</sup> 3) Digestion, Inductively Coupled Plasma Spectrometric Method <sup>[4]</sup>

## อากาศเสีย (ปล่อยระบาย) จำนวน 27 รายการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
1	Antimony	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>

  
 (นางริกาญจน์ จิตรสกุลไชโย)  
 ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
 และทะเบียนห้องปฏิบัติการ

2 Arsenic...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
2	Arsenic	1) Isokinetic Sampling, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
3	Beryllium	Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
4	Cadmium	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
5	Carbon monoxide	Instrumental Analyzer Method <sup>[5]</sup>
6	Chlorine	1) Absorption Sampling, Ion Chromatographic Method <sup>[5]</sup> 2) Isokinetic Sampling, Ion Chromatographic Method <sup>[5]</sup>
7	Chromium	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
8	Cobalt	Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
9	Copper	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
10	Cresol	Adsorption Sampling, Gas Chromatographic Method <sup>[5]</sup>
11	Dioxin/Furans	Isokinetic Sampling, Analysis by ISO/IEC 17025 Accredited Laboratory or Analysis by Department of Industrial Works Registered Laboratory (Dioxins/Furans Analysis Approved) <sup>[5]</sup>
12	Hydrogen chloride	1) Absorption Sampling, Ion Chromatographic Method <sup>[5]</sup> 2) Isokinetic Sampling, Ion Chromatographic Method <sup>[5]</sup>
13	Hydrogen Fluoride	1) Absorption Sampling, Ion Chromatographic Method <sup>[5]</sup> 2) Isokinetic Sampling, Ion Chromatographic Method <sup>[5]</sup>

  
 (นางริกาญจน์ จิตรสกุลไชโย)  
 ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

14 Hydrogen Sulfide...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
14	Hydrogen Sulfide	Absorption Sampling, Iodometric Method <sup>[5]</sup>
15	Lead	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
16	Manganese	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
17	Mercury	Isokinetic Sampling, Digestion, Cold-Vapor Atomic Absorption Spectrometric Method <sup>[5]</sup>
18	Nickel	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
19	Opacity	Ringelmann's Method <sup>[2]</sup>
20	Oxide of Nitrogen	1) Absorption Sampling, Ion Chromatographic Method <sup>[5]</sup> 2) Absorption Sampling, Phenoldisulfonic acid Method <sup>[5]</sup> 3) Instrumental Analyzer Method <sup>[5]</sup>
21	Selenium	1) Isokinetic Sampling, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[5]</sup> 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
22	Sulfur dioxide	1) Isokinetic Sampling, Barium-Thorin Titrimetric Method <sup>[5]</sup> 2) Instrumental Analyzer Method <sup>[5]</sup>
23	Sulfuric acid	Isokinetic Sampling, Barium-Thorin Titrimetric Method <sup>[5]</sup>
24	Tin	Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
25	Total Suspended Particulate	Isokinetic Sampling, Gravimetric Method <sup>[5]</sup>

26 Vanadium...

วิมล  
(นางริกาญจน์ ฉัตรสกุลวิไล)  
ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
26	Vanadium	Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method <sup>[5]</sup>
27	Xylene	1) Adsorption Sampling, Gas Chromatographic Method <sup>[5]</sup> 2) Adsorption Sampling, Gas Chromatographic/Mass Spectrometric Method <sup>[5]</sup>

## สิ่งปฏิกูลหรือวัสดุที่ไม่ใช้แล้ว จำนวน 34 รายการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
1	Aldrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
2	Antimony	1) Waste Extraction, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[1,6,16]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[7,16]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
3	Arsenic	1) Waste Extraction, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[1,6,16]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[7,16]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
4	Barium	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method <sup>[1,6,15]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup>

วิมล  
(นางริกาญจน์ ฉัตรสกุลวิไล)  
ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ

3) Digestion...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
5	Beryllium	3) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup> 1) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
6	Cadmium	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method <sup>[1,6,15]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
7	Chlordane	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
8	Chromium	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method <sup>[1,6,15]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
9	Chromium (III)	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method; Waste Extraction, Colorimetric Method; Calculation Method <sup>[1,6,15,17]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method; Waste Extraction, Colorimetric Method; Calculation Method <sup>[1,6,16,17]</sup>



(นางริยาญณ์ นิตกรสกุลไธ)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

3) Digestion...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
10	Chromium (VI)	3) Digestion, Flame Atomic Absorption Spectrometric Method; Alkaline Digestion, Colorimetric Method; Calculation Method <sup>[7,8,15,17]</sup> 4) Digestion, Inductively Coupled Plasma Method; Alkaline Digestion, Colorimetric Method; Calculation Method <sup>[7,8,14,17]</sup>
11	Cobalt	1) Waste Extraction, Colorimetric Method <sup>[1,17]</sup> 2) Alkaline Digestion, Colorimetric Method <sup>[8,17]</sup> 1) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
12	Copper	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method <sup>[1,6,15]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
13	2,4-D	1) Waste Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,24]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[24]</sup>
14	DDD	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
15	DDE	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup>



(นางริยาญณ์ นิตกรสกุลไธ)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

3) Soxhlet...



ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
16	DDT	3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup> 1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
17	Dieldrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
18	Endrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
19	Heptachlor	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet...

(นางรวิภาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
20	Lead	4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup> 1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method <sup>[1,6,15]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
21	Lindane	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
22	Mercury	1) Waste Extraction, Digestion, Cold-Vapor Atomic Absorption Spectrometric Method <sup>[1,18]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Cold-Vapor Atomic Absorption Spectrometric Method <sup>[1,9]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
23	Methoxychlor	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,22]</sup> 2) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,9,26]</sup> 3) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,22]</sup> 4) Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
24	Molybdenum	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>

(นางรวิภาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ

25 Nickel...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
25	Nickel	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method <sup>[1,6,15]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
26	Polychlorinated Biphenyls - Aroclor 1016 - Aroclor 1221 - Aroclor 1232 - Aroclor 1242 - Aroclor 1248 - Aroclor 1254 - Aroclor 1260	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method <sup>[1,9,23]</sup> 2) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,23]</sup>
27	Pentachlorophenol	1) Waste Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[1,24]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[24]</sup>
28	pH	Electrometric Method <sup>[30,31]</sup>
29	Selenium	1) Waste Extraction, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[1,6,20]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[7,20]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
30	Silver	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
31	Thallium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
32	Trichloroethylene	1) Waste Extraction, Purge and Trap, Gas Chromatographic/Mass Spectrometric Method <sup>[1,12,25]</sup> 2) Purge and Trap, Gas Chromatographic/Mass Spectrometric Method <sup>[12,25]</sup>

(นางรียาญจน์ ฉัตรสกุลวิไล)

33 Vanadium...

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
33	Vanadium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
34	Zinc	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method <sup>[1,6,15]</sup> 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method <sup>[1,6,14]</sup> 3) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 4) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>

## ดิน จำนวน 122 รายการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
1	Acenaphthene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
2	Acetone	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method <sup>[13,25]</sup>
3	Aldrin	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
4	Anthracene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
5	Antimony	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[7,16]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
6	Arsenic	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[7,16]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
7	Atrazine	Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup>
8	Barium	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>

9 Benz(a)anthracene...

วิมล

(นางรียาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ



ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
9	Benz(a)anthracene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
10	Benzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
11	Benzo(b)fluoranthene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
12	Benzo(k)fluoranthene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
13	Benzoic acid	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
14	Benzo(a)pyrene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
15	Benzo(g,h,i)perylene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
16	Beryllium	Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
17	Bis(2-chloroethyl)ether	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
18	Bis(2-ethylhexyl)phthalate	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
19	Bromodichloromethane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
20	Bromoform	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
21	Butanol	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
22	Butyl benzyl phthalate	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
23	Cadmium	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
24	Carbazole	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
25	Carbon disulfide	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
26	Carbon tetrachloride	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>

27 Chlordane...

(นางริกาญจน์ ฉัตรสกุลวิไล)  
ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และประเมินภัยสุขภาพ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
27	Chlordane	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
28	p-Chloroaniline	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
29	Chlorobenzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
30	Chlorodibromomethane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
31	Chloroform	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
32	2-Chlorophenol	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
33	Chromium	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
34	Chromium (III)	1) Digestion, Flame Atomic Absorption Spectrometric Method; Colorimetric Method; Calculation Method <sup>[7,8,15,17]</sup> 2) Digestion, Inductively Coupled Plasma Method; Colorimetric Method; Calculation Method <sup>[7,8,14,17]</sup>
35	Chromium (VI)	Alkaline Digestion, Colorimetric Method <sup>[8,17]</sup>
36	Chrysene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
37	Cyanide	1) Extraction, Distillation, Titrimetric Method <sup>[27,28,29]</sup> 2) Extraction, Distillation, Colorimetric Method <sup>[27,28,29]</sup>
38	2,4-D	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[24]</sup>
39	DDD	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
40	DDE	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>

(นางริกาญจน์ ฉัตรสกุลวิไล)  
ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

41 DDT...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
41	DDT	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
42	Dibenz(a,h)anthracene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
43	Di-n-butyl phthalate	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
44	1,2-Dichlorobenzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
45	1,3-Dichlorobenzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
46	1,4-Dichlorobenzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
47	3,3'-Dichlorobenzidine	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
48	1,1-Dichloroethane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
49	1,2-Dichloroethane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
50	1,1-Dichloroethylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
51	cis-1,2-Dichloroethylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
52	trans-1,2-Dichloroethylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
53	2,4-Dichlorophenol	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
54	1,2-Dichloropropane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
55	1,3-Dichloropropane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
56	1,3-Dichloropropene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>



57 Dieldrin...

(นางริกาญจน์ จิตรสกุลชัย)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

และทะเบียนห้องปฏิบัติการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
57	Dieldrin	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
58	Diethyl phthalate	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
59	2,4-Dimethylphenol	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
60	2,4-Dinitrophenol	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
61	2,4-Dinitrotoluene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
62	2,6-Dinitrotoluene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
63	Di-n-Octyl phthalate	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
64	Endosulfan	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
65	Endrin	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
66	Ethylbenzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
67	Fluoranthene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
68	Fluorene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
69	Heptachlor	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>




70 Heptachlor epoxide...

(นางริกาญจน์ จิตรสกุลชัย)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

และทะเบียนห้องปฏิบัติการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
70	Heptachlor epoxide	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
71	Hexachlorobenzene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
72	Hexachloro-1,3-butadiene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
73	n-Hexane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method <sup>[13,25]</sup>
74	$\alpha$ -HCH	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
75	$\beta$ -HCH	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
76	$\gamma$ -HCH	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
77	Hexachlorocyclopentadiene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
78	Hexachloroethane	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
79	Indeno(1,2,3-cd)pyrene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
80	Isophorone	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
81	Lead	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
82	Manganese	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>



(นางรียาญจน์ จิตรสกุลวิไล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

และทะเบียนห้องปฏิบัติการ

83 Mercury...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
83	Mercury	1) Digestion, Cold-Vapor Atomic Absorption Spectrometric Method <sup>[19]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
84	Methanol	Ultrasonic Extraction, Direct Aqueous Injection, Gas Chromatographic Method <sup>[11,21]</sup>
85	Methoxychlor	1) Ultrasonic Extraction, Gas Chromatographic Method <sup>[11,22]</sup> 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
86	Methyl bromide	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method <sup>[13,25]</sup>
87	Methylene chloride	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method <sup>[13,25]</sup>
88	2-Methylphenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
89	2-Methylnaphthalene	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[11,26]</sup>
90	Methyl tert-butyl ether	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method <sup>[13,25]</sup>
91	Naphthalene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
92	Nickel	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
93	Nitrobenzene	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
94	N-Nitrosodiphenylamine	Soxhlet Extraction, Gas Chromatographic/Mass Spectrometric Method <sup>[10,26]</sup>
95	Polychlorinated Biphenyls - Aroclor 1016 - Aroclor 1221 - Aroclor 1232 - Aroclor 1242 - Aroclor 1248 - Aroclor 1254 - Aroclor 1260	Soxhlet Extraction, Gas Chromatographic Method <sup>[10,23]</sup>



(นางรียาญจน์ จิตรสกุลวิไล)

ผู้อำนวยการศูนย์มาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

และทะเบียนห้องปฏิบัติการ

96 Pentachlorophenol...

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
96	Pentachlorophenol	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[24]</sup>
97	Phenanthrene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
98	Phenol	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
99	Pyrene	Soxhlet Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[10,26]</sup>
100	Selenium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method <sup>[7,20]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
101	Silver	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
102	Styrene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
103	1,1,2,2-Tetrachloroethane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
104	Tetrachloroethylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
105	Toluene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
106	TPH (C <sub>5</sub> -C <sub>8</sub> )	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
107	TPH (C <sub>8</sub> -C <sub>16</sub> )	1) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,21]</sup> 2) Soxhlet Extraction, Gas Chromatographic/ Mass spectrometric Method <sup>[10,21]</sup>
108	TPH (C <sub>16</sub> -C <sub>35</sub> )	1) Soxhlet Extraction, Gas Chromatographic Method <sup>[10,21]</sup> 2) Soxhlet Extraction, Gas Chromatographic/ Mass spectrometric Method <sup>[10,25]</sup>
109	1,2,4-Trichlorobenzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
110	1,1,1-Trichloroethane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
111	1,1,2-Trichloroethane	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
112	Trichloroethylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
113	2,4,5-Trichlorophenol	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
114	2,4,6-Trichlorophenol	Ultrasonic Extraction, Gas Chromatographic/ Mass Spectrometric Method <sup>[11,26]</sup>
115	1,3,5-Trimethylbenzene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
116	Vanadium	Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>
117	Vinyl chloride	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
118	m-Xylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
119	o-Xylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
120	p-Xylene	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
121	Xylene (Total)	Purge and Trap, Gas Chromatographic/ Mass Spectrometric Method <sup>[13,25]</sup>
122	Zinc	1) Digestion, Flame Atomic Absorption Spectrometric Method <sup>[7,15]</sup> 2) Digestion, Inductively Coupled Plasma Method <sup>[7,14]</sup>

## เอกสารอ้างอิง

- กระทรวงอุตสาหกรรม. ประกาศกระทรวงอุตสาหกรรม, พ.ศ. 2548. เรื่อง การกำจัดสิ่งปฏิกูลหรือ  
วัสดุที่ไม่ใช้แล้ว.ราชกิจจานุเบกษา. 25 มกราคม 2549. เล่มที่ 123 ตอนพิเศษ 11ง.
- กระทรวงอุตสาหกรรม. ประกาศกระทรวงอุตสาหกรรม, พ.ศ. 2549. เรื่อง กำหนดค่าปริมาณเขม่า  
ควันที่เจือปนในอากาศที่ระบายออกจากปล่องของหม้อน้ำโรงสีข้าวที่ใช้ถ่านเป็นเชื้อเพลิง.  
ราชกิจจานุเบกษา. 4 ธันวาคม 2549. เล่มที่ 123 ตอนพิเศษ 125ง.
- สมาคมวิศวกรรมสิ่งแวดล้อมแห่งประเทศไทย. คู่มือวิเคราะห์น้ำเสีย. พิมพ์ครั้งที่ 4. กรุงเทพฯ:  
เรือนแก้วการพิมพ์, 2547.
- APHA, AWWA, WEF. Standard Methods for the Examination of Water and  
Wastewater. 23<sup>rd</sup> ed. Washington, DC: APHA, 2017.
- United States Environmental Protection Agency. Standards of Performance for  
New Stationary Sources. 40 CFR 60. Appendix A, 2019.



6. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. SW-846, 1997.
7. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Acid Digestion of Sediments, Sludges, and Soils. SW-846 Method 3050B, 1996.
8. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Alkaline Digestion for Hexavalent Chromium. SW-846 Method 3060A, 1996.
9. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Separatory Funnel Liquid-Liquid Extraction. SW-846 Method 3510C, 1996.
10. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Soxhlet Extraction. SW-846 Method 3540C, 1996.
11. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Ultrasonic Extraction. SW-846 Method 3550C, 2007.
12. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Purge-and-Trap for Aqueous Samples. SW-846 Method 5030C, 2003.
13. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Closed-System Purge-and-Trap And Extraction For Volatile Organics in Soil and Waste Samples. SW-846 Method 5035A, 2002.
14. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Inductively Coupled Plasma-optical Emission Spectrometry. SW-846 Method 6010D, 2018
15. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Flame Atomic Absorption Spectrophotometry. SW-846 Method 7000B, 2007.
16. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Antimony and Arsenic (Atomic Absorption, Borohydride Reduction). SW-846 Method 7062, 1992.
17. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Chromium, Hexavalent (Colorimetric), SW-846 Method 7196A, 1992.
18. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Liquid Waste (Manual Cold-Vapor Technique, SW-846 Method 7470A, 1994.
19. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Solid or Semisolid Waste (Manual Cold-Vapor Technique, SW-846 Method 7471B, 2007.

(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ

20. United States...

20. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Selenium (Atomic Absorption, Borohydride Reduction), SW-846 Method 7742, 1994.
21. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Nonhalogenated Organics Using GC/FID. SW-846 Method 8015D, 2003.
22. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Organochlorine Pesticide by Gas Chromatography. SW-846 Method 8081B, 2007.
23. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Polychlorinated Biphenyls (PCBs) By Gas Chromatography. SW-846 Method 8082A, 2007.
24. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Chlorinated Herbicides By GC Using Methylation or Pentafluorobenzoylation Derivatization. SW-846 Method 8151A, 1996.
25. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Volatile Organic Compounds by Gas Chromatography/ Mass Spectrometry (GC/MS). SW-846 Method 8260D, 2018.
26. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. SemiVolatile Organic Compounds by Gas Chromatography/Mass Spectrometry. SW-846 Method 8270E, 2018.
27. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Total and Amenable Cyanide: Distillation. SW-846 Method 9010C, 2004.
28. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Cyanide Extraction Procedure for Solids and Oils. SW-846 Method 9013A, 2014.
29. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Cyanide in Waters and Extracts Using Titrimetric and Manual Spectrophotometric. SW-846 Method 9014, 2014.
30. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. pH Electrometric Measurement. SW-846 Method 9040C, 2004.
31. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Solid and Waste pH. SW-846 Method 9045D, 2004.



(นางริกาญจน์ ฉัตรสกุลวิไล)

ผู้อำนวยการกลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษ  
และทะเบียนห้องปฏิบัติการ



ภาคผนวก ช

---

ใบรับรองความสามารถห้องปฏิบัติการและขอบข่ายการรับรอง  
ห้องปฏิบัติการทดสอบ ตามมาตรฐาน ISO/IEC 17025  
จากสำนักงานมาตรฐานอุตสาหกรรม



ใบรับรองเลขที่ 20T173/1151

## ใบรับรองห้องปฏิบัติการ

อาศัยอำนาจตามความในพระราชบัญญัติการมาตรฐานแห่งชาติ พ.ศ. ๒๕๕๑

เลขาธิการสำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

ออกใบรับรองฉบับนี้ให้

บริษัท ซีคोट จำกัด

มีห้องปฏิบัติการตั้งอยู่เลขที่

239 ถนนริมคลองประปา แขวงบางซื่อ เขตบางซื่อ กรุงเทพมหานคร

ได้รับการรับรองความสามารถห้องปฏิบัติการทดสอบ

ตามมาตรฐานเลขที่ มอก. 17025-2561 (ISO/IEC 17025 : 2017)

ข้อกำหนดทั่วไปว่าด้วยความสามารถห้องปฏิบัติการทดสอบและสอบเทียบ

หมายเลขการรับรองที่ ทดสอบ ๐๓๙๔

โดยมีสาขาการรับรองตามรายละเอียดแนบท้ายใบรับรอง

ตั้งแต่วันที่ ๙ กันยายน พ.ศ. ๒๕๖๓

ถึง วันที่ ๘ กันยายน พ.ศ. ๒๕๖๖

ออกให้ ณ วันที่ ๒๓ กันยายน ๒๕๖๓

(นายวีระกิตต์ รัตนกิจธนวิทย์)

รองเลขาธิการ ปฏิบัติราชการแทน

เลขาธิการสำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม



กระทรวงอุตสาหกรรม สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

รายละเอียดแนบท้ายใบรับรองห้องปฏิบัติการทดสอบ

ใบรับรองเลขที่ 20T173/1151

ชื่อห้องปฏิบัติการ

ห้องปฏิบัติการทดสอบ บริษัท ซีคोट จำกัด

ที่อยู่

239 ถนนริมคลองประปา แขวงบางซื่อ เขตบางซื่อ กรุงเทพมหานคร

หมายเลขการรับรองที่

ทดสอบ 0394

สถานภาพห้องปฏิบัติการ

☒ ถาวร ☐ นอกสถานที่ ☐ชั่วคราว ☐เคลื่อนที่

สาขาการทดสอบ	รายการทดสอบ	วิธีทดสอบ
สาขาสิ่งแวดล้อม 1. น้ำและน้ำเสีย (water and wastewater)	<ul style="list-style-type: none"> <li>- Arsenic 0.000 5 mg/l to 0.090 0 mg/l</li> <li>- Arsenic 0.05 mg/l to 4.50 mg/l</li> <li>- Barium 0.02 mg/l to 4.50 mg/l</li> <li>- Cadmium 0.01 mg/l to 4.50 mg/l</li> <li>- Chromium 0.01 mg/l to 4.50 mg/l</li> <li>- Copper 0.02 mg/l to 4.50 mg/l</li> <li>- Iron 0.05 mg/l to 9.00 mg/l</li> <li>- Lead 0.03 mg/l to 4.50 mg/l</li> <li>- Manganese 0.01 mg/l to 9.00 mg/l</li> <li>- Nickel 0.01 mg/l to 4.50 mg/l</li> <li>- Zinc 0.02 mg/l to 9.00 mg/l</li> </ul>	<ul style="list-style-type: none"> <li>- Standard Methods for the Examination of Water and Wastewater, APHA, AWWA, WEF, 23<sup>rd</sup> edition, 2017, Part 3030 F and Part 3114 C</li> <li>- Standard Methods for the Examination of Water and Wastewater, APHA, AWWA, WEF, 23<sup>rd</sup> edition, 2017, Part 3030 E and Part 3120 B</li> </ul>

ฉบับที่ 1 ตั้งแต่วันที่ 9 กันยายน 2563

หน้า 1/5

กระทรวงอุตสาหกรรม สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

รายละเอียดแนบท้ายใบรับรองห้องปฏิบัติการทดสอบ

ใบรับรองเลขที่ 20T173/1151

หมายเลขการรับรองที่ ทดสอบ 0394

สถานภาพห้องปฏิบัติการ ☒ ถาวร ☐ นอกสถานที่ ☐ ชั่วคราว ☐ เคลื่อนที่

สาขาการทดสอบ	รายการทดสอบ	วิธีทดสอบ
สาขาสิ่งแวดล้อม		
1. น้ำและน้ำเสีย (ต่อ) (water and wastewater) (cont.)	- COD 100 mg/l to 4 000 mg/l	- Standard Methods for the Examination of Water and Wastewater, APHA, AWWA, WEF, 23 <sup>rd</sup> edition, 2017, Part 5220 D
2. คุณภาพอากาศ (air quality)		
2.1 บริเวณทำงาน (workplace)	- Total dust 0.10 mg/filter to 2.00 mg/filter  - Respirable dust 0.10 mg/filter to 2.00 mg/filter  - Benzene 1.10 µg/tube to 420 µg/tube  - Toluene 1.10 µg/tube to 420 µg/tube  - Total xylenes 2.20 µg/tube to 840 µg/tube • m,p-xylene 1.10 µg/tube to 420 µg/tube • o-xylene 1.10 µg/tube to 420 µg/tube	- NIOSH Manual of Analytical Methods (NMAM), method 0500, 4 <sup>th</sup> edition, 15 <sup>th</sup> August 1994 (Exclude Sampling)  - NIOSH Manual of Analytical Method(NMAM), method 0600, 4 <sup>th</sup> edition, 15 <sup>th</sup> January 1998 (Exclude Sampling)  - NIOSH Manual of Analytical Methods (NMAM), method 1501, 4 <sup>th</sup> edition, 15 <sup>th</sup> March 2003 (Exclude Sampling)

ฉบับที่ 1 ตั้งแต่วันที่ 9 กันยายน 2563

หน้า 2/5

กระทรวงอุตสาหกรรม สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

รายละเอียดแนบท้ายใบรับรองห้องปฏิบัติการทดสอบ

ใบรับรองเลขที่ 20T173/1151

หมายเลขการรับรองที่ ทดสอบ 0394

สถานภาพห้องปฏิบัติการ ☒ ถาวร ☐ นอกสถานที่ ☐ ชั่วคราว ☐ เคลื่อนที่

สาขาการทดสอบ	รายการทดสอบ	วิธีทดสอบ
สาขาสิ่งแวดล้อม		
2. คุณภาพอากาศ (ต่อ) (air quality) (cont.)		
2.2 อากาศในปล่องระบาย อากาศ (stack)	- Sulfur dioxide 1.00 mg/l to 16 000 mg/l (solution)	- US.EPA , Code of Federal Regulations, 40 CFR 60 appendix A, Method 6, July 2019 (Exclude Sampling)
2.3 บรรยากาศทั่วไป (ambient air)	- Hydrogen fluoride 5 µg/sample to 400 µg/sample  - Hydrogen chloride 5 µg/sample to 400 µg/sample  - Volatile organic compounds (VOCs) • Chloroethene 0.05 µg/m <sup>3</sup> to 51.00 µg/m <sup>3</sup> • 1,3 - butadiene 0.04 µg/m <sup>3</sup> to 44.00 µg/m <sup>3</sup> • Bromomethane 0.08 µg/m <sup>3</sup> to 77.00 µg/m <sup>3</sup> • Acrolein 0.05 µg/m <sup>3</sup> to 45.00 µg/m <sup>3</sup> • Acrylonitrile 0.04 µg/m <sup>3</sup> to 43.00 µg/m <sup>3</sup> • Dichloromethane 0.14 µg/m <sup>3</sup> to 69.00 µg/m <sup>3</sup> • Carbon disulfide 0.06 µg/m <sup>3</sup> to 62.00 µg/m <sup>3</sup> • Trichloromethane 0.20 µg/m <sup>3</sup> to 97.00 µg/m <sup>3</sup>	- In-house method : WI-7.2-1-22 based on US.EPA, Code of Federal Regulations, 40 CFR 60 appendix A Method 26, 2019 (Exclude Sampling)  - In-house method :WI-7.2-1-24 based on US.EPA , Compendium Method TO - 15, EPA / 625 / R-96 / 010b, January 1999 (Include sampling)

ฉบับที่ 1 ตั้งแต่วันที่ 9 กันยายน 2563

หน้า 3/5

กระทรวงอุตสาหกรรม สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

รายละเอียดแนบท้ายใบรับรองห้องปฏิบัติการทดสอบ  
ใบรับรองเลขที่ 20T173/1151

หมายเลขการรับรองที่ ทดสอบ 0394  
สถานภาพห้องปฏิบัติการ ☒ ถาวร ☐ นอกสถานที่ ☐ชั่วคราว ☐เคลื่อนที่

สาขาการทดสอบ	รายการทดสอบ	วิธีทดสอบ
<p>สาขาสิ่งแวดล้อม</p> <p>2. คุณภาพอากาศ (ต่อ)</p> <p>(air quality) (cont.)</p> <p>2.3 บรรยากาศทั่วไป (ต่อ)</p> <p>(ambient air) (cont.)</p>	<p>- Volatile organic compounds (VOCs) (cont.)</p> <ul style="list-style-type: none"> <li>• 1,2 - dichloroethane 0.08 <math>\mu\text{g}/\text{m}^3</math> to 80.00 <math>\mu\text{g}/\text{m}^3</math></li> <li>• Benzene 0.06 <math>\mu\text{g}/\text{m}^3</math> to 63.00 <math>\mu\text{g}/\text{m}^3</math></li> <li>• Carbon tetrachloride 0.25 <math>\mu\text{g}/\text{m}^3</math> to 125 <math>\mu\text{g}/\text{m}^3</math></li> <li>• Trichloroethylene 0.21 <math>\mu\text{g}/\text{m}^3</math> to 107 <math>\mu\text{g}/\text{m}^3</math></li> <li>• 1,2 - dichloropropane 0.18 <math>\mu\text{g}/\text{m}^3</math> to 92.00 <math>\mu\text{g}/\text{m}^3</math></li> <li>• Tetrachloroethylene 0.27 <math>\mu\text{g}/\text{m}^3</math> to 135 <math>\mu\text{g}/\text{m}^3</math></li> <li>• 1,2 - dibromoethane 0.31 <math>\mu\text{g}/\text{m}^3</math> to 153 <math>\mu\text{g}/\text{m}^3</math></li> <li>• 1,1,2,2 - tetrachloroethane 0.69 <math>\mu\text{g}/\text{m}^3</math> to 137 <math>\mu\text{g}/\text{m}^3</math></li> </ul>	<p>- In-house method :WI-7.2-1-24 US.EPA , Compendium Method TO - 15, EPA / 625 / R-96 / 010b, January 1999 (Include sampling)</p>

รายละเอียดแนบท้ายใบรับรองห้องปฏิบัติการทดสอบ  
ใบรับรองเลขที่ 20T173/1151

หมายเลขการรับรองที่ ทดสอบ 0394  
สถานภาพห้องปฏิบัติการ ☒ ถาวร ☐ นอกสถานที่ ☐ชั่วคราว ☐เคลื่อนที่

สาขาการทดสอบ	รายการทดสอบ	วิธีทดสอบ
<p>สาขาสิ่งแวดล้อม</p> <p>2. คุณภาพอากาศ (ต่อ)</p> <p>(air quality) (cont.)</p> <p>2.3 บรรยากาศทั่วไป (ต่อ)</p> <p>(ambient air) (cont.)</p>	<p>- Volatile organic compounds (VOCs) (cont.)</p> <ul style="list-style-type: none"> <li>• Benzyl chloride 0.52 <math>\mu\text{g}/\text{m}^3</math> to 103 <math>\mu\text{g}/\text{m}^3</math></li> <li>• 1,4 - dichlorobenzene 0.24 <math>\mu\text{g}/\text{m}^3</math> to 120 <math>\mu\text{g}/\text{m}^3</math></li> </ul>	<p>- In-house method :WI-7.2-1-24 US.EPA , Compendium Method TO - 15, EPA / 625 / R-96 / 010b, January 1999 (Include sampling)</p>

ออกให้ ณ วันที่ 13 กันยายน 2563

(นายวีระศักดิ์ รินเทงตบวิทย์)  
รองเลขาธิการ ปฏิบัติราชการแทน  
เลขาธิการสำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม