


ภาคผนวก ง
ใบรายงานผลการวิเคราะห์คุณภาพน้ำเสียและน้ำทิ้ง



ใบรายงานผลการวิเคราะห์

ชื่อลูกค้า	: การยาสูบแห่งประเทศไทย (ยสท.)	วันที่รับตัวอย่าง	: 19 เมษายน 2567
ที่อยู่	: 184 ถนนพระราม 4 แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110	วันที่วิเคราะห์	: 19-25 เมษายน 2567
ข้อมูลผู้ติดต่อ	: โทรศัพท์ : 0 2251 4440 อีเมล : kamonchanok.trae@gmail.com	วันที่ออกรายงานผล	: 30 เมษายน 2567
สถานที่เก็บตัวอย่าง	: นิคมอุตสาหกรรมโรจนะ จังหวัดพระนครศรีอยุธยา	เลขที่ใบรายงานผล	: 2024-U035823
ชนิดตัวอย่าง	: น้ำเสีย	เลขที่งาน	: 2023-008163
วันที่เก็บ	: 18 เมษายน 2567	หมายเลขปฏิบัติการ	: T24AI090-0001 - T24AI090-0002
เวลาเก็บ	: 1/		
วิธีเก็บ	: จ้วงเก็บ 1 ครั้ง, จ้วงเก็บ 1 ครั้ง และเทคนิคปลอดเชื้อ		
ผู้เก็บตัวอย่าง	: นายอชิตะ แสงจันทร์		
ผู้วิเคราะห์	: นางสาวอักษรินทร์ บุญคง		

ดัชนี	หน่วย	วิธีการวิเคราะห์	ผลการวิเคราะห์		ขีดจำกัดค่าสูงสุดของการวัด
			1 10:40 น. 1/ T24AI090-0001	2 10:50 น. 1/ T24AI090-0002	
ความเป็นกรดและด่าง ^a	-	ELECTROMETRIC METHOD (AT SITE) SM: PART 4500-H ⁺ B AND 1060 B	6.7 (34°C)	7.1 (31°C)	-
บีโอดี ^a	มิลลิกรัมต่อลิตร	MEMBRANE ELECTRODE METHOD (SM: PART 5210 B AND PART 4500-O G)	65.2	< 2.0	2.0
สารแขวนลอย ^c	มิลลิกรัมต่อลิตร	SUSPENDED SOLIDS DRIED AT 103-105 °C (SM: PART 2540 D)	31.1	ตรวจไม่พบ	5.0
ทีเคเอ็น ^c	มิลลิกรัมต่อลิตร	IN-HOUSE METHOD: UAE.TP.WAS.001 (KJELDAHL METHOD); SM: PART 4500-Norg C	64.4	ตรวจไม่พบ	1.5
น้ำมันและไขมัน ^c	มิลลิกรัมต่อลิตร	LIQUID-LIQUID, PARTITION-GRAVIMETRIC METHOD (SM: PART 5520 B)	5	ตรวจไม่พบ	3
MICROBIOLOGY					
แบคทีเรียกลุ่มฟิโคไซยาโนแบคทีเรีย ^b	เอ็มพีเอ็นต่อ 100 มิลลิลิตร	MULTIPLE-TUBE FERMENTATION TECHNIQUE (SM: PART 9221 E)	>160,000	17	1.8
สภาพตัวอย่าง					
สี/ลักษณะของน้ำ			เหลือง/ขุ่น	เหลือง/ใส	
สีของตะกอน			น้ำตาล	น้ำตาล	

^a : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

^b : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ กรมวิทยาศาสตร์บริการ

^c : รายการทดสอบที่ได้รับการทวนสอบโดยระบบคุณภาพของห้องปฏิบัติการ แต่ไม่อยู่ในขอบข่ายที่ได้รับการรับรอง

IN-HOUSE : BASED ON STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

SM : STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

RESULT 1 : น้ำเข้าระบบ อาคาร R01

RESULT 2 : น้ำออกจากระบบ อาคาร R01



(นางปิยะพัชร สุทธรณ์สงข)

ผู้ควบคุมห้องปฏิบัติการ

30 เมษายน 2567



ใบรายงานผลการวิเคราะห์

ชื่อลูกค้า	: การยาสูบแห่งประเทศไทย (ยสท.)	วันที่รับตัวอย่าง	: 19 เมษายน 2567
ที่อยู่	: 184 ถนนพระราม 4 แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110	วันที่วิเคราะห์	: 19-25 เมษายน 2567
ข้อมูลผู้ติดต่อ	: โทรศัพท์ : 0 2251 4440 อีเมล : kamonchanok.trae@gmail.com	วันที่ออกรายงานผล	: 30 เมษายน 2567
สถานที่เก็บตัวอย่าง	: นิคมอุตสาหกรรมโรจนะ จังหวัดพระนครศรีอยุธยา	เลขที่ใบรายงานผล	: 2024-U035826
ชนิดตัวอย่าง	: น้ำเสีย	เลขที่งาน	: 2023-008163
วันที่เก็บ	: 18 เมษายน 2567	หมายเลขปฏิบัติการ	: T24AI090-0003 - T24AI090-0004
เวลาเก็บ	: 1/		
วิธีเก็บ	: จ้างเก็บ 1 ครั้ง, จ้างเก็บ 1 ครั้ง และเทคนิคปลอดเชื้อ		
ผู้เก็บตัวอย่าง	: นายอชิตะ แสงจันทร์		
ผู้วิเคราะห์	: นางสาวอภิชรินทร์ บุญคง		

ดัชนี	หน่วย	วิธีการวิเคราะห์	ผลการวิเคราะห์		ขีดจำกัดต่ำสุดของการวัด
			1 11:10 น. 1/ T24AI090-0003	2 11:20 น. 1/ T24AI090-0004	
ความเป็นกรดและด่าง ^a	-	ELECTROMETRIC METHOD (AT SITE) SM: PART 4500-H ⁺ B AND 1060 B	6.9 (34°C)	6.6 (34°C)	-
บีโอดี ^a	มิลลิกรัมต่อลิตร	MEMBRANE ELECTRODE METHOD (SM: PART 5210 B AND PART 4500-O G)	174	15.6	2.0
สารแขวนลอย ^a	มิลลิกรัมต่อลิตร	SUSPENDED SOLIDS DRIED AT 103-105 °C (SM: PART 2540 D)	239	7.0	5.0
ทีเคเอ็น ^b	มิลลิกรัมต่อลิตร	IN-HOUSE METHOD: UAE.TP.WAS.001 (KJELDAHL METHOD); SM: PART 4500-Norg C	92.5	< LOQ	1.5
น้ำมันและไขมัน ^c	มิลลิกรัมต่อลิตร	LIQUID-LIQUID, PARTITION-GRAVIMETRIC METHOD (SM: PART 5520 B)	9	ตรวจไม่พบ	3
MICROBIOLOGY					
แบคทีเรียกลุ่มฟีคอลโคลิฟอร์ม ^d	เอ็มพีเอ็นต่อ 100 มิลลิลิตร	MULTIPLE-TUBE FERMENTATION TECHNIQUE (SM: PART 9221 E)	>160,000	790	1.8
สภาพตัวอย่าง					
สี/ลักษณะของน้ำ			เหลือง/ขุ่น	เหลือง/ใส	
สีของตะกอน			น้ำตาล	น้ำตาล	

^a : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

^b : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ กรมวิทยาศาสตร์บริการ

^c : รายการทดสอบที่ได้รับการทวนสอบโดยระบบคุณภาพของห้องปฏิบัติการ แต่ไม่อยู่ในขอบข่ายที่ได้รับการรับรอง

IN-HOUSE : BASED ON STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

SM : STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

RESULT 1 : น้ำเข้าระบบ อาคาร R03

RESULT 2 : น้ำออกจากระบบ อาคาร R03

< LOQ : < LIMIT OF QUANTITATION (ทีเคเอ็น ≥ 1.5 และ < 5.0 มิลลิกรัมต่อลิตร)



(นางปิยะพัชร สุทธรณีสว่างษ์)
ผู้ควบคุมห้องปฏิบัติการ

30 เมษายน 2567



ใบรายงานผลการวิเคราะห์

ชื่อลูกค้า : การยาสูบแห่งประเทศไทย (ยสท.)
 ที่อยู่ : 184 ถนนพระราม 4 แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110
 ข้อมูลผู้ติดต่อ : โทรศัพท์ : 0 2251 4440 อีเมล : kamonchanok.trae@gmail.com
 สถานที่เก็บตัวอย่าง : นิคมอุตสาหกรรมโรจนะ จังหวัดพระนครศรีอยุธยา
 ชนิดตัวอย่าง : น้ำเสีย
 วันที่เก็บ : 18 เมษายน 2567
 เวลาเก็บ : 1/
 วิธีเก็บ : จ้วงเก็บ 1 ครั้ง, จ้วงเก็บ 1 ครั้ง และเทคนิคปลอดเชื้อ
 ผู้เก็บตัวอย่าง : นายอชิตะ แสงจันทร์
 ผู้วิเคราะห์ : นางสาวอักษรินทร์ บุญคง
 วันที่รับตัวอย่าง : 19 เมษายน 2567
 วันที่วิเคราะห์ : 19-25 เมษายน 2567
 วันที่ออกรายงานผล : 30 เมษายน 2567
 เลขที่ใบรายงานผล : 2024-U035827
 เลขที่งาน : 2023-008163
 หมายเลขปฏิบัติการ : T24AI090-0005 - T24AI090-0006

ดัชนี	หน่วย	วิธีการวิเคราะห์	ผลการวิเคราะห์		ขีดจำกัดค่าสุด ของการวัด
			1 10:10 น. 1/ T24AI090-0005	2 10:00 น. 1/ T24AI090-0006	
ความเป็นกรดและด่าง ^a	-	ELECTROMETRIC METHOD (AT SITE) SM: PART 4500-H ⁺ B AND 1060 B	6.8 (32°C)	7.1 (34°C)	-
บีโอดี ^a	มิลลิกรัมต่อลิตร	MEMBRANE ELECTRODE METHOD (SM: PART 5210 B AND PART 4500-O G)	482	53.6	2.0
สารแขวนลอย ^a	มิลลิกรัมต่อลิตร	SUSPENDED SOLIDS DRIED AT 103-105 °C (SM: PART 2540 D)	396	17.6	5.0
ทีเคเอ็น ^b	มิลลิกรัมต่อลิตร	IN-HOUSE METHOD: UAE.TP.WAS.001 (KJELDAHL METHOD); SM: PART 4500-Norg C	714	62.5	1.5
น้ำมันและไขมัน ^a	มิลลิกรัมต่อลิตร	LIQUID-LIQUID, PARTITION-GRAVIMETRIC METHOD (SM: PART 5520 B)	113	4	3
MICROBIOLOGY					
แบคทีเรียกลุ่มฟีคอลโคลิฟอร์ม ^c	เอ็มพีเอ็นต่อ 100 มิลลิลิตร	MULTIPLE-TUBE FERMENTATION TECHNIQUE (SM: PART 9221 E)	>160,000	>160,000	1.8
สภาพตัวอย่าง สี/ลักษณะของน้ำ สีของตะกอน			เหลือง/ขุ่น น้ำตาล	เหลือง/ขุ่น น้ำตาล	

^a : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

^b : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ กรมวิทยาศาสตร์บริการ

^c : รายการทดสอบที่ได้รับการทวนสอบโดยระบบคุณภาพของห้องปฏิบัติการ แต่ไม่อยู่ในขอบข่ายที่ได้รับการรับรอง

IN-HOUSE : BASED ON STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

SM : STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

RESULT 1 : น้ำเข้าระบบ อาคาร R04

RESULT 2 : น้ำออกจากระบบ อาคาร R04



(นางปิยะพัชร สุทธรณีสวങ)
ผู้ควบคุมห้องปฏิบัติการ

30 เมษายน 2567



ใบรายงานผลการวิเคราะห์

ชื่อลูกค้า	: การยาสูบแห่งประเทศไทย (ยสท.)	วันที่รับตัวอย่าง	: 19 เมษายน 2567
ที่อยู่	: 184 ถนนพระราม 4 แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110	วันที่วิเคราะห์	: 19-25 เมษายน 2567
ข้อมูลผู้ติดต่อ	: โทรศัพท์ : 0 2251 4440 อีเมล : kamonchanok.trae@gmail.com	วันที่ออกรายงานผล	: 30 เมษายน 2567
สถานที่เก็บตัวอย่าง	: นิคมอุตสาหกรรมโรจนะ จังหวัดพระนครศรีอยุธยา	เลขที่ใบรายงานผล	: 2024-U035828
ชนิดตัวอย่าง	: น้ำเสีย	เลขที่งาน	: 2023-008163
วันที่เก็บ	: 18 เมษายน 2567	หมายเลขปฏิบัติการ	: T24AI090-0007 - T24AI090-0008
เวลาเก็บ	: 1/		
วิธีเก็บ	: จ้วงเก็บ 1 ครั้ง, จ้วงเก็บ 1 ครั้ง และเทคนิคปลอดเชื้อ		
ผู้เก็บตัวอย่าง	: นายอชิตะ แสงจันทร์		
ผู้วิเคราะห์	: นางสาวอักษรินทร์ บุญคง		

ดัชนี	หน่วย	วิธีการวิเคราะห์	ผลการวิเคราะห์		ขีดจำกัดต่ำสุดของการวัด
			1 10:20 น. 1/ T24AI090-0007	2 10:30 น. 1/ T24AI090-0008	
ความเป็นกรดและด่าง ^a	-	ELECTROMETRIC METHOD (AT SITE) SM: PART 4500-H ⁺ B AND 1060 B	6.8 (32°C)	6.8 (34°C)	-
บีโอดี ^a	มิลลิกรัมต่อลิตร	MEMBRANE ELECTRODE METHOD (SM: PART 5210 B AND PART 4500-O G)	160	43.6	2.0
สารแขวนลอย ^a	มิลลิกรัมต่อลิตร	SUSPENDED SOLIDS DRIED AT 103-105 °C (SM: PART 2540 D)	51.0	16.7	5.0
ทีเคเอ็น ^b	มิลลิกรัมต่อลิตร	IN-HOUSE METHOD: UAE.TP.WAS.001 (KJELDAHL METHOD); SM: PART 4500-Norg C	68.6	24.8	1.5
น้ำมันและไขมัน ^c	มิลลิกรัมต่อลิตร	LIQUID-LIQUID, PARTITION-GRAVIMETRIC METHOD (SM: PART 5520 B)	5	ตรวจไม่พบ	3
MICROBIOLOGY					
แบคทีเรียกลุ่มฟีคอลโคลิฟอร์ม ^o	เอ็มพีเอ็นต่อ 100 มิลลิลิตร	MULTIPLE-TUBE FERMENTATION TECHNIQUE (SM: PART 9221 E)	>160,000	>160,000	1.8
สภาพตัวอย่าง สี/ลักษณะของน้ำ สีของตะกอน			เหลือง/ขุ่น น้ำตาล	เหลือง/ขุ่น น้ำตาล	

^a : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

^b : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ กรมวิทยาศาสตร์บริการ

^c : รายการทดสอบที่ได้รับการทวนสอบโดยระบบคุณภาพของห้องปฏิบัติการ แต่ไม่อยู่ในขอบข่ายที่ได้รับการรับรอง

IN-HOUSE : BASED ON STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

SM : STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

RESULT 1 : น้ำเข้าระบบ อาคาร R05

RESULT 2 : น้ำออกจากระบบ อาคาร R05



(นางปิยะพัชร สุทธรณ์สว่างศรี)
ผู้ควบคุมห้องปฏิบัติการ

30 เมษายน 2567



ใบรายงานผลการวิเคราะห์

ชื่อลูกค้า	: การยาสูบแห่งประเทศไทย (ยสท.)	วันที่รับตัวอย่าง	: 19 เมษายน 2567
ที่อยู่	: 184 ถนนพระราม 4 แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110	วันที่วิเคราะห์	: 19-26 เมษายน 2567
ข้อมูลผู้ติดต่อ	: โทรศัพท์ : 0 2251 4440 อีเมล : kamonchanok.trae@gmail.com	วันที่ออกรายงานผล	: 30 เมษายน 2567
สถานที่เก็บตัวอย่าง	: นิคมอุตสาหกรรมโรจนะ จังหวัดพระนครศรีอยุธยา	เลขที่ใบรายงานผล	: 2024-U035829
ชนิดตัวอย่าง	: น้ำทิ้ง	เลขที่งาน	: 2023-008163
วันที่เก็บ	: 18 เมษายน 2567	หมายเลขปฏิบัติการ	: T24AI090-0009
เวลาเก็บ	: 09:50 น.		
วิธีเก็บ	: จ้างเก็บ 1 ครั้ง, จ้างเก็บ 1 ครั้ง และเทคนิคปลอดเชื้อ		
ผู้เก็บตัวอย่าง	: นายอชิตะ แสงจันทร์		
ผู้วิเคราะห์	: นางสาวอักษรินทร์ บุญคง		

ดัชนี	หน่วย	วิธีการวิเคราะห์	ผลการวิเคราะห์	ค่ามาตรฐาน	ขีดจำกัดค่าสุดของการวัด
			นำออกจากระบบ บอรรบม T24AI090-0009		
ความเป็นกรดและด่าง ^a		ELECTROMETRIC METHOD (AT SITE) SM: PART 4500-H ⁺ B AND 1060 B	6.9 (35°C)	5.5-9.0	-
บีโอดี* ^a	มิลลิกรัมต่อลิตร	MEMBRANE ELECTRODE METHOD (SM: PART 5210 B AND PART 4500-O G)	30.9	≤ 500	2.0
สารแขวนลอย ^a	มิลลิกรัมต่อลิตร	SUSPENDED SOLIDS DRIED AT 103-105 °C (SM: PART 2540 D)	14.6	≤ 200	5.0
ทีเคเอ็น ^b	มิลลิกรัมต่อลิตร	IN-HOUSE METHOD: UAE.TP.WAS.001 (KJELDAHL METHOD); SM: PART 4500-Norg C	23.9	≤ 100	1.5
น้ำมันและไขมัน ^c	มิลลิกรัมต่อลิตร	LIQUID-LIQUID, PARTITION-GRAVIMETRIC METHOD (SM: PART 5520 B)	ตรวจไม่พบ	< 10.0	3
MICROBIOLOGY					
แบคทีเรียกลุ่มฟอสฟอรัส ^c	เอ็มพีเอ็นต่อ 100 มิลลิลิตร	MULTIPLE-TUBE FERMENTATION TECHNIQUE (SM: PART 9221 E)	92,000	-	1.8
สภาพตัวอย่าง					
สี/ลักษณะของน้ำ			เหลือง/ขุ่น		
สีของตะกอน			น้ำตาล		

^a : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ สำนักงานมาตรฐานผลิตภัณฑ์อุตสาหกรรม

^b : อยู่ในขอบข่ายที่ได้รับการรับรอง ISO/IEC 17025 จากหน่วยรับรองระดับประเทศ กรมวิทยาศาสตร์บริการ

^c : รายการทดสอบที่ได้รับการทวนสอบโดยระบบคุณภาพของห้องปฏิบัติการ แต่ไม่อยู่ในขอบข่ายที่ได้รับการรับรอง

IN-HOUSE : BASED ON STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

SM : STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

มาตรฐาน : ประกาศ ฉบับที่ 1/2559 เรื่องการปล่อยน้ำเสียของโรงงานภายในสวนอุตสาหกรรมโรจนะ (อยุธยา) ลงวันที่ 31 สิงหาคม พ.ศ. 2559



(นางนียะพัชร สุทธรณีสว่างษ์)
ผู้ควบคุมห้องปฏิบัติการ

30 เมษายน 2567



ใบรายงานผลการวิเคราะห์

ชื่อลูกค้า	: การยาสูบแห่งประเทศไทย (ยสท.)	วันที่รับตัวอย่าง	: 19 เมษายน 2567
ที่อยู่	: 184 ถนนพระราม 4 แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110	วันที่วิเคราะห์	: 19-26 เมษายน 2567
ข้อมูลผู้ติดต่อ	: โทรศัพท์ : 0 2251 4440 อีเมล : kamonchanok.trae@gmail.com	วันที่ออกรายงานผล	: 30 เมษายน 2567
สถานที่เก็บตัวอย่าง	: -	เลขที่ใบรายงานผล	: 2024-U036200
ชนิดตัวอย่าง	: BLANK (น้ำเสีย)	เลขที่งาน	: 2023-008163
วันที่เก็บ	: -	หมายเลขปฏิบัติการ	: 2024-FB0374, 2024-TB0363
เวลาเก็บ	: -		
วิธีเก็บ	: -		
ผู้เก็บตัวอย่าง	: -		
ผู้วิเคราะห์	: นางสาวอักษรินทร์ บุญคง		

ดัชนี	หน่วย	วิธีการวิเคราะห์	ผลการวิเคราะห์		ขีดจำกัดค่าสุดของการวัด
			1 2024-FB0374	2 2024-TB0363	
บีโอดี	มิลลิกรัมต่อลิตร	MEMBRANE ELECTRODE METHOD (SM: PART 5210 B AND PART 4500-O G)	< 2.0	< 2.0	2.0
สารแขวนลอย	มิลลิกรัมต่อลิตร	SUSPENDED SOLIDS DRIED AT 103-105 °C (SM: PART 2540 D)	ตรวจไม่พบ	ตรวจไม่พบ	5.0
ทีเคเอ็น	มิลลิกรัมต่อลิตร	IN-HOUSE METHOD: UAE.TP.WAS.001 (KJELDAHL METHOD); SM: PART 4500-Norg C	ตรวจไม่พบ	ตรวจไม่พบ	1.5
น้ำมันและไขมัน	มิลลิกรัมต่อลิตร	LIQUID-LIQUID, PARTITION-GRAVIMETRIC METHOD (SM: PART 5520 B)	ตรวจไม่พบ	ตรวจไม่พบ	3
MICROBIOLOGY					
แบคทีเรียกลุ่มฟิคอลโคลิฟอร์ม	เอ็มพีเอ็นต่อ 100 มิลลิลิตร	MULTIPLE-TUBE FERMENTATION TECHNIQUE (SM: PART 9221 E)	< 1.8	< 1.8	1.8
สภาพตัวอย่าง สี/ลักษณะของน้ำ สีของตะกอน			ไม่มีสี/ใส -	ไม่มีสี/ใส -	

IN-HOUSE : BASED ON STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

SM : STANDARD METHODS FOR THE EXAMINATION OF WATER AND WASTEWATER, APHA, AWWA, WEF, 23rd EDITION, 2017.

RESULT 1 : FIELD BLANK

RESULT 2 : TRIP BLANK



(นางปิยะพัชร สุทธรณีสว่างษ์)
ผู้ควบคุมห้องปฏิบัติการ

30 เมษายน 2567



ภาคผนวก จ
เอกสารสอบเทียบเครื่องมือวิเคราะห์



List of Instruments Certification for Water Quality Analysis

No.	Instrument/Equipment	Parameter	Manufacturer	Model/Serial No.	Calibrator	Certification No.	Date of Calibration	Due date of Calibration	Remark
Water									
1	pH Meter	pH	Horiba	LAQUA-PH210 HA9M0046	Technology Promotion Association (Thailand-Japan)	24CH40	10 Jan 24	9 Jan 25	-



TECHNOLOGY PROMOTION ASSOCIATION (THAILAND-JAPAN)
CORPORATE SERVICES 3: EQUIPMENT CALIBRATION AND TESTING SERVICES
534/4 PATTANAKARN ROAD SOI 18, SUANLIANG, SIYANLIANG BANGKOK 10250
TEL: 0-2717-3000-29 FAX: 0-2716-9484



Cert.No.: 24CH40
Page.: 1 of 3

Certificate of Calibration

Equipment : pH Meter
Manufacturer : Horiba
Model : LAQUA-PH210
Serial No. : HA9M0046
ID No. : UAE.EFM.001/2563(EFM,pH.01/63)
Condition As-Received: Used Item
Received Date : 09 January 2024
Calibration Date : 10 January 2024
Reference : 2401-0219WSC-3
Submitted by : United Analyst and Engineering Consultant Co.,Ltd.
3 Sol Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong, Bangkok 10260
Ambient Temperature : (25 ± 2.5) °C
Relative Humidity : (50 ± 15) %
Calibration Procedure : In - house method :
- CP-CH5 by direct measurement with standard
voltage calibrator and direct measurement with
certified reference material (CRM)
- CP-CH5 by comparison with standard thermometer

Calibrated by : Warakorn Lemgagrakul

Approved by : 
Approved Signatory

(✓) Seithip Meangmai
() Warakorn Lemgagrakul
() Ponpan Palplim

Issue Date : 15 January 2024

The Uncertainties are for a confidence probability of approximately 95 %

This certificate may not be reproduced other than in full, except with the prior written
Approval of the Head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม
A 0062456



Cert.No.: 24CH40
Page.: 2 of 3

Condition of this calibration result

1. Reference Standard Instrument :-

Instrument	Serial No.	ID No.	Cert. No.	Due Date
1) Document Process Calibrator	54030348	130RC118	23E2802	27 Aug 2024
2) Ref. Standard Thermometer	4862054	110RC044	23I908	26 July 2024

This certification is traceable to the International System of Unit maintained through:-
- Technology Promotion Association (Thailand-Japan)

2. Certified Reference Materials : The measurement results are traceable to SI through CPA chem Ltd.,
ANSI-ASQ National Accreditation Board, Accredited No. AR-1835

Buffer Solution	Manufacturer	Lot No.	Exp. date
pH 4.008	CPA chem	940102	27 Nov 2025
pH 6.998	CPA chem	931959	01 Oct 2024
pH 9.997	CPA chem	940106	02 Nov 2024

3. This certificate is valid only to the item calibrated on date and place of calibration.

Calibration Results

Function : mV Measurement

Performing standard curve by Fluke at pH (4,7)(7,10)

Unit Under Calibration	Nominal Value	Standard Voltage Input	Actual Reading		Uncertainty of Measurement (±mV)	Coverage factor k
	pH	mV	mV	pH		
pH Meter S/N.: HA9M0046	4.00	-177.48	177.5	4.01	0.058	2.00
	7.00	0.00	0.2	7.00	0.058	2.00
	10.00	-177.48	-177.0	10.01	0.058	2.00


เอกสารไม่ควบคุม
a 1197729



Cert.No.: 24CH40
Page.: 3 of 3

Calibration Results

Function : pH Measurement

Performing three buffers standard curve by using buffer nominal pH (4,7)(7,10)

Unit Under Calibration	Standard pH Buffer Solution	Actual pH Reading	Actual mV Reading (mV)	Uncertainty of pH measurement (±)	Coverage factor k
pH Electrode S/N.: -	4.008	4.01	171.9	0.0079	2.00
	6.986	6.99	-2.2	0.0093	2.00
	6.986	6.99	-3.6	0.0093	2.00
	9.997	10.01	-171.0	0.011	2.07

Function : Temperature Measurement

(*) Without adjustment

This equipment was connected with Temperature Probe;

- Model : -
- Serial No. : -
Dimension of probe;
- Length : 103 mm
- Diameter : 16 mm
- Immersion Depth : 90 mm

Calibration Point (°C)	Standard Temperature (°C)	UUC* Reading (°C)	Error (°C)	Uncertainty of measurement (± °C)	Coverage factor k
25.0	25.002	25.0	-0.002	0.13	2.00
30.0	30.002	30.0	-0.002	0.13	2.00
35.0	35.003	35.0	-0.003	0.13	2.00

Remark : - UUC* = Unit Under Calibration

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k , providing a level of confidence of approximately 95 %.

-o0o-


เอกสารไม่ควบคุม
a 1197724

บัญชีรายการเครื่องมือหลักของห้องปฏิบัติการ สำหรับวิเคราะห์คุณภาพสิ่งแวดล้อม

No.	Instrument/Equipment	Parameter	Manufacturer	Model/Serial No.	Calibrator	Certification No.	Date of Calibration	Due date of Calibration *	Remark
เครื่องมือหลักวิเคราะห์คุณภาพน้ำเสีย									
1	pH Meter	pH	Mettler-Toledo	Seven Easy 520 / 1231155210	National Food Institute, Ministry of Industry, Thailand	2401718-001-01	11 Mar 24	10 Mar 25	-
2	Analytical Balance (Readability 0.01 mg)	Suspended Solids (SS)	Mettler-Toledo	XSR205DU / C210685394	National Food Institute, Ministry of Industry, Thailand	2402283-002-01	2 Apr 24	1 Apr 25	-
3	Hot Air Oven		Memmert	UF55 / B212 0411	Technology Promotion Association (Thailand-Japan)	24TM589	1 Apr 24	31 Mar 25	-
4	Analytical Balance (Readability 0.1 mg)	Fat, Oil and Grease	Mettler-Toledo	XSR204 / C117635043	National Food Institute, Ministry of Industry, Thailand	2302827-001-01	10 May 23	8 May 24	-
5	BOD Incubator	BOD	Arco	UC4-1320 / (UAE.WAO.015/2561)	Technology Promotion Association (Thailand-Japan)	24TM303	10 Feb 24	9 Feb 25	-
6	BOD Incubator		Arco	UR-1320 / (UAE.WAO.006/2553)	Technology Promotion Association (Thailand-Japan)	24TM588	1 Apr 24	31 Mar 25	-
7	Digester Unit	TKN	FOSS TECATOR	DT2520 / 91794469	FOSS South East Asia	9809	8 Feb 24	7 Feb 25	-
8	Digester Unit		Velp	DKL20 / 213517	National Food Institute, Ministry of Industry, Thailand	2304055-001-01	28 Aug 23	27 Aug 24	
9	Incubator	Fecal Coliform Bacteria	Memmert	IPP 260 / V616.0066	Technology Promotion Association (Thailand-Japan)	24TM650	2 Apr 24	1 Apr 25	-
10	Water Bath		Memmert	WNE 14 / L416.0606	Technology Promotion Association (Thailand-Japan)	24TM29	10 Feb 24	8 Feb 25	-

บัญชีรายการเครื่องมือหลักของห้องปฏิบัติการ สำหรับวิเคราะห์คุณภาพสิ่งแวดล้อม

No.	Instrument/Equipment	Parameter	Manufacturer	Model/Serial No.	Calibrator	Certification No.	Date of Calibration	Due date of Calibration*	Remark
เครื่องมือหลักวิเคราะห์คุณภาพน้ำเสีย									
11	Water Bath		Memmert	WNE 14 / L416.0606	Technology Promotion Association (Thailand-Japan)	24TM29	10 Feb 24	8 Feb 25	-
12	Auto Clave		ALP	CL-40L / 808763	National Food Institute, Ministry of Industry, Thailand	2402281-001-01	2 Apr 24	1 Apr 25	-
13	Refrigerator		Sanden	YPM11P / YPM11P-150801805	Technology Promotion Association (Thailand-Japan)	23TM1077	10 Jul 23	9 Jul 24	-
14	Analytical Balance		OHAUS	PX623 / C236754745	DKSH (Thailand) Ltd.	C01234158	7 Dec 23	6 Dec 24	-

Due Date of Calibration* : Based on the annual calibration plan. At least 1 time per year.

Calibration Certificate

Certificate No.: 2401718-001-01
Client name: UNITED ANALYST AND ENGINEERING CONSULTANT CO.,LTD.
Address: 3 Soi Udomsuk 41, Sukhumvit Road,
Bangchack, Prakhong, Bangkok 10260

Page 1 of 5

Equipment: pH Meter
Manufacturer: METTLER TOLEDO
Model: SevenEasy pH
Serial No.: 1231155210
ID No.: UAE.WAT.0102553
Order No.: 2401718
Operation No.: 2401718-001
Date of Receipt: 27 February 2024
Date of Calibration: 11 March 2024

Calibrated by Mr.Manas Sombek Specialist
Approved by (Mr.Pheraphat Tuanjit)
Manager, Division of Calibration Laboratory
Date of Issue: 12 March 2024
Responsible for the Technical Management Team

The uncertainties are for a confidence probability of approximately 95%.

This Certificate is issued in accordance with the conditions of accreditation granted by the Thai Laboratory Accreditation Scheme which has assessed the measurement capability of the laboratory and its responsibility to recognize national standards and to the units of measurement realized at the corresponding national standards laboratory. This certificate may not be reproduced other than in full except with the prior written approval of the National Food Institute.

F-CS-009 Revision: 01 Date: 20-04-65



Calibration Report

Certificate No.: 2401718-001-01
Equipment: pH Meter
Resolution: 0.01 pH
Manufacturer: METTLER TOLEDO
Model: SevenEasy pH
Serial No.: 1231155210
Type: Bench top
ID No.: UAE.WAT.0102553

Page 2 of 5

Date of Calibration: 11 March 2024
Location: Chemical Calibration Laboratory, National Food Institute
Environment Condition: Ambient Temperature: (23.4 ± 1.5) °C Relative Humidity: (51 ± 3) %
Condition of Equipment: Good Condition
Condition of this Results of Calibration

1. Calibration Method: W-CC-002 : In house method based on direct measurement by using standard voltage calibrator and certified reference material (CRM)
2. Reference Standards / Certified Reference Material

Instrument	Serial / ID No.	Manufacturer	Certificate No.	Due Date
2.1 DC Voltage Calibrator	2799007	Fluke	23E2033	14 June 2024
2.2 Digital Thermometer	2799007	Fluke	CC 66037C-01	30 October 2024
2.3 Thermo-Hypo Meter	NF16TH D1473	tesco	CC 660333-01	3 April 2024

Certified Reference Material	Lot No.	Manufacturer	Ref No.	Expiry Date
2.4 pH buffer 4.006 (Primary pH buffer Solution)	888842	CPAchem	PH216 L5	13 April 2025
2.5 pH buffer 6.805 (Primary pH buffer Solution)	888843	CPAchem	PH217 L5	13 April 2025
2.6 pH buffer 10.01 (Primary pH buffer Solution)	888844	CPAchem	PH220 L5	13 April 2024
2.7 pH buffer 7.00 (Standard pH buffer Solution)	C03109	HACH LANGE GmbH	S11M004	16 October 2025

3. This certificate is traceable to The International System of Unit (SI Unit)
3.1 Instruments No.2.1 through NSC-TIS-TIS 17025 Laboratory Accreditation of Calibration No.0008
3.2 Instruments No.2.2 and 2.3 through NSC-TIS-TIS 17025 Laboratory Accreditation of Calibration No.0081
3.3 Certified Reference Material No.2.4 to 2.6 traceable to Primary measurement method: Hamed cell using calibrated thermometer, bathometer, and nanovoltmeter. The Standard Solution preparation and certified by CPAchem Ltd is accredited to ISO 17034 and ISO/IEC 17025
3.4 Certified Reference Material No.2.7 traceable to PTB Certificate No. PTB-FH04-56309094/23 and Certificate No. PTB-FH08-65530320/22 (PTB: Physikalisch-Technische Bundesanstalt, Braunschweig, Germany)

4. This certificate was certified only for the instrument we calibrated.

5. This result of calibration was found accurate as shown on date and place of calibration only.

F-CS-012 Revision: 01 Date: 20-04-65

Handwritten signature

Calibration Report

Certificate No.: 2401718-001-01
Equipment: pH Meter
Resolution: 0.01 pH
Manufacturer: METTLER TOLEDO
Model: SevenEasy pH
Serial No.: 1231155210
Type: Bench top
ID No.: UAE.WAT.0102553

Date of Calibration: 11 March 2024
Page 3 of 5

Calibration Results:

1. Calibration of pH Meter [Manual Temperature Compensation at 25 °C]
(offset value before adjust: -0.4 mV)

Nominal pH	DC Voltage Standard (mV)	Average Indicator Reading		Uncertainty (±mV)	Coverage Factor (k)
		mV	pH		
0	414.121	-4.4	9.09	0.58	2.00
2	235.814	286	2.00	0.56	2.00
4	177.494	176	4.00	0.56	2.00
6	59.160	59	6.00	0.58	2.00
7	3.601	0	7.00	0.58	2.00
8	-59.159	-59	8.00	0.58	2.00
10	-177.461	-177	10.00	0.58	2.00
12	-295.811	-295	12.00	0.58	2.00
14	-414.118	-414	14.00	0.58	2.00

2. Calibration of pH Meter with Electrode [Manual Temperature Compensation at 25 °C]

Equipment: pH Electrode Type: Combined Electrode
Manufacturer: METTLER TOLEDO Model: InLab Solics
Serial No.: 3035791 ID No.: N/A
Performance of Electrode system (Three-Point Calibration at pH 4, 7 and 10)

Certified Value @25 °C (pH)	Average Indicator Reading		Relative Slope (%)	Uncertainty (± pH)	Coverage Factor (k)
	pH	mV			
4.003	4.01	188	-	0.0071	2.00
7.001	7.00	13	96.9	0.0086	2.00
10.010	10.01	-159	97.2	0.0085	2.00
6.865	6.87	21	-	0.0074	2.00

F-CS-012 Revision: 01 Date: 20-04-65



Calibration Report

Certificate No.: 2401718-001-01
Equipment: Digital Thermometer with RTD (pH Meter)
Resolution: 0.1 °C
Model: SevenEasy pH
Serial No.: 1231155210
ID No.: UAE.WAT.0102553
Manufacturer: METTLER TOLEDO

Date of Calibration: 11 March 2024
Page 4 of 5

Location: Chemical Calibration Laboratory, National Food Institute
Environment Condition: Ambient Temperature: 23 °C ± 1 °C
Relative Humidity: 51 % ± 2 %

Condition of this results of Calibration:

- Calibration Method : - In house method: W-T-025 by comparison with standard thermometer.
- The Calibration is determined by comparing with a known temperature from a standard resistance thermometer.
- The temperature scale in use at this laboratory is the International Temperature scale of 1990 (ITS-90).

2. Reference Standard Instrument:

Instrument	Model	Serial No.	Certificate No.	Due Date	Through
HANDHELD THERMOMETER	1523	2118154	PSL-T 057769	06-Jun-24	TISTR
Platinum Resistance Thermometer (PRT)	5527A	877332			

Support Equipment : - Low Temperature Bath (ISOCAL-6), Model: Europa-6 Plus Basic, S/N: 3415822

- This certificate is traceable to International System of Units (SI Unit).
- This certificate was certified only for the instrument we calibrated.
- This result of calibration was found accurate as shown on date and place of calibration only.
- Condition of Calibrated item : Good
- Result of Calibration : ☒ Without adjustment ☐ After adjustment

F-CS-012 Revision: 01 Date: 20-04-65

Handwritten signature



Calibration Report

Certificate No.: 2401718-001-01

Equipment: Digital Thermometer with RTD (pH Meter)

Resolution: 0.1 °C Model: SevenEasy pH

Serial No.: 1231155210 ID No.: UAE-WAT 010/2563

Manufacturer: METTLER TOLEDO

Date of Calibration: 11 March 2024

Page 5 of 5

Calibration point: 15.0, 25.0 and 35.0 °C

Calibration result:

The probe was immersed in liquid bath or dry bath to a minimum depth of 100 mm.
Description of probe, model: N/A SN: N/A
Dimension of probe: Diameter 4 mm, Length 120 mm.
Sheath material: Stainless Steel

UUC Reading (°C)	Standard Temperature (°C)	Correction Value (°C)	Uncertainty ± (°C)
15.1	14.998	0.1	0.099
25.1	24.998	0.1	0.099
35.1	34.997	0.1	0.099

Note:

UUC: Unit Under Calibration

The report uncertainty of measurement was based on standard uncertainty multiplied by coverage factor k=2, providing a level of confidence of approximately 95%.

End

FCS-012 Revision: 01 Date: 20-04-65



Calibration Certificate

Certificate No.: 2402283-002-01

Client name: UNITED ANALYST AND ENGINEERING CONSULTANT CO., LTD.

Address: 3 SOI UDOMSUK 41, SUKHUMVIT ROAD,
Bangchack, Prakhonong, Bangkok 10260

Page 1 of 4

Equipment: Electronic Balance

Manufacturer: METTLER TOLEDO

Model: XSR205DU

Serial No.: C210685394

ID No.: UAE-WAO.010/2565

Order No.: 2402283

Operation No.: 2402283-002

Date of Receipt: 2 April 2024

Date of Calibration: 2 April 2024

Calibrated by: Mr. Jerawut Prapawattipong
Scientist

Approved by: (Mr. Pheraphat Tuanjit)
Manager, Division of Calibration Laboratory

Date of Issue: 9 April 2024

Responsible for the Technical Management Team

The uncertainties are for a confidence probability of approximately 95%

This Certificate is issued in accordance with the conditions of accreditation granted by the Thai Laboratory Accreditation Scheme which has assessed the measurement capability of the laboratory and its traceability to recognized national standards and to the units of measurement realized at the corresponding national standards laboratory. This certificate may not be reproduced other than in full, except with the prior written approval of the National Food Institute.

FCS-009 Revision: 01 Date: 20-04-65



Calibration Report

Certificate No.: 2402283-002-01

Equipment: Electronic Balance Manufacturer: METTLER TOLEDO

Model: XSR205DU Resolution: 0.0001 g / 0.0001 g

Serial No.: C210685394 ID No.: UAE-WAO 010/2565

Capacity: 220 g

Date of Calibration: 2 April 2024

Page 2 of 4

Environment Condition: Ambient Temperature: 24.5 ± 0.5 °C Relative Humidity: 47.5 ± 2.5 %

Place of Calibration: Laboratory, UNITED ANALYST AND ENGINEERING CONSULTANT CO., LTD.

Condition of Equipment: Good Condition

Condition of This Results of Calibration:

1. Calibration Method: NFI Method WMA-031 In-House Method based on UKAS Lab 14: 2015

2. Reference Standards:

Reference Standard Model Serial No. Calibrated By Certificate No. Due Date

Standard Weight Class E2 1mg to 200g 8505587572 TCS MC3040325 8 April 2021

Instrument Model Serial No. Calibrated By Certificate No. Due Date

Thermo-hygrometer 608-H1 NFI BTH 016/23 Quality Return QR24-0343 9 February 2025

3. This certificate is traceable to SI UNIT.

4. This certificate was certified only for the instrument we calibrated.

5. This result of calibration was found accurate as shown on data and place of calibration only.

Calibration Results:

1. Repeatability of Reading:

Nominal Value (g)	Standard Deviation of Reading (g)
40	0.0000942
80	0.0000532
100	0.000048
200	0.000048

2. Off-Center Error:

A mass of 100 g was placed and moved to various position on pan.

The balance reading obtained is given in the table.

1	2	3	4	5	6	(Maximum Difference)
(g)	(g)	(g)	(g)	(g)	(g)	(g)
100.0000	100.0001	99.9999	99.9999	100.0001	100.0000	0.0001

FCS-012 Revision: 01 Date: 20-04-65



Calibration Report

Certificate No.: 2402283-002-01

Equipment: Electronic Balance Manufacturer: METTLER TOLEDO

Model: XSR205DU Resolution: 0.0001 g / 0.0001 g

Serial No.: C210685394 ID No.: UAE-WAO 010/2565

Capacity: 220 g

Date of Calibration: 2 April 2024

Page 3 of 4

Calibration Results: (Continued)

Calibration Range: 0 - 80 g

Calibration Adjustment: Internal Calibration

3. Departure from Nominal Value: (Range: 0 - 80 g; Resolution: 0.0001 g)

Nominal Value	Standard Value	Average Reading	Correction	Uncertainty	Coverage Factor
Unload	0.00000	0.00000	0.00000	0.0000000	2.00
0.001	0.001003	0.00101	-0.00001	0.0000069	2.00
0.005	0.005003	0.005009	0.00000	0.0000092	2.00
0.01	0.010003	0.010009	0.00000	0.0000089	2.00
0.05	0.049995	0.050003	0.00000	0.0000096	2.00
0.1	0.100011	0.100009	0.00001	0.000011	2.00
0.5	0.500016	0.500001	0.00001	0.000014	2.00
1	1.000003	1.000002	-0.00002	0.000016	2.00
2	2.000023	2.000001	0.00001	0.000017	2.00
5	5.000017	5.000002	0.00000	0.000020	2.00
10	10.000009	10.000000	0.00001	0.000026	2.00
20	20.000021	20.000039	0.00003	0.000037	2.00
30	30.000049	30.000011	0.00003	0.000050	2.00
50	50.000023	50.000002	0.00001	0.000058	2.00
80	80.000068	80.000002	0.00003	0.000111	2.00

FCS-012 Revision: 01 Date: 20-04-65





มูลนิธิส่งเสริมพัฒนาอุตสาหกรรม
อาหารอุตสาหกรรม
Foundation for Industrial Development National Food Institute
Food Industrial Laboratory Service Center



Calibration Report

Certificate No.: 2402283-002-01
Equipment: Electronic Balance
Manufacturer: METTLER TOLEDO
Model: XSR205DU
Resolution: 0.0001 g / 0.0001 g
Serial No.: C210685394
ID No.: UAE.WAO.010/2556
Capacity: 220 g

Date of Calibration: 2 April 2024 Page 4 of 4

Calibration Results: (Continued)

Calibration Range: 81 - 200 g

Calibration Adjustment: Internal Calibration

3. Departure from Nominal Value: (Range: 81 - 200 g ; Resolution: 0.0001 g)

Nominal Value	Standard Value	Average Reading	Correction	Uncertainty	Coverage Factor
90	90.00010	90.0001	0.0000	0.00015	2.00
100	100.00005	100.0001	0.0000	0.00015	2.00
110	110.00007	110.0001	0.0000	0.00016	2.00
120	120.00009	120.0000	0.0001	0.00017	2.00
130	130.00010	130.0000	0.0001	0.00019	2.00
140	140.00014	140.0000	0.0001	0.00020	2.00
150	150.00009	150.0001	0.0000	0.00020	2.00
160	160.00010	160.0001	0.0000	0.00022	2.00
170	170.00012	170.0001	0.0000	0.00023	2.00
200	200.00016	200.0002	0.0000	0.00029	2.00

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k , providing a level of confidence of approximately 95 %.

End

FCS-012 Revision: 01 Date: 20-04-65



TECHNOLOGY PROMOTION ASSOCIATION (THAILAND-JAPAN)
CORPORATE SERVICES 3: EQUIPMENT CALIBRATION AND TESTING SERVICES
5344 PATTANAKARN ROAD SOI 15, SUANLUANG, SUANLUANG BANGKOK 10350
TEL: 0-2717-3000-29 FAX: 0-2719-9484



Certificate of Calibration

Cert. No.: 24TM589
Page : 1 of 3

Equipment : Hot Air Oven
Manufacturer : Memmert
Model : UF 55
Serial No. : B212.0411
ID No. : UAE.WAO.006/2556
Submitted by : United Analyst and Engineering Consultant Co.,Ltd.
3 Soi Udomauk 41, Sukhumvit Road,
Bangchak, Phraekhanong,
Bangkok 10260
Location : Lab Floor 2
Received Order : 01 April 2024
Calibration Date : 01 - 02 April 2024
Ambient Temperature : (26 ± 1) °C
Relative Humidity : (50 ± 3) %
Calibrated by : Krieda Malee
Approved by :
() Ponpen Paipim
(✓) Suwit Imjai
() Kunchit Promprat

Issue Date : 5 April 2024

The Uncertainties are for a confidence probability of approximately 95 %

This certificate may not be reproduced other than in full, except with the prior written
Approval of the Head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม
A 0065055



Equipment : Hot Air Oven
Condition As-Received : Used Item
Reference : 2404-0004OC-3
Certificate No.: 24TM589
Page : 2 of 3

Procedure Used :-

Calibration were conducted using calibration procedure CP-OT02 based on TLAS G-20 according to direct measurement method with Data Acquisition which connected with Resistance Temperature Detector (RTD) and Thermocouple Type T.

The temperature scale used was based on ITS-90.

Condition of this result of calibration

1. Reference standard instrument:

Instrument	Serial No.	Cert. No.	Traceable	Due Date
1) Data Acquisition	MY57013711	23LM115	TPA	11 Jul 2024

2. This certificate is valid only to the item calibrated on date and place of calibration.

3. This certification is traceable to the International System of Unit.

Remark : TPA : Technology Promotion Association (Thailand - Japan)


Result of Calibration :- (*) Without Adjustment

Function of UUC* : Temperature Source

Fresh air setting : Close

Environment during calibration		
	Beginning	Finished
Temp. (°C)	27	26
REL.Humid. (%)	47	48
AC Supply (Volt)	221	220

Ref. Std. ID No.: @ Calibration Point		
Position :	(120 to 180) °C	(104) °C
1	21-18TC-01	22-18RTD-2/1
2	21-18TC-02	18RTD-2/2
3	21-18TC-03	18RTD-2/3
4	21-18TC-04	18RTD-2/4
5	21-18TC-05	18RTD-2/5
6	21-18TC-06	18RTD-2/6
7	21-18TC-07	18RTD-2/7
8	21-18TC-08	18RTD-2/8
9 (ref.)	21-18TC-09	18RTD-2/9



Probe Installation Details : Dimension of Chamber :
a = 5.0 cm D = 0.50 m
b = 5.0 cm W = 0.80 m
c = 5.0 cm H = 0.75 m
Capacity = 0.30 m³

เอกสารไม่ควบคุม
a 1209739



Equipment : Hot Air Oven
Condition As-Received : Used Item
Reference : 2404-0004OC-3
Certificate No.: 24TM589
Page : 3 of 3
Result of Calibration :- (*) Without Adjustment
Function of UUC* : Temperature Source
Fresh air setting : Close

Calibration Point (°C)	UUC* Setting (°C)	UUC* Reading (°C)	Temperature stability (± °C)	Temperature uniformity (°C)	Overall Variation (°C)	Coverage Factor k
104.0	104.0	104.0	0.032	0.47	0.84	2
120.0	120.0	120.0	0.12	0.72	1.3	2
180.0	180.0	180.0	0.13	1.2	1.5	2

Calibration Point (°C)	Measured Temperature (°C)									Uncertainty (± °C)
	1	2	3	4	5	6	7	8	9 (ref.)	
104.0	104.484	103.847	104.226	104.232	104.106	103.691	104.275	104.127	104.013	0.42
120.0	120.486	120.089	120.635	120.598	119.531	119.644	120.364	120.144	120.156	1.1
180.0	180.574	178.769	180.285	180.670	179.594	179.780	180.287	178.951	179.602	1.1

Average* : The average of 30 values in each position.

Temperature stability : One-half of the greatest maximum difference of measured temperature at any one sensor.

Temperature uniformity : The maximum difference of measured temperatures at any sensors and the measured temperature at the reference location which are observed at the same time or at as close an observation time as possible to determine the temperature pattern or homogeneity within the chamber under steady-state conditions.

Overall Variation : The Difference of the maximum and minimum measured temperatures throughout observation.

UUC* : Unit Under Calibration

Note : The reported uncertainty of measurement was included stability and excluded uniformity .

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k , providing a level of confidence of approximately 95 %.

-000-

เอกสารไม่ควบคุม
a 1209738

Calibration Certificate

Certificate No.: 2302827-001-01
Client name: UNITED ANALYST AND ENGINEERING CONSULTANT CO., LTD.
Address: 3 Soi Udomsuk 41, Sukhumvit Road,
Bangchak, Phra Khanong, Bangkok 10260

Page 3 of 4

Equipment: Electronic Balance

Manufacturer: METTLER TOLEDO

Model: XSR204

Serial No.: C117635043

ID No.: UAE.WAS.012/2564

Order No.: 2302827

Operation No.: 2302827-001

Date of Receipt: 10 May 2023

Date of Calibration: 10 May 2023

Calibrated by Mr. Manas Somek
Specialist

Approved by
(Mr. Phraphat Tuntit)
Manager, Division of Calibration Laboratory
Responsible for the Technical Management Team

The uncertainties are for a confidence probability of approximately 95%

This Certificate is issued in accordance with the conditions of accreditation granted by the Thai Laboratory Accreditation Scheme which has assessed the measurement capability of the laboratory and its traceability to recognized national standards and to the units of measurement realized at the corresponding national standards laboratory. This certificate may not be reproduced other than in full, except with the prior written approval of the National Food Institute.

F-CS-009 Revision: 01 Date: 20-04-65

Calibration Report

Certificate No.: 2302827-001-01
Equipment: Electronic Balance
Model: XSR204
Serial No.: C117635043
Capacity: 220 g
Manufacturer: METTLER TOLEDO
Resolution: 0.0001 g
ID No.: UAE.WAS.012/2564

Page 2 of 4

Date of Calibration: 10 May 2023

Environment Condition: Ambient Temperature: 23.4 ± 0.2 °C Relative Humidity: 43.4 ± 0.9 %

Place of Calibration: Balance room (Water Analysis Unit), UNITED ANALYST AND ENGINEERING CONSULTANT CO., LTD.

Condition of Equipment: Good Condition

Condition of This Results of Calibration:

1. Calibration Method: NFI Method W-HA-001 In-House Method based on UKAS Lab 14: 2015

2. Reference Standards:

Reference Standard Model Serial No. Calibrated By Certificate No. Due Date

Standard Weight Class E2 1mg to 200g B505567572 TCS M2304535 8 April 2024

Instrument Model Serial No. Calibrated By Certificate No. Due Date

Thermo-Hygro Meter 605-H1 NFI.BTH 016/23 Quality Room QR23-0489 21 February 2024

3. This certification is traceable to SI UNIT

4. This certificate was certified only for the instrument we calibrated.

5. This result of calibration was found accurate as shown on date and place of calibration only.



Calibration Results:

1. Repeatability of Reading:

Nominal Value (g)	Standard Deviation of Reading (g)
100	0.000032
200	0.000032

2. Off-Center Error:

A mass of 100 g was placed and moved to various position on pan.
The balance reading obtained is given in the table.



1	2	3	4	5	6	(Maximum Difference)
(g)	(g)	(g)	(g)	(g)	(g)	(g)
100.0002	100.0002	100.0002	100.0002	100.0003	100.0002	0.0001

F-CS-012 Revision: 01 Date: 20-04-65

Calibration Report

Certificate No.: 2302827-001-01
Equipment: Electronic Balance
Model: XSR204
Serial No.: C117635043
Capacity: 220 g
Manufacturer: METTLER TOLEDO
Resolution: 0.0001 g
ID No.: UAE.WAS.012/2564

Page 3 of 4

Date of Calibration: 10 May 2023

Calibration Results: (Continued)

Calibration Range: 0 - 200 g

Calibration Adjustment: Internal Calibration

3. Departure from Nominal Values:

Nominal Value (g)	Standard Value (g)	Average Reading (g)	Correction (g)	Uncertainty (g)	Coverage Factor K
Unipad	0.00300	0.00300	0.00000	0.000085	2.00
0.01	0.01000	0.01000	0.00000	0.000085	2.00
0.02	0.02000	0.02000	0.00000	0.000085	2.00
0.05	0.05000	0.05000	0.00000	0.000085	2.00
0.1	0.10000	0.10000	0.00000	0.000085	2.00
0.2	0.20000	0.20000	0.00000	0.000085	2.00
0.5	0.50000	0.50000	0.00000	0.000085	2.00
1	1.00000	1.00000	0.00000	0.000086	2.00
2	2.00002	2.00000	-0.00002	0.000086	2.00
3	3.00003	3.00000	-0.00003	0.000087	2.00
5	5.00002	5.00000	-0.00002	0.000087	2.00
10	10.00001	10.00000	-0.00001	0.000088	2.00
20	20.00003	20.00000	-0.00003	0.000092	2.00
30	30.00004	30.00000	-0.00004	0.000098	2.00
40	40.00007	40.00000	-0.00007	0.00011	2.00
45	45.00009	45.00001	-0.00008	0.00013	2.00

F-CS-012 Revision: 01 Date: 20-04-65

Calibration Report

Certificate No.: 2302827-001-01
Equipment: Electronic Balance
Model: XSR204
Serial No.: C117635043
Capacity: 220 g
Manufacturer: METTLER TOLEDO
Resolution: 0.0001 g
ID No.: UAE.WAS.012/2564

Page 4 of 4

Date of Calibration: 10 May 2023

Calibration Results: (Continued)

Calibration Range: 0 - 200 g

Calibration Adjustment: Internal Calibration

3. Departure from Nominal Values:

Nominal Value (g)	Standard Value (g)	Average Reading (g)	Correction (g)	Uncertainty (g)	Coverage Factor K
50	50.00003	50.00000	-0.00003	0.00011	2.00
55	55.00005	55.00000	-0.00005	0.00012	2.00
60	60.00004	60.00000	-0.00004	0.00012	2.00
65	65.00005	65.00000	-0.00005	0.00013	2.00
70	70.00006	70.00001	-0.00005	0.00013	2.00
75	75.00008	75.00002	-0.00006	0.00013	2.00
80	80.00007	80.00002	-0.00005	0.00014	2.00
85	85.00009	85.00002	-0.00007	0.00014	2.00
90	90.00010	90.00002	-0.00008	0.00015	2.00
100	100.00005	100.00002	-0.00003	0.00016	2.00
120	120.00009	120.00002	-0.00007	0.00018	2.00
150	150.00005	150.00002	-0.00003	0.00021	2.00
200	200.00016	200.00003	-0.00013	0.00028	2.00

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor K, providing a level of confidence of approximately 95 %.

----- End -----

F-CS-012 Revision: 01 Date: 20-04-65



TECHNOLOGY PROMOTION ASSOCIATION (THAILAND-JAPAN)
CORPORATE SERVICES 3: EQUIPMENT CALIBRATION AND TESTING SERVICES
534/4 PATTANAKARN ROAD SOI 18, SUANLUANG, SUANLUANG BANGKOK 10250
TEL. 0-2717-3000-29 FAX. 0-2719-9484



Cert. No.: 24TM303
Page : 1 of 3

Certificate of Calibration

Equipment : BOD Incubator
Manufacturer : Arco
Model : UC4-1320
Serial No. : 13URC4S013201
ID No. : UAE.WAO.015/2551
Submitted by : United Analyst and Engineering Consultant Co., Ltd.
3 Soi Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong,
Bangkok 10260
Location : Lab Floor 2
Received Order : 10 February 2024
Calibration Date : 10 February 2024
Ambient Temperature : (26 ± 10) °C
Relative Humidity : (50 ± 30) %
Calibrated by : Tewatchai Pama
Approved by :
() Pormhippa Tameyakul
(✓) Unnophol Harachai
() Suwit Imjai
Issue Date : 19 February 2024

The Uncertainties are for a confidence probability of approximately 95%

This certificate may not be reproduced other than in full, except with the prior written
Approval of the head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม



Equipment : BOD Incubator
Condition As-Received : Used Item
Reference : 2402-0234OC-1
Result of Calibration : (*) Without Adjustment
Function of UUC* : Temperature Source
Fresh air setting : Not Available

Cert. No.: 24TM303
Page : 3 of 3

Calibration Point (°C)	UUC* Setting (°C)	UUC* Reading (°C)	Temperature stability (± °C)	Temperature uniformity (°C)	Overall Variation (°C)	Coverage Factor k
20.0	20.1	19.8	0.37	0.72	1.4	2

Calibration Point (°C)	Measured Temperature (°C)								Uncertainty (± °C)
	1	2	3	4	5	6	7	8 (ref.)	
20.0	19.873	19.803	20.322	19.690	19.615	19.585	19.612	19.558	0.58

Average* : The average of 30 values in each position.

Temperature stability : One-half of the greatest maximum difference of measured temperature at any one sensor.

Temperature uniformity : The maximum difference of measured temperatures at any sensors and the measured temperature at the reference location which are observed at the same time or at as close an observation time as possible to determine the temperature pattern or homogeneity within the chamber under steady-state conditions.

Overall Variation : The Difference of the maximum and minimum measured temperatures throughout observation.

UUC* : Unit Under Calibration

Note : The reported uncertainty of measurement was included stability and excluded uniformity.

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k, providing a level of confidence of approximately 95 %.

-000-

เอกสารไม่ควบคุม



Equipment : BOD Incubator
Condition As-Received : Used Item
Reference : 2402-0234OC-1

Cert. No.: 24TM303
Page : 2 of 3

Procedure Used :-

Calibration were conducted using calibration procedure CP-OT02 based on TLAS G-20 according to direct measurement method with Data Acquisition which connected with Resistance Temperature Detector (RTD).
The temperature scale used was based on ITS-90.

Condition of this result of calibration

1. Reference standard instrument:-

Instrument	Serial No.	Cert. No.	Traceable	Due Date
1) Data Acquisition	MY59003411	23LM208	TPA	27 Dec 2024

2. This certificate is valid only to the item calibrated on date and place of calibration.

3. This certification is traceable to the International System of Unit.

Remark : TPA : Technology Promotion Association (Thailand - Japan)


Result of Calibration : (*) Without Adjustment

Function of UUC* : Temperature Source

Fresh air setting : Not Available

Environment during calibration	
	Beginning / Finished
Temp. (°C)	28 / 31
REL.Humid. (%)	70 / 65
AC Supply (Volt)	233 / 234

Position :	Ref. Std. ID No.:
1	20RTD-2/1
2	20RTD-2/2
3	20RTD-2/3
4	20RTD-2/4
5	20RTD-2/5
6	20RTD-2/6
7	20RTD-2/7
8	20RTD-2/8
9 (ref.)	20RTD-2/9



Probe Installation Details :

Dimension of Chamber :	
a = 10 cm	D = 0.62 m
b = 10 cm	W = 1.2 m
c = 10 cm	H = 1.2 m
	Capacity = 0.89 m ³

เอกสารไม่ควบคุม



TECHNOLOGY PROMOTION ASSOCIATION (THAILAND-JAPAN)
CORPORATE SERVICES 3: EQUIPMENT CALIBRATION AND TESTING SERVICES
534/4 PATTANAKARN ROAD SOI 18, SUANLUANG, SUANLUANG BANGKOK 10250
TEL. 0-2717-3000-29 FAX. 0-2719-9484



Cert. No.: 24TM558
Page : 1 of 3

Certificate of Calibration

Equipment : BOD Incubator
Manufacturer : ARCO
Model : UR-1320
Serial No. : -
ID No. : UAE.WAO.006/2553
Submitted by : United Analyst and Engineering Consultant Co., Ltd.
3 Soi Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong,
Bangkok 10260
Location : Lab Floor 2
Received Order : 01 April 2024
Calibration Date : 01 April 2024
Ambient Temperature : (26 ± 10) °C
Relative Humidity : (50 ± 30) %
Calibrated by : Krisda Malee
Approved by :
() Ponpan Paipim
(✓) Suwit Imjai
() Kunchit Promprat
Issue Date : 5 April 2024

The Uncertainties are for a confidence probability of approximately 95%

This certificate may not be reproduced other than in full, except with the prior written
Approval of the head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม

A 0065064

เอกสารไม่ควบคุม



มูลนิธิศูนย์พัฒนาอาหาร
ศูนย์บริการห้องปฏิบัติการอาหาร
Foundation for Industrial Development National Food Institute
Food Industrial Laboratory Service Center

Verification Certificate

Certificate No.: 2304455-001-01
Client name: UNITED ANALYST AND ENGINEERING CONSULTANT CO., LTD.
Address: 3 Soi Udomsuk 41, Sukhumvit Road,
Bangchack, Prakhnong, Bangkok 10260

Page 1 of 4

Equipment: Digestion Unit (Heating Block)

Manufacturer: VELP SCIENTIFICA

Model: DKL20

Serial No.: 213517

ID No.: UAE.WAS.005/2555

Order No.: 2304455

Operation No.: 2304455-001

Date of Receipt: 28 August 2023

Date of Calibration: 28-29 August 2023

Calibrated by Mr. Manas Somsak
Specialist

Approved by (Mr. Pheraphat Tuanjit)
Manager, Division of Calibration Laboratory
Responsible for the Technical Management Team

Date of Issue: 1 September 2023

The uncertainties are for a confidence probability of approximately 95 %.

This Certificate is issued in accordance with the conditions of accreditation granted by the Thai Laboratory Accreditation scheme which has assessed the measurement capability of the laboratory and its traceability to recognized national standards and to the units of measurement realized at the corresponding national standards laboratory. This certificate may not be reproduced other than in full except with the prior written approval of the National Food Institute.

F-CS-009 Revision: 01 Date: 20-04-65



มูลนิธิศูนย์พัฒนาอาหาร
ศูนย์บริการห้องปฏิบัติการอาหาร
Foundation for Industrial Development National Food Institute
Food Industrial Laboratory Service Center

Verification Report

Certificate No.: 2304455-001-01
Equipment: Digestion Unit (Heating Block)
Model: DKL20 Serial No.: 213517
Resolution: 1 °C ID No.: UAE.WAS.005/2555
Manufacturer: VELP SCIENTIFICA

Date of Calibration: 28-29 August 2023

Page 2 of 4

Location: Dry Laboratory (312), UNITED ANALYST AND ENGINEERING CONSULTANT CO., LTD.
Environment Condition: Ambient Temperature (28 ± 1) °C
Relative Humidity (58 ± 3) %
Line Voltage (224 ± 2) Volt

Condition of this results of Calibration:

- This instrument was calibrated by Insert standard thermocouples type R into its Digestion blocks and Calibration according to NFI Method W-TE-026 based on BS 4309 : 1968
- The temperature scale used was based on ITS - 90
- All data show below were final values and the Initial data may be obtained upon request.

2. Reference Standard Instrument :

Instrument	Model	Serial No.	Certificate No.	Due Date	Through
Digital Thermometer with Thermocouple	34970A	MY404557/MY4184452	TC23/0048	2-Jun-2024	N.M. Technical Center Laboratory
Type R	R/CH1 to R/CH3				

- This certificate is traceable to International System of Units (SI Units).

- This certificate was certified only for the instrument we calibrated.

- This result of calibration was found accurate as shown on date and place of calibration only.

- Condition of Calibrated item : Good

UUC* Description

Time of Record 1 Hour 6 Minute At 380 °C

- Result of Calibration : ☒ Without adjustment ☐ After adjustment

F-CS-012 Revision: 01 Date: 20-04-65



มูลนิธิศูนย์พัฒนาอาหาร
ศูนย์บริการห้องปฏิบัติการอาหาร
Foundation for Industrial Development National Food Institute
Food Industrial Laboratory Service Center

Verification Report

Certificate No.: 2304455-001-01
Equipment: Digestion Unit (Heating Block)
Model: DKL20 Serial No.: 213517
Resolution: 1 °C ID No.: UAE.WAS.005/2555
Manufacturer: VELP SCIENTIFICA

Date of Calibration: 28-29 August 2023

Page 3 of 4

Calibration point: 380 °C

Calibration result:

Table1 : Reporting of Temperature

Block No.	UUC* Setting (°C)	UUC* Reading (°C)	Stability (±°C)	Standard Thermometer (°C)	Uncertainty (±°C)
1	380	380	0.16	378.59	2.0
2	380	380	0.18	378.65	2.0
3	380	380	0.18	381.62	2.0
4	380	380	0.24	380.23	2.0
5	380	380	0.26	379.86	2.0
6	380	380	0.26	380.93	2.0
7	380	380	0.25	381.11	2.0
8	380	380	0.19	382.35	2.0
9	380	380	0.26	381.55	2.0
10	380	380	0.25	380.20	2.0
11	380	380	0.29	382.08	2.0
12	380	380	0.19	382.26	2.0
13	380	380	0.19	382.26	2.0
14	380	380	0.21	382.15	2.0
15	380	380	0.12	382.15	2.0
16	380	380	0.20	381.91	2.0
17	380	380	0.15	381.09	2.0
18	380	380	0.13	381.42	2.0
19	380	380	0.13	381.77	2.0
20	380	380	0.29	382.08	2.0

Note:

- UUC* = Unit Under Calibration

- Immersion depth of standard thermometer in tube level high of sand is equal heater plate of UUC.

- Stability = One-half of the greatest maximum difference of measured temperatures at one sensors, for at least half an hour after reaching steady state.

The report uncertainty of measurement was based on standard uncertainty multiplied by coverage factor $k=2$, providing a level of confidence of approximately 95 %.

F-CS-012 Revision: 01 Date: 20-04-65



มูลนิธิศูนย์พัฒนาอาหาร
ศูนย์บริการห้องปฏิบัติการอาหาร
Foundation for Industrial Development National Food Institute
Food Industrial Laboratory Service Center

Verification Report

Certificate No.: 2304455-001-01
Equipment: Digestion Unit (Heating Block)
Model: DKL20 Serial No.: 213517
Resolution: 1 °C ID No.: UAE.WAS.005/2555
Manufacturer: VELP SCIENTIFICA


Date of Calibration: 28-29 August 2023

Page 4 of 4

Calibration point: 380 °C

Calibration result: Continued

Figure 1. Location of Reference Standard and Block Diagram of Digestion Unit



Sensor Installation Location

----- End -----

F-CS-012 Revision: 01 Date: 20-04-65



Certificate of Calibration

Cert. No.: 24TM650
Page : 1 of 3

Equipment : Incubator
Manufacturer : Memmert
Model : IPP 250
Serial No. : V616.0066
IO No. : UAE.MIC.032/2559
Submitted by : United Analyst and Engineering Consultant Co.,Ltd.
3 Soi Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong,
Bangkok 10280
Location : Microbiology Laboratory (302)
Received Order : 01 April 2024
Calibration Date : 02 - 03 April 2024
Ambient Temperature : $(26 \pm 10) ^\circ\text{C}$
Relative Humidity : $(50 \pm 30) \%$

Calibrated by : Man Pattanapongpalboon

Approved by :

() Ponpan Paipim
(✓) Suwit Imjai
() Kunchit Promprat

Issue Date : 7 April 2024

The Uncertainties are for a confidence probability of approximately 95%.

This certificate may not be reproduced other than in full, except with the prior written approval of the head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม



Equipment : Incubator
Condition As-Received : Used Item
Reference : 2404-003OC-2
Procedure Used :-

Cert. No.: 24TM650
Page : 2 of 3

Calibration were conducted using calibration procedure CP-OT02 based on TLAS G-20 according to direct measurement method with Data Acquisition which connected with Resistance Temperature Detector (RTD).
The temperature scale used was based on ITS-90.

Condition of this result of calibration

1. Reference standard instrument:-

Instrument	Serial No.	Cert. No.	Traceable	Due Date
1) Data Acquisition	MY48023932	23LM122	TPA	26 Jul 2024

2. This certificate is valid only to the item calibrated on date and place of calibration.

3. This certification is traceable to the International System of Unit.


Remark : TPA : Technology Promotion Association (Thailand - Japan)

Result of Calibration :- (*) Without Adjustment

Function of UUC* : Temperature Source

Fresh air setting : Close

Environment during calibration		
	Beginning	Finished
Temp. (°C)	25	25
REL. Humid. (%)	57	54
AC Supply (Volt)	221	222



Probe Installation Details :

a = 5.0 cm
b = 5.0 cm
c = 5.0 cm

Dimension of Chamber :

D = 0.50 m
W = 0.64 m
H = 0.90 m
Capacity = 0.26 m³

Position	Ref. Std. ID No.
1	19-16RTD-01
2	19-16RTD-02
3	19-16RTD-03
4	19-16RTD-04
5	19-16RTD-05
6	19-16RTD-06
7	21-16RTD-07
8	19-16RTD-08
9 (ref.)	19-16RTD-09

เอกสารไม่ควบคุม



Equipment : Incubator
Condition As-Received : Used Item
Reference : 2404-003OC-2
Result of Calibration :- (*) Without Adjustment
Function of UUC* : Temperature Source
Fresh air setting : Close

Cert. No.: 24TM650
Page : 3 of 3

Calibration Point (°C)	UUC* Setting (°C)	UUC* Reading (°C)	Temperature stability (± °C)	Temperature uniformity (°C)	Overall Variation (°C)	Coverage Factor k
25.0	25.0	25.0	0.063	0.73	1.3	2
36.0	36.0	36.0	0.14	0.57	0.93	2

Calibration Point (°C)	Measured Temperature (°C)									Uncertainty (± °C)
	1	2	3	4	5	6	7	8	9 (ref.)	
25.0	25.596	25.310	25.439	25.412	24.347	24.332	24.313	24.414	24.875	0.30
36.0	35.643	35.965	35.618	35.701	36.239	36.260	36.343	36.357	36.063	0.31

Average* : The average of 30 values in each position.

Temperature stability : One-half of the greatest maximum difference of measured temperature at any one sensor.

Temperature uniformity : The maximum difference of measured temperatures at any sensors and the measured temperature at the reference location which are observed at the same time or at as close an observation time as possible to determine the temperature pattern or homogeneity within the chamber under steady-state conditions.

Overall Variation : The Difference of the maximum and minimum measured temperatures throughout observation.

UUC* : Unit Under Calibration

Note : The reported uncertainty of measurement was included stability and excluded uniformity .

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k, providing a level of confidence of approximately 95 %.

-o-o-

เอกสารไม่ควบคุม



Certificate of Calibration

Cert. No.: 24TM29
Page : 1 of 3

Equipment : Water Bath

Manufacturer : Memmert

Model : WNE 14

Serial No. : L416.0606

IO No. : UAE.MIC.002/2560

Submitted by : United Analyst and Engineering Consultant Co.,Ltd.
3 Soi Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong,
Bangkok 10280

Location : Microbiology Laboratory

Received Order : 10 February 2024

Calibration Date : 10 February 2024

Ambient Temperature : $(26 \pm 10) ^\circ\text{C}$

Relative Humidity : $(50 \pm 30) \%$

Calibrated by : Krisda Malice

Approved by :

() Pomthippa Tameyakul
(✓) Unnophol Harachai
() Suwit Imjai

Approved Signatory

Issue Date : 19 February 2024

The Uncertainties are for a confidence probability of approximately 95%.

This certificate may not be reproduced other than in full, except with the prior written approval of the head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม



Equipment : Water Bath
Condition As-Received : Used Item
Reference : 2402-0232OC-2
Cert. No.: 24TM29
Page : 2 of 3

Procedure Used :-
Calibration were conducted using in-house calibration procedure CP-OT04 Based on ASTM E715 according to direct measurement method with Data Acquisition which connected with Industrial Platinum Resistance Thermometer (IPRT).

The temperature scale used was based on ITS-90.

Condition of this result of calibration

1. Reference standard Instrument:-

Instrument	Serial No.	Cert. No.	Traceable	Due Date
1) Data Acquisition	MY49001451	23LM27	TPA	25 Feb 2024

2. This certificate is valid only to the item calibrated on date and place of calibration.

3. This certification is traceable to the International System of Unit.


Remark : TPA : Technology Promotion Association (Thailand - Japan)

Result of Calibration :- (*) Without Adjustment

Function of UUC* : Temperature Source

Heat transfer medium used : Water

	Environmental		AC Voltage Supply
	(°C)	(%R.H.)	(Volt)
Beginning of Calibration	26	51	220
Finished of Calibration	25	50	221



Front

Position :	Ref. Std. ID No.:
1	N37P301419
2	N37P300732
3	N37P301420
4	N37P301421
5(ref.)	N37P301425

เอกสารไม่ควบคุม



Equipment : Water Bath
Condition As-Received : Used Item
Reference : 2402-0232OC-2
Cert. No.: 24TM29
Page : 3 of 3

Result of Calibration :- (*) Without Adjustment
Function of UUC* : Temperature Source

Calibration point (°C)	UUC* Setting (°C)	UUC* Reading (°C)	Average* Standard Reading (°C)					Uncertainty (± °C)
			1	2	3	4	5 (ref.)	
44.5	44.4	44.4	44.508	44.469	44.502	44.521	44.527	0.15

Calibration point (°C)	Uniformity (°C)	Stability (± °C)	Coverage Factor k
44.5	0.15	0.074	2

Average* : The average of 30 values in each position.

Uniformity : The maximum difference of measured temperatures at any sensors and the measured temperature at the reference location which are observed at the same time or at as close an observation time as possible to determine the temperature pattern or homogeneity within the chamber under steady-state conditions.

Stability : One-half of the greatest maximum difference of measured temperature at any one probe.
UUC* : Unit Under Calibration

Note : The reported uncertainty of measurement was included stability and excluded uniformity.

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k, providing a level of confidence of approximately 95 %.

-o0o-

เอกสารไม่ควบคุม



TECHNOLOGY PROMOTION ASSOCIATION (THAILAND-JAPAN)
CORPORATE SERVICES 3: EQUIPMENT CALIBRATION AND TESTING SERVICES
534/4 PATTANAKARN ROAD SOI 18, SUANLUANG, SUANLUANG BANGKOK 10250
TEL. 0-2717-3000-29 FAX. 0-2719-9494



Cert. No.: 24TM29
Page : 1 of 3

Certificate of Calibration

Equipment : Water Bath
Manufacturer : Mommert
Model : WNE 14
Serial No. : L416.0606
ID No. : UAE.MIC.002/2560
Submitted by : United Analyst and Engineering Consultant Co.,Ltd.
3 Soi Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong,
Bangkok 10260
Location : Microbiology Laboratory
Received Order : 10 February 2024
Calibration Date : 10 February 2024
Ambient Temperature : (26 ± 10) °C
Relative Humidity : (50 ± 30) %

Calibrated by : Krisda Malee

Approved by :
Approved Signatory

() Ponthippha Tameyakul
(✓) Uthongphol Harachai
() Suwit Imjai

Issue Date : 19 February 2024

The Uncertainties are for a confidence probability of approximately 95%

This certificate may not be reproduced other than its full, except with the prior written
Approval of the head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม



Equipment : Water Bath
Condition As-Received : Used Item
Reference : 2402-0232OC-2
Cert. No.: 24TM29
Page : 2 of 3

Procedure Used :-

Calibration were conducted using in-house calibration procedure CP-OT04 Based on ASTM E715 according to direct measurement method with Data Acquisition which connected with Industrial Platinum Resistance Thermometer (IPRT).

The temperature scale used was based on ITS-90.

Condition of this result of calibration

1. Reference standard Instrument:-

Instrument	Serial No.	Cert. No.	Traceable	Due Date
1) Data Acquisition	MY49001451	23LM27	TPA	25 Feb 2024

2. This certificate is valid only to the item calibrated on date and place of calibration.

3. This certification is traceable to the International System of Unit.


Remark : TPA : Technology Promotion Association (Thailand - Japan)

Result of Calibration :- (*) Without Adjustment

Function of UUC* : Temperature Source

Heat transfer medium used : Water

	Environmental		AC Voltage Supply
	(°C)	(%R.H.)	(Volt)
Beginning of Calibration	26	51	220
Finished of Calibration	25	50	221



Front

Position :	Ref. Std. ID No.:
1	N37P301419
2	N37P300732
3	N37P301420
4	N37P301421
5(ref.)	N37P301425

เอกสารไม่ควบคุม



Equipment : Water Bath
Condition As-Received : Used Item
Reference : 2402-02320C-2
Result of Calibration : (*) Without Adjustment
Function of UUC* : Temperature Source

Cert. No.: 24TM29
Page : 3 of 3

Calibration point (°C)	UUC* Setting (°C)	UUC* Reading (°C)	Average* Standard Reading (°C)					Uncertainty (± °C)
			1	2	3	4	5 (ref.)	
44.5	44.4	44.4	44.506	44.469	44.502	44.521	44.527	0.15

Calibration point (°C)	Uniformity (°C)	Stability (± °C)	Coverage Factor k
44.5	0.15	0.074	2

Average* : The average of 30 values in each position.
Uniformity : The maximum difference of measured temperatures at any sensors and the measured temperature at the reference location which are observed at the same time or at as close an observation time as possible to determine the temperature pattern or homogeneity within the chamber under steady-state conditions.
Stability : One-half of the greatest maximum difference of measured temperature at any one probe.
UUC* : Unit Under Calibration
Note : The reported uncertainty of measurement was included stability and excluded uniformity.

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k , providing a level of confidence of approximately 95 %.

-00-

เอกสารไม่ควบคุม



TECHNOLOGY PROMOTION ASSOCIATION (THAILAND-JAPAN)
CORPORATE SERVICES 3: EQUIPMENT CALIBRATION AND TESTING SERVICES
514/4 PATTANAKARN ROAD SOI 13, SUANLUANG, SUANLUANG BANGKOK 10250
TEL. 0 2717 3000-26 FAX. 0 2719 9484



Cert. No.: 23TM763
Page : 1 of 3

Certificate of Calibration

Equipment : Autoclave
Manufacturer : ALP
Model : CL-43L
Serial No. : 808763
ID No. : UAE.MIC.0262563
Submitted by : United Analyst and Engineering Consultant Co.,Ltd.
3 Soi Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong,
Bangkok 10260
Location : Microbiology Laboratory (301)
Received Order : 27 April 2023
Calibration Date : 27 April 2023
Ambient Temperature : (26 ± 10) °C
Relative Humidity : (50 ± 30) %

Calibrated by : Preecha Hlahib

Approved by :
Approved Signatory

(/) Pormthippa Tameyakul
(/) Malee Bulkrusa
() Suwit Imjai

Issue Date : 11 May 2023

The Uncertainties are for a confidence probability of approximately 95%

This certificate may not be reproduced other than in full, except with the prior written
Approval of the Head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม

A 0053944



Equipment : Autoclave
Condition As-Received : Used Item
Reference : 2304-04610C-2
Procedure Used : -

Cert. No.: 23TM763
Page : 2 of 3

Calibration were conducted using in-house calibration procedure CP-OT03 according to direct measurement method with Data Acquisition which connected with Thermocouple Type T

The temperature scale used was based on ITS-90.

Condition of this result of calibration

1. Reference standard instrument:-

Instrument	Model	Serial No.	Cert. No.	Due Date
1) Data Acquisition	34972A	MY59003411	22LM165	26 Nov 2023

2. This certificate is valid only to the item calibrated on date and place of calibration.

3. This certification is traceable to the International System of Unit.

4. This result of calibration covers laboratory autoclaves for the sterilization of goods and material which

could be infected with organisms categorized as Hazard Group 1, 2 and 3**

(** = Categorization of pathogens according to hazard and categories of containment, second edition, 1990)

It does not cover autoclaves for use with material infect with organisms in Hazard Group 4, for which

complete containment and sterilization of infected condensate is considered to be essential.


This result of calibration does not apply to sterilizers or disinfectors used for medical, dental, pharmaceutical

or veterinary purposes which are directly concerned with patient care, or those used for fabrics subjected to

sterilization which are required to be dry at the end of cycle.

Result of Calibration : (*) Without Adjustment

Function of UUC* : Temperature Source



	Environmental		
	(°C)	(%R.H.)	(Volt)
Beginning of Calibration	27	60	220
Finished of Calibration	27	58	220
Position	Ref. Std. ID No.:		
1 = Center of chamber	18-20TC-04		
2 = Temperature sensor	18-20TC-05		
3 = Exhaust port	18-20TC-06		

เอกสารไม่ควบคุม

a 1159968



Equipment : Autoclave
Condition As-Received : Used Item
Reference : 2304-04610C-2
Result of Calibration : (*) Without Adjustment
Function of UUC* : Temperature Source

Cert. No.: 23TM763
Page : 3 of 3

Operating parameter Set : Temperature = 115.0 °C
Sterilization period = 15 minute

UUC* Setting (°C)	UUC* Reading (°C)	Position	Average* Standard Reading (°C)	Stability (± °C)	Pressure Reading (MPa)	Uncertainty (± °C)	Coverage Factor k
115.0	115.0	1	115.213	0.22	0.08	0.75	2
		2	115.166				
		3	115.260				

Operating parameter Set : Temperature = 121.0 °C
Sterilization period = 30 minute

UUC* Setting (°C)	UUC* Reading (°C)	Position	Average* Standard Reading (°C)	Stability (± °C)	Pressure Reading (MPa)	Uncertainty (± °C)	Coverage Factor k
121.0	121.0	1	121.260	0.29	1.1	0.75	2
		2	121.224				
		3	121.284				

Average* : The average of 30 values in each position.

Stability : One-half of the greatest maximum difference of measured temperature at any one probe.

UUC* : Unit Under Calibration

Note : The reported uncertainty of measurement was included stability and excluded uniformity .

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k , providing a level of confidence of approximately 95 %.

-00-

เอกสารไม่ควบคุม

a 1159967



TECHNOLOGY PROMOTION ASSOCIATION (THAILAND-JAPAN)
CORPORATE SERVICES 3: EQUIPMENT CALIBRATION AND TESTING SERVICES
53-4 PATTANAKARN ROAD SOT 18, SUKHUMVIT, SUKHUMVIT BANGKOK 10250
TEL: 0-2717-3000-29 FAX: 0-2719-9484



Cert. No.: 23TM1077
Page: 1 of 3

Certificate of Calibration

Equipment : Refrigerator
Manufacturer : Sanden Intercool
Model : YPM11P
Serial No. : YPM11P-150801805
ID No. : UAE.MIC.012/2558
Submitted by : United Analyst and Engineering Consultant Co., Ltd.
3 Sol Udomsuk 41, Sukhumvit Road,
Bangchak, Phrakhanong,
Bangkok 10260
Location : Microbiology Laboratory
Received Order : 10 July 2023
Calibration Date : 10 July 2023
Ambient Temperature : $(26 \pm 10) ^\circ\text{C}$
Relative Humidity : $(50 \pm 30) \%$
Calibrated by : Man Pattanapongpaiboon
Approved by :
() Pornthippa Tameyskul
(/) Malee Butkuea
() Suwit Imjel

Issue Date : 20 July 2023

The Uncertainties are for a confidence probability of approximately 95%

This certificate may not be reproduced other than in full, except with the prior written
Approval of the head of Corporate Services 3: Equipment Calibration and Testing Services.

เอกสารไม่ควบคุม



Equipment : Refrigerator
Condition As-Received : Used Item
Reference : 2307-0087OC-4
Procedure Used :-

Cert. No.: 23TM1077
Page: 2 of 3

Calibration were conducted using calibration procedure CP-OT02 according to direct measurement
method with Data Acquisition which connected with Resistance Temperature Detector (RTD).
The temperature scale used was based on ITS-90.


Condition of this result of calibration

- Reference standard instrument:-
Instrument Serial No. Cert. No. Traceable Due Date
1) Data Acquisition MY59003411 22LM165 TPA 26 Nov 2023
- This certificate is valid only to the item calibrated on date and place of calibration.
- This certification is traceable to the International System of Unit.

Remark : TPA : Technology Promotion Association (Thailand - Japan)

Result of Calibration : (*) Without Adjustment
Function of UUC* : Temperature Source
Fresh air setting : Not Available

Environment during calibration		
	Beginning	Finished
Temp. (°C)	24	24
REL.Humid. (%)	54	55
AC Supply (Volt)	221	222



Probe Installation Details : Dimension of Chamber :
a = 10 cm D = 0.51 m
b = 10 cm W = 1.0 m
c = 10 cm H = 1.2 m
Capacity = 0.61 m³

Position :	Ref. Std. ID No.:
1	20RTD-2/1
2	20RTD-2/2
3	20RTD-2/3
4	20RTD-2/4
5	20RTD-2/5
6	20RTD-2/6
7	20RTD-2/7
8	20RTD-2/8
9 (ref.)	20RTD-2/9

เอกสารไม่ควบคุม



Equipment : Refrigerator
Condition As-Received : Used Item
Reference : 2307-0087OC-4
Result of Calibration : (*) Without Adjustment
Function of UUC* : Temperature Source
Fresh air setting : Not Available
Cert. No.: 23TM1077
Page: 3 of 3

Calibration Point (°C)	UUC* Setting (°C)	UUC* Reading (°C)	Temperature stability (± °C)	Temperature uniformity (°C)	Overall Variation (°C)	Coverage Factor k
5.0	5.0	-1.9	2.6	3.2	5.9	2

Calibration Point (°C)	Measured Temperature (°C)									Uncertainty (± °C)
	1	2	3	4	5	6	7	8	9 (ref.)	
5.0	2.237	2.432	2.281	2.637	4.642	4.536	4.667	4.577	3.015	3.2

Average* : The average of 30 values in each position.
Temperature stability : One-half of the greatest maximum difference of measured temperature at any one sensor.
Temperature uniformity : The maximum difference of measured temperatures at any sensors and the measured temperature at the reference location which are observed at the same time or at as close an observation time as possible to determine the temperature pattern or homogeneity within the chamber under steady-state conditions.
Overall Variation : The Difference of the maximum and minimum measured temperatures throughout observation.
UUC* : Unit Under Calibration
Note : The reported uncertainty of measurement was included stability and excluded uniformity.

The reported uncertainty of measurement was based on a standard uncertainty multiplied by a coverage factor k, providing a level of confidence of approximately 95 %.

-o0o-

เอกสารไม่ควบคุม



Certificate of Calibration

Equipment : Balance
Model : PX823
Serial No. (or ID.): C236754745 (UAE.MIC.055/2565)
Manufacturer : Ohaus
Condition : In condition

Certificate No.: C01234158
Issued Date: 08 December 2023
Job No.: WO-00011251
Page: 1 of 3

Customer : United Analyst and Engineering Consultant Co., Ltd.
3 Sol Udomsuk 41, Sukhumvit Road, Bangchak Sub-District,
Phrakhanong District, Bangkok, THAILAND 10260

Environment Condition : Temperature $25 ^\circ\text{C} \pm 0.5 ^\circ\text{C}$
Humidity $54 \% \text{RH} \pm 1.7 \% \text{RH}$

Calibration Place : United Analyst and Engineering Consultant Co., Ltd. (301 Microbiology Room)
3 Sol Udomsuk 41, Sukhumvit Road, Bangchak Sub-District,
Phrakhanong District, Bangkok, THAILAND 10260

Calibration By : Mr. Adisai Makroil
Calibration Date : 07 December 2023
The Method used : In-house method, CAL-WI-47, based on UKAS Lab 14
Traceability : This certificate is traceable to the SI Units maintained by National Institute of Metrology (NIMT), Thailand through DKSH Technology Co., Ltd. Certificate No. C02222534

(Mr. Adisai Makroil)
Person in charge

(Mr. Rungrod Jenkitrakulchai)
Authorized signatory

This certificate is issued the units of measurement according to the International System of Units (SI), it provides traceability of measurement to International or national standard or other recognized national standard laboratories.
The measurement uncertainty stated is the expanded uncertainty which is obtained from the standard uncertainty multiplied by the coverage factor (k=2) to provide a level of confidence of approximately 95%. It is determined in accordance with the Guide to Expression of Uncertainty in Measurement (GUM).
These results may be affected by deviations from specified conditions. The results relate only to the items tested, calibrated or sampled. The report shall not be reproduced except in full without approval of DKSH Technology Limited.

บริษัท เทคโนโลยี จำกัด
DKSH Technology Limited
2533 ถนนสุขุมวิท แขวงคลองตัน เขตคลองเตย กรุงเทพมหานคร 10260
Phone: +66 2251 7100 Email: info.calibration@dksh.com Website: www.dksh.com/thailand/calibration

Delivering Growth - In Asia and Beyond.

เอกสารไม่ควบคุม

CAL-FM-C01-12 12 Sep 2022

Calibration Results:

Before Adjustment

Eccentric Error: Weight to be 1/3 or 1/2 of Maximum capacity, taken from the center of the pan as a zero reference.

			Nominal Test Value	200	(g)
Reference Points (g)					
A	B	C	D	E	
-	0.000	-0.003	0.000	0.001	

Repeatability: Determination of the standard deviation of weighing balance., Readability 0.001 (g)

Nominal test value (g)	Standard Deviation
50	0.0006
500	0.0008

Error of Indication from nominal or conventional mass value., Readability 0.001 (g)

Nominal Value (g)	Conventional Mass (g)	Displayed Value (g)	Error of Indication (g)	Uncertainty (g)	k
1	1.0000	1.000	0.000	0.0013	2.10
5	5.0001	5.000	0.000	0.0013	2.10
10	10.0001	10.001	0.001	0.0013	2.10
20	20.0000	20.000	0.000	0.0013	2.09
50	50.0001	50.000	0.000	0.0013	2.09
100	100.0001	100.001	0.001	0.0013	2.09
200	200.0004	200.002	0.002	0.0014	2.07
300	300.0005	300.002	0.002	0.0015	2.05
400	400.0006	400.004	0.003	0.0016	2.03
500	500.0006	500.008	0.007	0.0019	2.02
600	600.0007	600.009	0.008	0.0021	2.01

บริษัท ดีเคเอส อีเซีย จำกัด
DKSH Technology Limited
2533 ถนนสุขุมวิท แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10260
2533 Sukhumvit Road, Bangkok, Pratinthong, Bangkok 10260
Phone: +66 2638 7000 Email: info.asia@dksh.com Website: www.dksh.com/indonesia-thailand

เอกสารไม่ควบคุม

CAL-FM-C01-14; 12 Sep 2022

Delivering Growth - In Asia and Beyond.

After Adjustment

Eccentric Error: Weight to be 1/3 or 1/2 of Maximum capacity, taken from the center of the pan as a zero reference.

						Nominal Test Value	200	(g)
Reference Points (g)								
A	B	C	D	E				
-	0.001	-0.002	-0.002	0.001				

Repeatability: Determination of the standard deviation of weighing balance., Readability 0.001 (g)

Nominal test value (g)	Standard Deviation
50	0.0008
500	0.0008

Error of Indication from nominal or conventional mass value., Readability 0.001 (g)

Nominal Value (g)	Conventional Mass (g)	Displayed Value (g)	Error of Indication (g)	Uncertainty (g)	k
1	1.0000	1.000	0.000	0.0013	2.10
5	5.0001	5.000	0.000	0.0013	2.10
10	10.0001	10.000	0.000	0.0013	2.10
20	20.0000	20.000	0.000	0.0013	2.10
50	50.0001	50.000	0.000	0.0013	2.10
100	100.0001	100.000	0.000	0.0014	2.09
200	200.0004	200.000	0.000	0.0014	2.07
300	300.0005	300.001	0.001	0.0015	2.05
400	400.0006	400.002	0.001	0.0017	2.04
500	500.0006	500.001	0.000	0.0019	2.02
600	600.0007	600.002	0.001	0.0021	2.01

The End of Certificate

บริษัท ดีเคเอส อีเซีย จำกัด
DKSH Technology Limited
2533 ถนนสุขุมวิท แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10260
2533 Sukhumvit Road, Bangkok, Pratinthong, Bangkok 10260
Phone: +66 2638 7000 Email: info.asia@dksh.com Website: www.dksh.com/indonesia-thailand

เอกสารไม่ควบคุม

CAL-FM-C01-14; 12 Sep 2022

Delivering Growth - In Asia and Beyond.

Statements of conformity:

This conformity certificate documents the validity of the following statements of conformity based on the measurement results of corresponding calibration certificate:

The error of indication determined during calibration are under given measurement and environmental conditions and considering the expanded measurement uncertainty (coverage probability 95%) within the specification. The given measurement uncertainty already includes other all effects by according to the standard method, UKAS Lab14. Therefore, those parameters have not been assessed separately.

Tolerance and Decision rules:

Assessment of the conformity of the measurement device are done based on direct comparison of the relevant measurement results with the tolerances and decision rule as prescribed by the customer.

- Decision rule : ☐ Choice A Binary Statement for Simple Acceptance Rule ($w = 0$), Specific Risk < 50% PFA.
- ☒ Choice B Non-binary statement with guard band ($w = 1$ U), Pass or Fail Specific Risk < 2.5% PFA and Condition Pass or Condition Fail Specific Risk < 50% PFA.
- ☐ Choice C Customer defined, Customers may define arbitrary multiple of r to have applied as guard band ($w = r$ U).
- : PFA = Probability of False Accept

Rungrod

(Mr. Rungrod Jenkitrakulchai)

Authorized signatory

เอกสารไม่ควบคุม

CAL-FM-C01-14; 12 Sep 2022

บริษัท ดีเคเอส อีเซีย จำกัด
DKSH Technology Limited
2533 ถนนสุขุมวิท แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10260
2533 Sukhumvit Road, Bangkok, Pratinthong, Bangkok 10260
Phone: +66 2638 7000 Email: info.asia@dksh.com Website: www.dksh.com/indonesia-thailand

Delivering Growth - In Asia and Beyond.

Statements of conformity:

Before Adjustment

Readability: 0.001 g

Nominal Value (g)	Error of Indication (g)	Guard band (w) (g)	Tolerance (±) (g)	Conformity
1	0.000	0.0013	0.002	Pass
5	0.000	0.0013	0.010	Pass
10	0.001	0.0013	0.020	Pass
20	0.000	0.0013	0.040	Pass
50	0.000	0.0013	0.100	Pass
100	0.001	0.0013	0.200	Pass
200	0.002	0.0014	0.400	Pass
300	0.002	0.0015	0.600	Pass
400	0.003	0.0016	0.800	Pass
500	0.007	0.0019	1.000	Pass
600	0.008	0.0021	1.200	Pass

The validity of the statements of conformity cannot be guaranteed for different places of use, environmental conditions or improper use.

บริษัท ดีเคเอส อีเซีย จำกัด
DKSH Technology Limited
2533 ถนนสุขุมวิท แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10260
2533 Sukhumvit Road, Bangkok, Pratinthong, Bangkok 10260
Phone: +66 2638 7000 Email: info.asia@dksh.com Website: www.dksh.com/indonesia-thailand

Delivering Growth - In Asia and Beyond.

เอกสารไม่ควบคุม

CAL-FM-C01-14; 12 Sep 2022

Statements of conformity:

After Adjustment

Readability: 0.001 g

Nominal Value	Error of indication	Guard band (u)	Tolerance ($\pm$)	Conformity
g	g	g	g	
1	0.000	0.0013	0.002	Pass
5	0.000	0.0013	0.010	Pass
10	0.000	0.0013	0.020	Pass
20	0.000	0.0013	0.040	Pass
50	0.000	0.0013	0.100	Pass
100	0.000	0.0014	0.200	Pass
200	0.000	0.0014	0.400	Pass
300	0.001	0.0015	0.600	Pass
400	0.001	0.0017	0.800	Pass
500	0.000	0.0019	1.000	Pass
600	0.001	0.0021	1.200	Pass

The validity of the statements of conformity cannot be guaranteed for different places of use, environmental conditions or improper use.



The End of Statements of conformity

บริษัท ดีเคเอส อีซี จำกัด
DKSH Technology Limited
2333 ถนนสุขุมวิท แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110
2333 Sukhumvit Road, Bangkok, Thailand 10110
Phone: +66 2638 7000 Email: info.calibration@dksh.com Website: www.dksh.com/scientific-thailand

Delivering Growth - In Asia and Beyond.

เอกสารไม่ควบคุม

DAI-PM-001-14; 12 Sep 2022



เอกสารไม่ควบคุม

ใบตรวจสอบสภาพเครื่องชั่ง

เลขที่ใบงาน: WO-00011251

ชนิดเครื่องมือ: Balance

รุ่น: PX623

หมายเลขเครื่อง: C236754745

ตรวจสอบ (รับ)		รายการตรวจเช็ค	ตรวจสอบ (ส่ง)		หมายเหตุ
ปกติ	ไม่ปกติ		07 Dec 2023	ปกติ	
		General			
☒	☐	1. สายไฟ/Adapter, power supply 220/110V	☒	☐	
☒	☐	2. ความสมบูรณ์ชุดกระดกกันลม (Cover)	☒	☐	
☒	☐	3. ความสมบูรณ์ชุดของระดับน้ำ	☒	☐	
☒	☐	4. การปรับระดับของขาตั้งเครื่อง	☒	☐	
☒	☐	5. การตอบสนองของปุ่มกด	☒	☐	
☒	☐	6. ความสมบูรณ์ของ Display	☒	☐	
☒	☐	7. การแสดงผลของ Display หลังวางน้ำหนัก	☒	☐	
☒	☐	8. ชุดรองจานชั่ง (Stopper) / pan support	☒	☐	
☒	☐	9. การทำงานของ Function Internal / External	☒	☐	
☒	☐	10. ความสะอาดของตัวเครื่องภายนอกและแผ่น load cell	☒	☐	
☒	☐	11. สภาวะแวดล้อม ณ สถานที่ตั้งเครื่อง	☒	☐	


หมายเหตุเพิ่มเติมเรื่องข้อแนะนำ :

Mr. Adisai Maknoi
Service Engineer

เอกสารไม่ควบคุม

บริษัท ดีเคเอส อีซี จำกัด
DKSH Technology Limited
2333 ถนนสุขุมวิท แขวงคลองเตย เขตคลองเตย กรุงเทพมหานคร 10110
2333 Sukhumvit Road, Bangkok, Thailand 10110
Phone: +66 2638 7000 Email: info.calibration@dksh.com Website: www.dksh.com/scientific-thailand
Delivering Growth - In Asia and Beyond.

ภาคผนวก ฉ
หนังสือขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์



ลำดับ	สารมลพิษ	วิธีวิเคราะห์
38	Phenols	1) Distillation, Chloroform Extraction Method ⁽³⁾ 2) Distillation, Direct Photometric Method ⁽³⁾
39	Selenium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽³⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽³⁾
40	Sulfide	1) Iodometric Method ⁽³⁾ 2) Methylene Blue Method ⁽³⁾
41	Temperature	Laboratory and Field Methods ⁽³⁾
42	Total Dissolved Solids	Dried at 180 °C ⁽³⁾
43	Total Kjeldahl Nitrogen	Semi-Micro-Kjeldahl Method ⁽³⁾
44	Total Suspended Solids	Dried from 103 to 105 °C ⁽³⁾
45	Trivalent Chromium	1) Digestion, Direct Air-Acetylene Flame Method; Colorimetric Method; Calculation ⁽³⁾ 2) Digestion, Inductively Coupled Plasma Method; Colorimetric Method; Calculation ⁽³⁾
46	Zinc	1) Digestion, Direct Air-Acetylene Flame Method ⁽³⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽³⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽³⁾

น้ำดื่ม จำนวน 126 รายการ

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
1	Acenaphthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
2	Acetone	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
3	Aldrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
4	Anthracene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾

5 Antimony...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
5	Antimony	Digestion, Inductively Coupled Plasma Method ⁽³⁾
6	Arsenic	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽³⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽³⁾
7	Atrazine	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
8	Barium	1) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽³⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽³⁾
9	Benz(a)anthracene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
10	Benzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
11	Benzo(b)fluoranthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
12	Benzo(k)fluoranthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
13	Benzoic acid	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
14	Benzo(a)pyrene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
15	Benzo(g,h,i)perylene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
16	Beryllium	Digestion, Inductively Coupled Plasma Method ⁽³⁾
17	Bis(2-chloroethyl)ether	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
18	Bis(2-ethylhexyl)phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾

19 Bromodichloromethane...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
19	Bromodichloromethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
20	Bromoform	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
21	Butanol	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
22	Butyl benzyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
23	Cadmium	1) Digestion, Direct Air-Acetylene Flame Method ⁽³⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽³⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽³⁾
24	Carbazole	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
25	Carbon disulfide	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
26	Carbon tetrachloride	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
27	Chlordane	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
28	p-Chloroaniline	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
29	Chlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
30	Chlorodichloromethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
31	Chloroform	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
32	2-Chlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
33	Chromium	1) Digestion, Direct Air-Acetylene Flame Method ⁽³⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽³⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽³⁾

34 Chromium (III)...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
34	Chromium (III)	1) Digestion, Direct Air-Acetylene Flame Method; Colorimetric Method; Calculation ⁽³⁾ 2) Digestion, Inductively Coupled Plasma Method; Colorimetric Method; Calculation ⁽³⁾
35	Chromium (VI)	1) Colorimetric Method ⁽³⁾ 2) Extraction, Air-Acetylene Flame Method ⁽³⁾
36	Chrysene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
37	Cyanide	Distillation, Colorimetric Method ⁽³⁾
38	2,4-D	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾
39	DDO	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
40	DDE	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
41	DDT	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
42	Dibenz(a,h)anthracene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽³⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
43	Di-n-butyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
44	1,2-Dichlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
45	1,3-Dichlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
46	1,4-Dichlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽³⁾
47	3,3'-Dichlorobenzidine	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽³⁾

48 1,1-Dichloroethane...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
48	1,1-Dichloroethane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
49	1,2-Dichloroethane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
50	1,1-Dichloroethylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
51	cis-1,2-Dichloroethylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
52	trans-1,2-Dichloroethylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
53	2,4-Dichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
54	1,2-Dichloropropane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
55	1,3-Dichloropropane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
56	1,3-Dichloropropene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
57	Dieldrin	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
58	Diethyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
59	2,4-Dimethylphenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
60	2,4-Dinitrophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
61	2,4-Dinitrotoluene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
62	2,6-Dinitrotoluene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
63	Di n Octyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
64	Endosulfan	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾

55 Endrin...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
65	Endrin	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
66	Ethylbenzene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
67	Fluoranthene	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
68	Fluorene	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
69	Heptachlor	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
70	Heptachlor epoxide	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
71	Hexachlorobenzene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
72	Hexachloro-1,3-butadiene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
73	n-Hexane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
74	α-HCH	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
75	β-HCH	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾

76 γ-HCH...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
76	γ-HCH	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
77	Hexachlorocyclopentadiene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
78	Hexachloroethane	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
79	Indeno(1,2,3-cd)pyrene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
80	Isophorone	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
81	Lead	1) Digestion, Direct Air-Acetylene Flame Method ⁽¹⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽¹⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽¹⁾
82	Manganese	1) Digestion, Direct Air-Acetylene Flame Method ⁽¹⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽¹⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽¹⁾
83	Mercury	Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ⁽¹⁾
84	Methanol	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
85	Methoxychlor	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽¹⁾
86	Methyl bromide	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
87	Methylene chloride	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
88	2-Methylphenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
89	2-Methylnaphthalene	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
90	Methyl tert-butyl ether	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾

91 Naphthalene...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
91	Naphthalene	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
92	Nickel	1) Digestion, Direct Air-Acetylene Flame Method ⁽¹⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽¹⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽¹⁾
93	Nitrobenzene	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
94	N-Nitrosodiphenylamine	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
95	N-Nitrosodi-n-propylamine	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
96	Polychlorinated Biphenyls - PCB 1016 - PCB 1221 - PCB 1232 - PCB-1242 - PCB-1248 - PCB-1254 - PCB-1260	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
97	Pentachlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
98	pH	Electrometric Method ⁽¹⁾
99	Phenanthrene	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
100	Phenol	1) Distillation, Chloroform Extraction Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾
101	Pyrene	1) Liquid-Liquid Extraction, Gas Chromatographic/ Method ⁽¹⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ⁽¹⁾

102 Selenium...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
102	Selenium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^{3,5} 2) Digestion, Inductively Coupled Plasma Method ^{3,1}
103	Silver	Digestion, Inductively Coupled Plasma Method ^{3,1}
104	Styrene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
105	1,1,2,2-Tetrachloroethane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
106	Tetrachloroethylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
107	Toluene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
108	Toxaphene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,1} 2) Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
109	TPH (C ₁ - C ₆)	1) Purge and Trap, Gas Chromatographic Method ^{3,1,2,3} 2) Purge and Trap, Gas Chromatographic/ Mass spectrometric Method ^{3,1,2,3}
110	TPH (C ₇ - C ₁₃)	Separatory Funnel Liquid-Liquid extraction, Gas Chromatographic Method ^{3,2,3}
111	TPH (C ₁₄ - C ₃₅)	Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,2,3}
112	1,2,4-Trichlorobenzene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
113	1,1,1-Trichloroethane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
114	1,1,2-Trichloroethane	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
115	Trichloromethylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
116	2,4,5-Trichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
117	2,4,6-Trichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
118	1,3,5 Trimethylbenzene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}

119 Vanadium...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
119	Vanadium	Digestion, inductively Coupled Plasma Method ^{3,1}
120	Vinyl acetate	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
121	Vinyl chloride	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
122	m-Xylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
123	o-Xylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
124	p-Xylene	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
125	Xylene (Total)	Purge and Trap Gas Chromatographic/ Mass Spectrometric Method ^{3,1}
126	Zinc	1) Digestion, Direct Air-Acetylene Flame Method ^{3,1} 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ^{3,1} 3) Digestion, Inductively Coupled Plasma Method ^{3,1}

สิ่งบ่งชี้หรือสัญลักษณ์ที่ใช้แล้ว จำนวน 35 รายการ

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
1	Aldrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
2	Antimony	Digestion, Inductively Coupled Plasma Method ^{3,1,2}
3	Arsenic	1) Waste Extraction, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^{3,1,1,1} 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,1,2} 3) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^{3,1,1} 4) Digestion, Inductively Coupled Plasma Method ^{3,1,2}
4	Barium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,1,1} 2) Digestion, Inductively Coupled Plasma Method ^{3,1,2}

5 Beryllium...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
5	Beryllium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,2} 2) Digestion, Inductively Coupled Plasma Method ^{3,1,2}
6	Cadmium	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^{3,1,1,1} 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,2} 3) Digestion, Flame Atomic Absorption Spectrometric Method ^{3,1,1} 4) Digestion, Inductively Coupled Plasma Method ^{3,1,2}
7	Chlordane	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
8	Chromium	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^{3,1,1,1} 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,2} 3) Digestion, Flame Atomic Absorption Spectrometric Method ^{3,1,1} 4) Digestion, Inductively Coupled Plasma Method ^{3,1,2}
9	Chromium (II)	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method; Waste Extraction, Colorimetric Method; Calculation ^{3,1,1,1,1} 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method; Waste Extraction, Colorimetric Method; Calculation ^{3,1,2,1,1} 3) Digestion, Flame Atomic Absorption Spectrometric Method; Alkaline Digestion, Colorimetric Method; Calculation ^{3,1,1,1,1} 4) Digestion, Inductively Coupled Plasma Method; Alkaline Digestion, Colorimetric Method; Calculation ^{3,1,1,1,1}
10	Chromium (VI)	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,2} 2) Alkaline Digestion, Colorimetric Method ^{3,1,1}
11	Cobalt	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,2} 2) Digestion, Inductively Coupled Plasma Method ^{3,1,2}

12 Copper...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
12	Copper	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^{3,1,1,1} 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^{3,1,2} 3) Digestion, Flame Atomic Absorption Spectrometric Method ^{3,1,1} 4) Digestion, Inductively Coupled Plasma Method ^{3,1,2}
13	2,4-D	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
14	DDD	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
15	DOE	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
16	DDT	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
17	Dieldrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
18	Endrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}
19	Heptachlor	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^{3,7,2,1} 2) Ultrasonic Extraction, Gas Chromatographic Method ^{3,2,1}

20 Lead...

ลำดับ	สารเคมี	วิธีวิเคราะห์
20	Lead	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(1,4,13) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(5,13) 4) Digestion, Inductively Coupled Plasma Method ^(5,12)
21	Lindane	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(1,7,21) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(8,21)
22	Mercury	1) Waste Extraction, Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ^(1,14) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 3) Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ^(1,17) 4) Digestion, Inductively Coupled Plasma Method ^(5,12) 5) Thermal Decomposition Amalgamation and Atomic Absorption Spectrometric Method ⁽¹⁸⁾
23	Methoxychlor	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(1,7,21) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(8,21)
24	Molybdenum	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 2) Digestion, Inductively Coupled Plasma Method ^(5,12)
25	Nickel	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(1,4,13) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(5,13) 4) Digestion, Inductively Coupled Plasma Method ^(5,12)

26 Polychlorinated Biphenyls...

ลำดับ	สารเคมี	วิธีวิเคราะห์
26	Polychlorinated Biphenyls - Aroclor 1016 - Aroclor 1221 - Aroclor 1232 - Aroclor 1242 - Aroclor 1248 - Aroclor 1254 - Aroclor 1260 - 2-Chlorobiphenyl - 2,3-Dichlorobiphenyl - 2,2',5-Trichlorobiphenyl - 2,4',5-Trichlorobiphenyl - 2,2',3,5'-Tetrachlorobiphenyl - 2,2',5,5'-Tetrachlorobiphenyl - 2,3',4,4'-Tetrachlorobiphenyl - 2,2',3,4,5'-Pentachlorobiphenyl - 2,2',4,5,5'-Pentachlorobiphenyl - 2,3,3',4',6-Pentachlorobiphenyl - 2,2',3,4,4',5'-Hexachlorobiphenyl - 2,2',3,4,5,5'-Hexachlorobiphenyl - 2,2',3,5,5',6-Hexachlorobiphenyl - 2,2',4,4',5,5'-Hexachlorobiphenyl - 2,2',3,3',4,4',5-Heptachlorobiphenyl - 2,2',3,4,4',5,5'-Heptachlorobiphenyl - 2,2',3,4,4',5,6-Heptachlorobiphenyl - 2,2',3,4',5,5',6-Heptachlorobiphenyl - 2,2',3,3',4,4',5,5',6-Nonachlorobiphenyl	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(1,2,21) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(8,21)



UNITED ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

ดำเนินการถูกต้อง

วิภา

27 Pentachlorophenol...

ลำดับ	สารเคมี	วิธีวิเคราะห์
27	Pentachlorophenol	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ^(1,7,24) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(8,24)
28	pH	Electrometric Method ^(25,26)
29	Selenium	1) Waste Extraction, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^(1,4,19) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 3) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^(5,19) 4) Digestion, Inductively Coupled Plasma Method ^(5,12)
30	Silver	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 2) Digestion, Inductively Coupled Plasma Method ^(5,12)
31	Thallium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 2) Digestion, Inductively Coupled Plasma Method ^(5,12)
32	Toxaphene	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(1,7,21) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(8,21)
33	Trichloroethylene	1) Waste Extraction, Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(1,10,23) 2) Waste Extraction, Equilibrium Headspace, Gas Chromatographic/Mass Spectrometric Method ^(1,9,23) 3) Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(1,1,23) 4) Equilibrium Headspace, Gas Chromatographic/Mass Spectrometric Method ^(9,23)
34	Vanadium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 2) Digestion, Inductively Coupled Plasma Method ^(5,12)

35 Zinc...

ลำดับ	สารเคมี	วิธีวิเคราะห์
35	Zinc	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(1,4,13) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(1,4,12) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(5,13) 4) Digestion, Inductively Coupled Plasma Method ^(5,12)

เอกสารอ้างอิง

- กระทรวงอุตสาหกรรม, ประกาศกระทรวงอุตสาหกรรม, พ.ศ. 2566. เรื่อง การจัดการสิ่งปฏิกูลหรือวัสดุที่ไม่ใช้แล้ว.ราชกิจจานุเบกษา. 31 พฤษภาคม 2566. เล่มที่ 140 ตอนพิเศษ 126 ง.
- สมาคมวิศวกรรมสิ่งแวดล้อมแห่งประเทศไทย. คู่มือวิเคราะห์น้ำเสีย. พิมพ์ครั้งที่ 4. กรุงเทพฯ: เรือนแก้วการพิมพ์, 2547.
- APHA, AWWA, WEF. Standard Methods for the Examination of Water and Wastewater. 24th ed. Washington, DC: APHA, 2023.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. SW-846, 2014.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Acid Digestion of Sediments, Sludges, and Soils. SW-846 Method 3050B, 1996.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Alkaline Digestion for Hexavalent Chromium. SW-846 Method 3060A, 1996.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Separatory Funnel Liquid-Liquid Extraction. SW-846 Method 3510C, 1996.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Ultrasonic Extraction. SW-846 Method 3550C, 2007.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Volatile Organic Compounds in Various Sample Matrices Using Equilibrium Headspace Analysis. SW-846 Method 5021A, 2014.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Purge and Trap for Aqueous Samples. SW-846 Method 5030C, 2003.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Closed System Purge and Trap and Extraction for Volatile Organics in Soil and Waste Sample. SW-846 Method 5035A, 2000.
- United States...

12. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Inductively Coupled Plasma-Optical Emission Spectrometry. SW-846 Method 6010D, 2014.

13. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Flame Atomic Absorption Spectrophotometry. SW-846 Method 7000B, 2007.

14. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Arsenic (Atomic Absorption, Gaseous Hydride). SW-846 Method 7061A, 1992.

15. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Chromium, Hexavalent (Colorimetric). SW-846 Method 7196A, 1992.

16. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Liquid Waste (Manual Cold Vapor Technique). SW-846 Method 7470A, 1994.

17. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Solid or Semisolid Waste (Manual Cold-Vapor Technique). SW-846 Method 7471B, 1998.

18. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Solids and Solutions by Thermal Decomposition, Amalgamation, and Atomic Absorption Spectrophotometry. SW-846 Method 7473, 2007.

19. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Selenium (Atomic Absorption, Borohydride Reduction). SW-846 Method 7742, 1994.

20. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Nonhalogenated Organics Using GC/FID. SW-846 Method 8015D, 2003.

21. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Organochlorine Pesticides by Gas Chromatography. SW-846 Method 8091B, 2007.

22. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Polychlorinated Biphenyls (PCBs) by Gas Chromatography. SW-846 Method 8082A, 2007.

23. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Volatile Organic Compounds by Gas Chromatography/Mass Spectrometry. SW-846 Method 8260D, 2018.

24. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Semivolatile Organic Compounds by Gas Chromatography/Mass Spectrometry. SW-846 Method 8270E, 2018.

25. United States...

25. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. pH Electrometric Measurement. SW-846 Method 9040C, 2004.

26. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Soil and Waste pH. SW-846 Method 9045D, 2004.



UAE
UNITED ANALYST AND ENGINEER
CONSULTANT COMPANY LIMITED

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบและประเมินผลปฏิบัติการ การวิเคราะห์ในห้องปฏิบัติการ กรมโรงงานอุตสาหกรรม โทร. ๐ ๒๓๓๐ ๒๓๓๑ ต่อ ๒๐๓๓-๔



ที่ อก ๐๓๓๐(๑) ๓ ๖ ๕ ๓ ๘

กรมโรงงานอุตสาหกรรม
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท
เขตราชเทวี กรุงเทพฯ ๑๐๑๐๐

๑๓ ธันวาคม ๒๕๖๖

เรื่อง เปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์

เรียน กรรมการผู้จัดการ บริษัท ยูโนเต็ด แอนาไลติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด

อ้างถึง คำขอขึ้นทะเบียน/ต่ออายุ/เปลี่ยนแปลงบุคลากร และขออนุญาตขอห้องปฏิบัติการวิเคราะห์เอกชน ลงวันที่ ๗ พฤศจิกายน ๒๕๖๖

ตามที่หนังสืออ้างอิง บริษัท ยูโนเต็ด แอนาไลติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด ขอปฏิบัติภารกิจวิเคราะห์เอกชน เลขทะเบียน ๖-๑๕๕ สถานที่ตั้งเลขที่ ๓ ซอยสุขุมสุข ๔๓ ถนนสุขุมวิท แขวงบางจาก เขตพระโขนง กรุงเทพมหานคร ขอเปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์ ความละเอียดแจ้งแล้ว นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว ให้เพิ่มเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๖ ราย ได้แก่

- | | |
|-------------------------------|----------------------------|
| ๑) นางสาวพรพิมล ประจักษ์ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๖ |
| ๒) นายวิฑูรย์ บุญญาธิ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๓ |
| ๓) นางสาวณัฐชา แวงภาพ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๔ |
| ๔) นายณัฐพล สุขย์ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๕ |
| ๕) นายสิทธิพล พร้อมพองขึ้นบุญ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๖ |
| ๖) นางสาวณัฏพร การงานดี | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๗ |

อนึ่ง หนังสือฉบับนี้จะหมดอายุพร้อมหนังสือต่ออายุขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน คือในวันที่ ๒ กุมภาพันธ์ ๒๕๖๘ ทั้งนี้ สามารถยื่นคำขอผ่านระบบอิเล็กทรอนิกส์ได้ทันหน้าเว็บไซต์ กรมโรงงานอุตสาหกรรม

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

(นายประสม คำทรงษ์)

ผู้อำนวยการกองวิจัยและพัฒนาและประเมินผลปฏิบัติการ กรมโรงงานอุตสาหกรรม



UAE
UNITED ANALYST AND ENGINEER
CONSULTANT COMPANY LIMITED

กองวิจัยและพัฒนาและประเมินผลปฏิบัติการ

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบและประเมินผลปฏิบัติการ

โทร. ๐ ๒๓๓๐ ๒๓๓๑ ต่อ ๒๐๓๓-๔

โทรสาร ๐ ๒๓๓๐ ๒๓๓๑ ต่อ ๒๐๓๔

ไปรษณีย์อิเล็กทรอนิกส์ saraband@uwc.co.th



"อุตสาหกรรมก้าวไกล ประเทศไทยก้าวหน้า ร่วมกันพัฒนา อุตสาหกรรมสีเขียว"



ที่ อก ๐๓๓๐(๑) ๘ ๗ ๒ ๕

กรมโรงงานอุตสาหกรรม
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท
เขตราชเทวี กรุงเทพฯ ๑๐๑๐๐

๒๕ พฤษภาคม ๒๕๖๖

เรื่อง เปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์

เรียน กรรมการผู้จัดการ บริษัท ยูโนเต็ด แอนาไลติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด

อ้างถึง คำขอขึ้นทะเบียน/ต่ออายุ/เปลี่ยนแปลงบุคลากร และขออนุญาตขอห้องปฏิบัติการวิเคราะห์เอกชน ลงวันที่ ๓๖ พฤษภาคม ๒๕๖๖

ตามที่หนังสืออ้างอิง บริษัท ยูโนเต็ด แอนาไลติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด ขอปฏิบัติภารกิจวิเคราะห์เอกชน เลขทะเบียน ๖-๑๕๕ สถานที่ตั้งเลขที่ ๓ ซอยสุขุมสุข ๔๓ ถนนสุขุมวิท แขวงบางจาก เขตพระโขนง กรุงเทพมหานคร ขอเปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์ ความละเอียดแจ้งแล้ว นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว มีความเห็นดังนี้

๑. โดยยกเลิกเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๕ ราย

- | | |
|-------------------------------|----------------------------|
| ๑) นางสาวพรพิมล ประจักษ์ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๖ |
| ๒) นายวิฑูรย์ บุญญาธิ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๓ |
| ๓) นางสาวณัฐชา แวงภาพ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๔ |
| ๔) นายณัฐพล สุขย์ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๕ |
| ๕) นางสาวสุพัตรา จันทร์ประทีป | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๖ |
| ๖) นางสาวณัฏพร การงานดี | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๗ |

๒. ให้เพิ่มเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๔ ราย

- | | |
|-------------------------|----------------------------|
| ๑) นางสาววิภา ฝ้ายสิงห์ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๓ |
| ๒) นางสาวณัฏพร การงานดี | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๔ |
| ๓) นางสาวณัฐชา แวงภาพ | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๕ |
| ๔) นางสาวณัฏพร การงานดี | ทะเบียนเลขที่ ๖-๑๕๕-๖-๐๑๕๖ |

อนึ่ง หนังสือฉบับนี้จะหมดอายุพร้อมหนังสือต่ออายุขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน คือในวันที่ ๒ กุมภาพันธ์ ๒๕๖๘ ทั้งนี้ สามารถยื่นคำขอผ่านระบบอิเล็กทรอนิกส์ได้ทันหน้าเว็บไซต์ กรมโรงงานอุตสาหกรรม

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

(นายประสม คำทรงษ์)

ผู้อำนวยการกองวิจัยและพัฒนาและประเมินผลปฏิบัติการ กรมโรงงานอุตสาหกรรม



UAE
UNITED ANALYST AND ENGINEER
CONSULTANT COMPANY LIMITED

กองวิจัยและพัฒนาและประเมินผลปฏิบัติการ

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบและประเมินผลปฏิบัติการ

โทร. ๐ ๒๓๓๐ ๒๓๓๑ ต่อ ๒๐๓๓-๔

โทรสาร ๐ ๒๓๓๐ ๒๓๓๑ ต่อ ๒๐๓๔

ไปรษณีย์อิเล็กทรอนิกส์ saraband@uwc.co.th



"อุตสาหกรรมก้าวไกล ประเทศไทยก้าวหน้า ร่วมกันพัฒนา อุตสาหกรรมสีเขียว"



ที่ อก ๐๓๑๐(๑)/ ๖ ๐ ๒ ๘



กรมโรงงานอุตสาหกรรม
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท
เขตราชเทวี กรุงเทพฯ ๑๐๕๐๐

๒ ๒ มีนาคม ๒๕๖๖

เรื่อง เปลี่ยนแปลงบุคลากรและสารมลพิษที่วิเคราะห์

เรียน กรรมการผู้จัดการ บริษัท ยูโนเด็ค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด

อ้างถึง คำขอขึ้นทะเบียน/ต่ออายุ/เปลี่ยนแปลงบุคลากร และขอสมัครสมาชิกของห้องปฏิบัติการวิเคราะห์เอกชน
ลงวันที่ ๓๐ มกราคม ๒๕๖๖

สิ่งที่ส่งมาด้วย เอกสารแนบท้ายหนังสือเปลี่ยนแปลงบุคลากรและสารมลพิษที่วิเคราะห์

บริษัท ยูโนเด็ค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด จำนวน ๒ แผ่น

ตามหนังสือที่อ้างถึง บริษัท ยูโนเด็ค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด
ห้องปฏิบัติการวิเคราะห์เอกชน เลขทะเบียน ๖-๑๔๕ สถานที่ยกเลิกที่ ๓ ขอออกเลข ๔๔ ถนนสุขุมวิท
แขวงบางจาก เขตพระโขนง กรุงเทพมหานคร ขอเปลี่ยนแปลงบุคลากรและสารมลพิษที่วิเคราะห์
ความละเอียดแล้ว ดังนี้

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว มีความเห็นดังนี้

๑. ให้อยู่ในอำนาจหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๒ ราย

๑) นายวิชาญ สุวรรณราช ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๐๓๖

๒) นายพิพัฒน์ คัมภีร์กุล ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๐๕๗

๒. ให้เพิ่มเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๑๑ ราย

๑) นางสาวอรุณ ประสานศรี ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๒

๒) นายณพต เนียมเนียม ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๓

๓) นายสุกรม สอนศรี ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๔

๔) นายณพต คลานนท์ ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๕

๕) นายรัชชชัย พูลใจวาทะ ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๖

๖) นายณวัฒน์ กลับบ้านเกาะ ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๗

๗) นายธีรวัฒน์ ธรรมสุวรรณ ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๘

๘) นายนิพนธ์พงศ์ ชะนุกิต ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๓๙

๙) นางสาวณัฐกานา พสนิกกิจ ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๔๐

๑๐) นางสาวชลภัทร ทองบุรณ์ ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๔๑

๑๑) นางสาวพริษา ขจรนันทิยาภรณ์ ทะเบียนเลขที่ ๖-๑๔๕-๖-๐๑๔๒

๓. ให้เพิ่มขอขยายสารมลพิษที่วิเคราะห์ในบัญชี ดังนี้



ดำเนินการถูกต้อง

อนึ่ง...

- ๒ -

อนึ่ง หนังสือฉบับนี้จะมีผลใช้บังคับเมื่อพ้นกำหนดสิบวันนับแต่วันพ้นจากอำนาจการปฏิบัติหน้าที่ของ
ที่ อก ๐๓๑๐(๑)/๖๐๒๘ ลงวันที่ ๒ กุมภาพันธ์ ๒๕๖๕ คือในวันที่ ๒ กุมภาพันธ์ ๒๕๖๕ ทั้งนี้ สามารถยื่นคำขอ
ผ่านระบบอิเล็กทรอนิกส์ได้ที่หน้าเว็บไซต์กรมโรงงานอุตสาหกรรม ตาม QR Code ที่แนบมาด้วย

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

สุรศักดิ์

(นายประจักษ์ คำวงศ์)
ผู้อำนวยการกองควบคุมมลพิษและสิ่งแวดล้อม
ปฏิบัติราชการแทนอธิบดีกรมโรงงานอุตสาหกรรม



ยื่นคำขอผ่านระบบอิเล็กทรอนิกส์

กองวิจัยและพัฒนาสิ่งแวดล้อม

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบและทะเบียนห้องปฏิบัติการ

โทร. ๐ ๒๔๓๐ ๖๓๑๒ ต่อ ๒๓๐๓-๕ โทรสาร ๐ ๒๔๓๐ ๖๓๑๒ ต่อ ๒๓๐๔

ไปรษณีย์อิเล็กทรอนิกส์ sarabang@dw.mail.go.th



ดำเนินการถูกต้อง



"อุตสาหกรรมก้าวไกล ประเทศไทยก้าวหน้า ร่วมกันพัฒนา อุตสาหกรรมสีเขียว"



เอกสารแนบท้ายหนังสือเปลี่ยนแปลงบุคลากรและสารมลพิษที่วิเคราะห์

บริษัท ยูโนเด็ค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด เลขทะเบียน ๖-๑๔๕

ที่ อก ๐๓๑๐(๑)/ ๖ ๐ ๒ ๘

ลงวันที่ ๒ ๒ มีนาคม ๒๕๖๖

ขอขยายสารมลพิษที่ได้รับขึ้นทะเบียนจากกรมโรงงานอุตสาหกรรม จำนวน ๑๖ รายการ

เดิม จำนวน ๑๖ รายการ

ลำดับที่	สารมลพิษ	วิธีวิเคราะห์
1	Benzene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
2	Carbon tetrachloride	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
3	1,2-Dichloroethane	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
4	1,1-Dichloroethylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
5	cis-1,2-Dichloroethylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
6	trans-1,2-Dichloroethylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
7	Ethylbenzene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
8	Methylene chloride	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
9	Styrene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
10	Tetrachloroethylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
11	Toluene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
12	Trichloroethylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
13	m-Xylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
14	o-Xylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
15	p-Xylene	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)
16	Xylene (Total)	Equilibrium Headspace, Gas Chromatographic/ Mass Spectrometric Method ^(1,2)

เอกสารอ้างอิง...

- ๒ -

เอกสารอ้างอิง

1. United States Environmental Protection Agency, Test Methods for Evaluation Solid
Waste Physical/Chemical Methods. Volatile Organic Compounds in Various Sample Matrices
Using Equilibrium Headspace Analysis. SW-846 Method 5021A, 2014.

2. United States Environmental Protection Agency, Test Methods for Evaluation Solid
Waste Physical/Chemical Methods. Volatile Organic Compounds by Gas Chromatography/
Mass Spectrometry. SW-846 Method 8260D, 2018. 



ดำเนินการถูกต้อง

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบและทะเบียนห้องปฏิบัติการ กองวิจัยและพัฒนาสิ่งแวดล้อม กรมโรงงานอุตสาหกรรม โทร. ๐ ๒๔๓๐ ๖๓๑๒ ต่อ ๒๓๐๓-๕

ที่ อก ๐๑๐๐(๑)/ ๑๕๕๕ ๕๕



กรมโรงงานอุตสาหกรรม
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท
เขตราชเทวี กรุงเทพฯ ๑๐๕๐๐

๒๕ ตุลาคม ๒๕๖๕

เรื่อง เปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์

เรียน กรรมการผู้จัดการ บริษัท ยูโนเด็ค แอแนลลิติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด

อ้างถึง คำขอขึ้นทะเบียนต่ออายุ/เปลี่ยนแปลงบุคลากร และชนิดสารเคมีของห้องปฏิบัติการวิเคราะห์เอกชน
ลงวันที่ ๑๘ ตุลาคม ๒๕๖๕

ตามหนังสือที่อ้างถึง บริษัท ยูโนเด็ค แอแนลลิติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด
ห้องปฏิบัติการวิเคราะห์เอกชน เลขทะเบียน ๖-๑๕๕๕ สถานที่ตั้งเลขที่ ๓ ซอยสุขุมวิท ๕๑ ถนนสุขุมวิท แขวงบางจาก
เขตพระโขนง กรุงเทพมหานคร ขอเปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์ ความละเอียดแจ้งแล้ว นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว มีความเห็นดังนี้

๑. ให้ออกเลิกเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๔ ราย

- | | |
|---|-----------------------------|
| ๑) นายสุธรรม นกขี้นอก | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๒ |
| ๒) นายกนกพงศ์ บุญทอง | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๓ |
| ๓) นายกฤตพล พงศ์สถาพร | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๔ |
| ๔) นางสาววิมลลักษณ์ อินใจดีกาญจนการ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๕ |
| ๕. ให้เพิ่มผู้ควบคุมดูแลห้องปฏิบัติการวิเคราะห์ จำนวน ๖ ราย | |
| ๑) นายกนกพงศ์ บุญทอง | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๖ |
| ๒) นายสุธรรม นกขี้นอก | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๗ |
| ๓. ให้เพิ่มเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๑๒ ราย | |
| ๑) นายชินวัฒน์ หอยสิงห์ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๘ |
| ๒) นายประจักษ์ แก้วกาคี | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๖๙ |
| ๓) นายศักดิ์สิทธิ์ มุสิกสุ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๐ |
| ๔) นายศุภณันท์ อุไรจินดาพันธ์ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๑ |
| ๕) นายชาญณรงค์ อัสสยะ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๒ |
| ๖) นางสาวจิตราพร ศรีวรรณ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๓ |
| ๗) นายสุจิตต์ โพธิ์เงิน | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๔ |
| ๘) นายเจษฎา ชัยศิริ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๕ |
| ๙) นายระพีกร เหมะอิน | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๖ |
| ๑๐) นายสุวิทย์ รุ่งเรือง | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๗ |
| ๑๑) นายสุวิทย์ หล้าใจ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๘ |
| ๑๒) นายชัย บัวสกล | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๙ |

UAE
UPTON ANALYST AND CONSULTING
CONSULTANT COMPANY LIMITED

ดำเนินการถูกต้อง

อนึ่ง หนังสือฉบับนี้

- ๒ -

อนึ่ง หนังสือฉบับนี้จะมีผลใช้บังคับเมื่อพ้นกำหนดสิบห้าวันนับจากวันที่ออก
ที่ อก ๐๑๐๐(๑)/๑๕๕๕๕ ลงวันที่ ๕ กุมภาพันธ์ ๒๕๖๕ คือในวันที่ ๒ กุมภาพันธ์ ๒๕๖๕ ทั้งนี้ สามารถยื่นคำขอ
ผ่านระบบอิเล็กทรอนิกส์ได้ที่เว็บไซต์กรมโรงงานอุตสาหกรรม ตาม QR Codeท้ายหนังสือฉบับนี้

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

๕๕๕๕ ๕๕๕๕

(นายประสม คำรณพงษ์)
ผู้อำนวยการกองวิจัยและเตือนภัยมลพิษโรงงาน
ปฏิบัติการกรมอนามัยกรมโรงงานอุตสาหกรรม



ยื่นคำขอผ่านระบบอิเล็กทรอนิกส์

กองวิจัยและเตือนภัยมลพิษโรงงาน
กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษและทะเบียนห้องปฏิบัติการ
โทร. ๐ ๒๕๓๐ ๖๓๒๖ ต่อ ๒๐๐๐-๕
โทรสาร ๐ ๒๕๓๐ ๖๓๒๖ ต่อ ๒๐๐๐-๕
ไปรษณีย์อิเล็กทรอนิกส์ saraban@dw.mail.go.th

UAE
UPTON ANALYST AND CONSULTING
CONSULTANT COMPANY LIMITED

ดำเนินการถูกต้อง



"อุตสาหกรรมก้าวไกล ประเทศไทยก้าวหน้า ร่วมกันพัฒนา อุตสาหกรรมสีเขียว"



ที่ อก ๐๑๐๐(๑)/ ๑๖๕๕ ๕๕



กรมโรงงานอุตสาหกรรม
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท
เขตราชเทวี กรุงเทพฯ ๑๐๕๐๐

๑๑ กันยายน ๒๕๖๕

เรื่อง เปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์

เรียน กรรมการผู้จัดการ บริษัท ยูโนเด็ค แอแนลลิติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด

อ้างถึง คำขอขึ้นทะเบียนต่ออายุ/เปลี่ยนแปลงบุคลากร และชนิดสารเคมีของห้องปฏิบัติการวิเคราะห์เอกชน
ลงวันที่ ๒๖ สิงหาคม ๒๕๖๕

ตามหนังสือที่อ้างถึง บริษัท ยูโนเด็ค แอแนลลิติกส์ แอนด์ เอ็นจิเนียริ่ง คอนซัลแตนท์ จำกัด
ห้องปฏิบัติการวิเคราะห์เอกชน เลขทะเบียน ๖-๑๕๕๕ สถานที่ตั้งเลขที่ ๓ ซอยสุขุมวิท ๕๑ ถนนสุขุมวิท แขวงบางจาก
เขตพระโขนง กรุงเทพมหานคร ขอเปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์ ความละเอียดแจ้งแล้ว นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว มีความเห็นดังนี้

๑. ให้ออกเลิกเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๘ ราย

- | | |
|---|-----------------------------|
| ๑) นายปริทา ไขยมุสิกกุล | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๓ |
| ๒) นายปิยะพันธุ์ ศรีอุไรเจริญ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๔ |
| ๓) นายธีรเมธ สุทธิ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๕ |
| ๔) นางสาวศิริวรรณ ขอนหา | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๖ |
| ๕) นายศักดิ์สิทธิ์ เกียรติ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๗ |
| ๖) นางสาวลัดดาวัลย์ โพธิ์เงิน | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๘ |
| ๗) นางสาวกมลวรรณ เจริญพันธ์ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๗๙ |
| ๘) นางสาวจันทร์จิรา ประกอบทรัพย์ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๐ |
| ๒. ให้เพิ่มเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๑๓ ราย | |
| ๑) นางสาวมาลาสาธิต แหวงใบเมือง | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๑ |
| ๒) นางสาวพิมพ์พรรณ สิมมา | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๒ |
| ๓) นายบัณฑิตพันธ์ วงศ์คำ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๓ |
| ๔) นายประพันธ์พันธ์ เมื่อนาม | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๔ |
| ๕) นางสาวศุภมาส สุทธิ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๕ |
| ๖) นางสาวภาณุพร ชื่นนุกุล | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๖ |
| ๗) นางสาวบุญญา มอญคุณ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๗ |
| ๘) นายอมรพล อรรถลักษณ์ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๘ |
| ๙) นางสาวศิริพร ทองขาว | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๘๙ |
| ๑๐) นางสาวณิชากร ศุภชาติ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๙๐ |
| ๑๑) นางสาววิมลวรรณ คำ | ทะเบียนเลขที่ ๖-๑๕๕๕-๖-๐๐๙๑ |

UAE
UPTON ANALYST AND CONSULTING
CONSULTANT COMPANY LIMITED

ดำเนินการถูกต้อง

อนึ่ง หนังสือฉบับนี้

- ๒ -

อนึ่ง หนังสือฉบับนี้จะมีผลใช้บังคับเมื่อพ้นกำหนดสิบห้าวันนับจากวันที่ออก
ที่ อก ๐๑๐๐(๑)/๑๕๕๕๕ ลงวันที่ ๕ กุมภาพันธ์ ๒๕๖๕ คือในวันที่ ๒ กุมภาพันธ์ ๒๕๖๕ ทั้งนี้ สามารถยื่นคำขอ
ผ่านระบบอิเล็กทรอนิกส์ได้ที่เว็บไซต์กรมโรงงานอุตสาหกรรม ตาม QR Codeท้ายหนังสือฉบับนี้

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

๕๕๕๕ ๕๕๕๕

(นางจินดา นาคะศรี)

ผู้อำนวยการกองวิจัยและเตือนภัยมลพิษโรงงาน

ปฏิบัติการกรมอนามัยกรมโรงงานอุตสาหกรรม



ยื่นคำขอผ่านระบบอิเล็กทรอนิกส์

กองวิจัยและเตือนภัยมลพิษโรงงาน
กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบมลพิษและทะเบียนห้องปฏิบัติการ
โทร. ๐ ๒๕๓๐ ๖๓๒๖ ต่อ ๒๐๐๐-๕
โทรสาร ๐ ๒๕๓๐ ๖๓๒๖ ต่อ ๒๐๐๐-๕
ไปรษณีย์อิเล็กทรอนิกส์ saraban@dw.mail.go.th

UAE
UPTON ANALYST AND CONSULTING
CONSULTANT COMPANY LIMITED

ดำเนินการถูกต้อง



"อุตสาหกรรมก้าวไกล ประเทศไทยก้าวหน้า ร่วมกันพัฒนา อุตสาหกรรมสีเขียว"



ที่ อก ๐๓๑๐(๑)/ ๔๘๗ ๘ ๗



กรมโรงงานอุตสาหกรรม
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท
เขตราชเทวี กรุงเทพฯ ๑๐๖๐๐

๒๑ เมษายน ๒๕๖๕

เรื่อง เปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์

เรียน กรรมการผู้จัดการ บริษัท ยูนิค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด

อ้างถึง คำขอในทะเบียน/ต่ออายุ/เปลี่ยนแปลงบุคลากร และขอใบสามารถผลิตของห้องปฏิบัติการวิเคราะห์เอกชน
ลงวันที่ ๓๐ มีนาคม ๒๕๖๕

ตามที่สำนักงานคณะกรรมการอาหารและยา (ป.ร.) ได้แจ้งให้บริษัท ยูนิค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด
ห้องปฏิบัติการวิเคราะห์เอกชน เลขทะเบียน ๖-๑๕๕๕ สถานที่ตั้งเลขที่ ๔ ซอยอุดมสุข ถนนสุขุมวิท แขวงบางจาก
เขตพระโขนง กรุงเทพมหานคร ขอเปลี่ยนแปลงบุคลากรของห้องปฏิบัติการวิเคราะห์ ความละเอียดแจ้งแล้ว นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว มีความเห็นดังนี้

๑. ให้ยกเลิกผู้ควบคุมห้องปฏิบัติการวิเคราะห์ จำนวน ๒ ราย

๑) นางมานิตา แยมไย ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๕

๒) นางสาวกมลวรรณ คงคำ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๒

๒. ให้ยกเลิกเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๒ ราย

๑) นางสาวศิริพร อภิการรัตน์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๖

๒) นางสาวพรนันทา กิ่งนุ่น ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๔

๓. ให้เพิ่มเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๒ ราย

๑) นางสาวอัญญลักษณ์ ธนโชติกาอุณาการ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๗

๒) นางสาวจันทร์จิรา ประกอบทรัพย์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๘

ทั้งนี้ หนังสือฉบับนี้จะหมดอายุพร้อมหนังสือต่ออายุขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน
ที่ อก ๐๓๑๐(๑)/๑๕๕๕๕ ลงวันที่ ๔ กุมภาพันธ์ ๒๕๖๕ คือในวันที่ ๒ กุมภาพันธ์ ๒๕๖๕ ทั้งนี้ สามารถยื่นคำขอ
ผ่านระบบอิเล็กทรอนิกส์ได้ทั้งนี้ผ่านเว็บไซต์กรมโรงงานอุตสาหกรรม ตาม QR Code ที่แนบมาเพื่อสืบค้น

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

(นางจินดา เศรษฐินทวี)
ผู้อำนวยการกองวิเคราะห์และทะเบียนโรงงาน
ปฎิบัติราชการแทนอธิบดีกรมโรงงานอุตสาหกรรม



ยื่นคำขอผ่านระบบอิเล็กทรอนิกส์

กองวิจัยและพัฒนาด้านเคมีของโรงงาน

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบผลิตภัณฑ์และทะเบียนห้องปฏิบัติการ
โทร. ๐ ๒๕๑๐ ๖๓๖๒ ต่อ ๒๐๓๑-๕ โทรสาร ๐ ๒๕๑๐ ๖๓๖๒ ต่อ ๒๐๓๑-๕
ไปรษณีย์อิเล็กทรอนิกส์ sarabangdiv@mail.go.th

ดำเนินการถูกต้อง



"อุตสาหกรรมก้าวหน้า ประเทศไทยก้าวหน้า ร่วมกันพัฒนา อุตสาหกรรมสีเขียว"



ที่ อก ๐๓๑๐(๑)/ ๔๘๗ ๘ ๗



กรมโรงงานอุตสาหกรรม
ถนนพระรามที่ ๖ แขวงทุ่งพญาไท
เขตราชเทวี กรุงเทพฯ ๑๐๖๐๐

๑๙ กุมภาพันธ์ ๒๕๖๕

เรื่อง ต่ออายุหนังสือขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน

เรียน กรรมการผู้จัดการ บริษัท ยูนิค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด

อ้างถึง คำขอขึ้นทะเบียน/ต่ออายุ/เปลี่ยนแปลงบุคลากร และขอใบสามารถผลิตของห้องปฏิบัติการวิเคราะห์เอกชน
ลงวันที่ ๒๗ ธันวาคม ๒๕๖๔

สิ่งที่ส่งมาด้วย ๑. รายชื่อผู้ควบคุมห้องปฏิบัติการวิเคราะห์ จำนวน ๔๐ ราย

๒. รายชื่อเจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๑๐๖ ราย

๓. ขอบข่ายสามารถผลิตที่ได้รับขึ้นทะเบียนจากกรมโรงงานอุตสาหกรรม

ตามที่หนังสืออ้างอิง บริษัท ยูนิค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด
ขอต่ออายุหนังสือขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน เลขทะเบียน ๖-๑๕๕๕ สถานที่ตั้งเลขที่ ๓
ซอยอุดมสุข ๔๔ ถนนสุขุมวิท แขวงบางจาก เขตพระโขนง กรุงเทพมหานคร ต่อกรมโรงงานอุตสาหกรรม นั้น

กรมโรงงานอุตสาหกรรมพิจารณาแล้ว ให้บริษัท ยูนิค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง
คอนซัลแตนท์ จำกัด ต่ออายุหนังสือขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน โดยไม่ต้องประกอบดังนี้

ก. ผู้ควบคุมห้องปฏิบัติการวิเคราะห์ จำนวน ๔๐ ราย ตามสิ่งที่ส่งมาด้วย ๑

ข. เจ้าหน้าที่ประจำห้องปฏิบัติการวิเคราะห์ จำนวน ๑๐๖ ราย ตามสิ่งที่ส่งมาด้วย ๒

ค. ขอบข่ายสามารถผลิตที่ได้รับขึ้นทะเบียนให้วิเคราะห์ในน้ำเสีย น้ำใต้ดิน อากาศเสีย สิ่งปฏิกูล

หรือวัสดุที่ไม่ใช่แล้ว และดิน ตามสิ่งที่ส่งมาด้วย ๓

หนังสือฉบับนี้จะหมดอายุในวันที่ ๒ กุมภาพันธ์ ๒๕๖๕ หากประสงค์จะต่ออายุหนังสือ

ขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน ให้ยื่นคำขอต่ออายุพร้อมเอกสารประกอบคำขอต่อ

กรมโรงงานอุตสาหกรรมภายใน ๓๐ วัน ก่อนวันสิ้นสุดของหนังสือขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน
ทั้งนี้ สามารถยื่นคำขอผ่านระบบอิเล็กทรอนิกส์ได้ทั้งนี้ผ่านเว็บไซต์กรมโรงงานอุตสาหกรรม ตาม QR Code ที่แนบมาเพื่อสืบค้น

จึงเรียนมาเพื่อทราบ

ขอแสดงความนับถือ

(นางจินดา เศรษฐินทวี)
ผู้อำนวยการกองวิเคราะห์และทะเบียนโรงงาน
ปฎิบัติราชการแทนอธิบดีกรมโรงงานอุตสาหกรรม



ดำเนินการถูกต้อง

กองวิจัยและพัฒนาด้านเคมีของโรงงาน

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบผลิตภัณฑ์และทะเบียนห้องปฏิบัติการ

โทร. ๐ ๒๕๑๐ ๖๓๖๒ ต่อ ๒๐๓๑-๕ โทรสาร ๐ ๒๕๑๐ ๖๓๖๒ ต่อ ๒๐๓๑-๕

ไปรษณีย์อิเล็กทรอนิกส์ sarabangdiv@mail.go.th

สิ่งที่ส่งมาด้วย ๑

เอกสารแนบท้ายหนังสือรับต่ออายุขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน

บริษัท ยูนิค แอนาไลติกส์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด เลขทะเบียน ๖-๑๕๕

ที่ อก ๐๓๑๐(๑)/ ๔๘๗ ๘ ๗ ลงวันที่ ๑๙ กุมภาพันธ์ ๒๕๖๕

ก. ผู้ควบคุมห้องปฏิบัติการวิเคราะห์ จำนวน ๔๐ ราย

๑) นางสาวกมลวรรณ อภิการรัตน์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๖

๒) นายณรงค์ จันทา ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๖

๓) นางสาวนันทิชา บุญไชย ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๓

๔) นางปิยะพัชร สุทธอนันต์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๔

๕) นางมานิตา แยมไย ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๕

๖) นางสาวกมลวรรณ วิริยะกุล ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๖

๗) นายณพรัตน์ วงศ์อนุรักษชัย ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๗

๘) นางสาวอริยวรรณ บุญลา ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๘

๙) นายสุวิทย์ ออคนอก ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๐๙

๑๐) นางสาวจิตติกา สมบูรณ์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๐

๑๑) นางสาวบุษกร เลิศกาญจนา ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๑

๑๒) นางสาววิไลลักษณ์ ศรีสุข ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๒

๑๓) นางสาวปวีณา จรัสโชติพิณ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๓

๑๔) นายศิลา บรรจงใจรักษ์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๔

๑๕) นายปฏิกรณ์ คณะนา ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๕

๑๖) นายธีรวัฒน์ ชนกัน ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๖

๑๗) นางสาวศิริพร ศรีประคิษฐ์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๗

๑๘) นางสาวสิริวิภา ธีระ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๘

๑๙) นางสาวกมลวรรณ อภิการรัตน์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๑๙

๒๐) นายภูษิต พานิชย์เลิศอำไพ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๐

๒๑) นายณัฐวัฒน์ เสงส์รัตน์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๑

๒๒) นายเอกรัตน์ ปะคะนิพนธ์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๒

๒๓) นางสาวนันทิชา ศรีสุภาภรณ์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๓

๒๔) นางสาวเจตจิราพร ทัตตะอาด ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๔

๒๕) นางสาวสุวรรณา คงทอง ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๕

๒๖) นางสาววรรณ พัดทองชื่น ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๖

๒๗) นายวิรัช ไกแก้ว ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๗

๒๘) นายวิรัช เทพนครี ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๘

๒๙) นายอนุชาณ์ สว่าง ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๒๙

๓๐) นายกรวิทย์ เขียวศรีสุกุล ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๓๐

๓๑) นางสาวอริยา รังสวัสดิ์ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๓๑

๓๒) นางสาวกมลวรรณ คงคำ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๓๒

๓๓) นายสุวิทย์ ออคนอก ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๓๓

๓๔) นางสาวทัศนีย์ อ่อนคำ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๓๔

๓๕) นางสาวพริ้งพรรณ ตันประเสริฐ ทะเบียนเลขที่ ๖-๑๕๕๕-๕-๐๐๓๕



ดำเนินการถูกต้อง

กองวิจัยและพัฒนาด้านเคมีของโรงงาน

กลุ่มมาตรฐานวิธีการวิเคราะห์ทดสอบผลิตภัณฑ์และทะเบียนห้องปฏิบัติการ

โทร. ๐ ๒๕๑๐ ๖๓๖๒ ต่อ ๒๐๓๑-๕ โทรสาร ๐ ๒๕๑๐ ๖๓๖๒ ต่อ ๒๐๓๑-๕

ไปรษณีย์อิเล็กทรอนิกส์ sarabangdiv@mail.go.th

(นางจินดา เศรษฐินทวี)
ผู้อำนวยการกองวิเคราะห์และทะเบียนโรงงาน
ปฎิบัติราชการแทนอธิบดีกรมโรงงานอุตสาหกรรม

๓๖) นายภูษิต...

เอกสารแนบท้ายหนังสือรับคําสั่งขึ้นทะเบียนห้องปฏิบัติการวิเคราะห์เอกชน
บริษัท ยูนิเคิล แอแนลิติกส์ แอนด์ เอ็นจิเนียริง คอร์ปอเรชั่น จำกัด เลขทะเบียน ๖-๑๕๕
ที่ อก ๐๓๑๐(๑)/ ๑๘๗ ๕ ลงวันที่ ๑๔ กุมภาพันธ์ ๒๕๖๕
ขอขยายสารมลพิษที่ได้รับขึ้นทะเบียนจากกรมโรงงานอุตสาหกรรม จำนวน ๑๕๗ รายการ

น้ำเสีย จำนวน 4๕ รายการ

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
1	Aldrin	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
2	Arsenic	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽⁴⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾ Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
3	Barium	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
4	α-BHC	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
5	β-BHC	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
6	δ-BHC	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
7	γ-BHC	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
8	Biochemical Oxygen Demand	1) 5-Day BOD Test, Azide Modification Method ⁽⁴⁾ 2) 5-Day BOD Test, Membrane Electrode Method ⁽⁴⁾
9	Cadmium	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
10	Chemical Oxygen Demand	1) Closed Reflux, Titrimetric Method ⁽⁴⁾ 2) Closed Reflux, Colorimetric Method ⁽⁴⁾ 3) Open Reflux, Titrimetric Method ⁽⁴⁾
11	Chlordane	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
12	Chromium	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
13	Color	ADMI Weighted-Ordinate Spectrophotometric Method ⁽⁴⁾
14	Copper	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
15	Cyanide	1) Distillation, Potentiometric Method ⁽⁴⁾ 2) Flow Injection Analysis Method ⁽⁴⁾

16 o,p'-DDT...

-๒-

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
16	o,p'-DDT	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
17	4,4'-DDD	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
18	4,4'-DDE	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
19	4,4'-DDT	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
20	Dieldrin	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
21	Endosulfan I	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
22	Endosulfan II	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
23	Endosulfan sulfate	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
24	Endrin	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
25	Endrin aldehyde	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
26	Formaldehyde	Distillation, Colorimetric Method ⁽⁴⁾
27	Free Chlorine	1) Iodometric Method ⁽⁴⁾ 2) DPD Ferrous Titrimetric Method ⁽⁴⁾
28	Heptachlor	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
29	Heptachlor Epoxide	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
30	Hexavalent Chromium	1) Colorimetric Method ⁽⁴⁾ 2) Extraction, Direct Air-Acetylene Flame Method ⁽⁴⁾
31	Lead	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
32	Manganese	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
33	Mercury	Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ⁽⁴⁾
34	Methoxychlor	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
35	Nickel	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾

36 Oil & Grease...

-๓-

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
36	Oil & Grease	1) Liquid-Liquid, Partition-Gravimetric Method ⁽⁴⁾ 2) Soxhlet Extraction Method ⁽⁴⁾
37	pH	Electrometric Method ⁽⁴⁾
38	Phenols	1) Distillation, Chloroform Extraction Method ⁽⁴⁾ 2) Distillation, Direct Photometric Method ⁽⁴⁾
39	Selenium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽⁴⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
40	Sulfide	1) Iodometric Method ⁽⁴⁾ 2) Methylene Blue Method ⁽⁴⁾
41	Temperature	Laboratory and Field Methods ⁽⁴⁾
42	Total Dissolved Solids	Dried at 180 °C ⁽⁴⁾
43	Total Kjeldahl Nitrogen	Semi-Micro-Kjeldahl Method ⁽⁴⁾
44	Total Suspended Solids	Dried at 103-105 °C ⁽⁴⁾
45	Trivalent Chromium	1) Digestion, Direct Air-Acetylene Flame Method; Colorimetric Method; Calculation ⁽⁴⁾ 2) Digestion, Inductively Coupled Plasma Method; Colorimetric Method; Calculation ⁽⁴⁾
46	Zinc	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾

น้ำดื่ม จำนวน 126 รายการ

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
1	Acenaphthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
2	Acetone	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
3	Aldrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾

4 Anthracene...

-๔-

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
4	Anthracene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
5	Antimony	Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
6	Arsenic	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽⁴⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
7	Atrazine	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
8	Barium	1) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
9	Benz(a)anthracene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
10	Benzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
11	Benzo(b)fluoranthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
12	Benzo(k)fluoranthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
13	Benzoic acid	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
14	Benzo(a)pyrene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾

15 Benzo(g,h,i)perylene...

ลำดับ	สารเคมี	วิธีวิเคราะห์
15	Benzofluoranthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
16	Beryllium	Digestion, Inductively Coupled Plasma Method ⁽³⁾
17	Bis(2-chloroethyl)ether	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁵⁾
18	Bis(2-ethylhexyl)phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁵⁾
19	Bromodichloromethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
20	Bromoform	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
21	Butanol	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
22	Butyl benzyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁵⁾
23	Cadmium	1) Digestion, Direct Air-Acetylene Flame Method ⁽¹⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽²⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽³⁾
24	Carbazole	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
25	Carbon disulfide	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
26	Carbon tetrachloride	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
27	Chlordane	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
28	p-Chloroaniline	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
29	Chlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾

30 Chlorodibromomethane...

ลำดับ	สารเคมี	วิธีวิเคราะห์
30	Chlorodibromomethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
31	Chloroform	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
32	2-Chlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
33	Chromium	1) Digestion, Direct Air-Acetylene Flame Method ⁽¹⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽²⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽³⁾
34	Chromium (III)	1) Digestion, Direct Air-Acetylene Flame Method; Colorimetric Method; Calculation ⁽⁴⁾ 2) Digestion, Inductively Coupled Plasma Method; Colorimetric Method; Calculation ⁽⁴⁾
35	Chromium (VI)	1) Colorimetric Method ⁽⁴⁾ 2) Extraction, Air Acetylene Flame Method ⁽⁴⁾
36	Chrysene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
37	Cyanide	Distillation, Colorimetric Method ⁽⁴⁾
38	2,4-D	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾
39	DDD	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
40	DDE	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
41	DDT	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾

42 Dibenz(a,h)anthracene...

ลำดับ	สารเคมี	วิธีวิเคราะห์
42	Dibenz(a,h)anthracene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
43	Di-n-butyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
44	1,2-Dichlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
45	1,3-Dichlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
46	1,4-Dichlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
47	3,3'-Dichlorobenzidine	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
48	1,1-Dichloroethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
49	1,2-Dichloroethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
50	1,1-Dichloroethylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
51	1,1,2-Dichloroethylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
52	trans-1,2-Dichloroethylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
53	2,4-Dichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
54	1,2-Dichloropropane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
55	1,3-Dichloropropane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
56	1,3-Dichloropropane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
57	Dieldrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾

58 Diethyl phthalate...

ลำดับ	สารเคมี	วิธีวิเคราะห์
58	Diethyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
59	2,4-Dimethylphenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
60	2,4-Dinitrophenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
61	2,4-Dinitrotoluene	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
62	2,6-Dinitrotoluene	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
63	Di-n-Octyl phthalate	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
64	Endosulfan	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
65	Endrin	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
66	Ethylbenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
67	Fluoranthene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
68	Fluorene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾
69	Heptachlor	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁵⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁶⁾

70 Heptachlor epoxide...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
70	Heptachlor epoxide	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
71	Hexachlorobenzene	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
72	Hexachloro-1,3-butadiene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
73	n-Hexane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
74	α-HCH	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
75	β-HCH	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
76	γ-HCH	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
77	Hexachlorocyclopentadiene	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
78	Hexachloroethane	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
79	Indeno(1,2,3-cd)pyrene	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
80	Isophorone	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
81	Lead	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾

UPT-ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

ดำเนินการโดย

82 Manganese...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
82	Manganese	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
83	Mercury	Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ⁽⁴⁾
84	Methanol	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
85	Methoxychlor	Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾
86	Methyl bromide	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
87	Methylene chloride	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
88	2-Methylphenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
89	2-Methylnaphthalene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
90	Methyl tert-butyl ether	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
91	Naphthalene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
92	Nickel	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁴⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
93	Nitrobenzene	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
94	N-Nitrosodiphenylamine	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
95	N-Nitrosodi-n-propylamine	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾

UPT-ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

ดำเนินการโดย

96 Polychlorinated Biphenyls...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
96	Polychlorinated Biphenyls - PCB 1016 - PCB 1221 - PCB 1232 - PCB 1242 - PCB 1248 - PCB 1254 - PCB 1260	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
97	Pentachlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
98	pH	Electrometric Method ⁽⁴⁾
99	Phenanthrene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
100	Phenol	1) Distillation, Chloroform Extraction Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
101	Pyrene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
102	Selenium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽⁴⁾ 2) Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
103	Silver	Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
104	Styrene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
105	1,1,2,2-Tetrachloroethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
106	Tetrachloroethylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
107	Toluene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾

UPT-ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

ดำเนินการโดย

108 Toxaphene...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
108	Toxaphene	1) Liquid-Liquid Extraction, Gas Chromatographic Method ⁽⁴⁾ 2) Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
109	TFH (C ₈ - C ₉)	1) Purge and Trap, Gas Chromatographic Method ^(11,12) 2) Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(11,12)
110	TPH (C ₈ - C ₁₀)	Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(12,2)
111	TPH (C ₁₀ - C ₁₂)	Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(12,2)
112	1,2,4-Trichlorobenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
113	1,1,1-Trichloroethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
114	1,1,2-Trichloroethane	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
115	Trichloroethylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
116	2,4,5-Trichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
117	2,4,6-Trichlorophenol	Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
118	1,3,5-Trimethylbenzene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
119	Vanadium	Digestion, Inductively Coupled Plasma Method ⁽⁴⁾
120	Vinyl acetate	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
121	Vinyl chloride	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
122	m-Xylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
123	o-Xylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾

UPT-ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

ดำเนินการโดย

124 p-Xylene...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
124	p-Xylene	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
125	Xylene (Total)	Purge and Trap Gas Chromatographic/Mass Spectrometric Method ⁽⁴⁾
126	Zinc	1) Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Digestion, Electrothermal Atomic Absorption Spectrometric Method ⁽⁵⁾ 3) Digestion, Inductively Coupled Plasma Method ⁽⁶⁾

ตรวจวิเคราะห์ (ป่องระบบ) จำนวน 25 รายการ

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
1	Antimony	Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
2	Arsenic	1) Isokinetic Sampling, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽⁵⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
3	Cadmium	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
4	Carbon Monoxide	Instrumental Analyzer Method ⁽⁹⁾
5	Chlorine	Isokinetic Sampling, Ion Chromatographic Method ⁽³⁾
6	Chromium	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
7	Cobalt	Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
8	Copper	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
9	Cresol	Absorption Sampling, Gas Chromatographic Method ⁽⁴⁾

10 Dioxins/Furans.

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
10	Dioxins/Furans	Isokinetic Sampling ⁽³⁾
11	Hydrogen Chloride	Isokinetic Sampling, Ion Chromatographic Method ⁽³⁾
12	Hydrogen Fluoride	Isokinetic Sampling, Ion Chromatographic Method ⁽³⁾
13	Hydrogen Sulfide	Absorption Sampling, Iodometric Method ⁽⁸⁾
14	Lead	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
15	Manganese	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
16	Mercury	Isokinetic Sampling, Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ⁽⁵⁾
17	Nickel	1) Isokinetic Sampling, Digestion, Direct Air-Acetylene Flame Method ⁽⁴⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
18	Opacity	Ringelmann's Method ⁽¹⁾
19	Oxides of Nitrogen	1) Absorption Sampling, Phenoldisulfonic acid Method ⁽¹⁰⁾ 2) Instrumental Analyzer Method ⁽¹⁾
20	Selenium	1) Isokinetic Sampling, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ⁽⁵⁾ 2) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
21	Sulfur Dioxide	1) Absorption Sampling, Barium-Thoron Titrimetric Method ⁽²⁾ 2) Instrumental Analyzer Method ⁽¹⁾
22	Sulfuric Acid	Isokinetic Sampling, Barium-Thoron Titrimetric Method ⁽²⁾
23	Total Suspended Particulate	Isokinetic Sampling, Gravimetric Method ⁽³⁾
24	Vanadium	Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾
25	Xylene	1) Isokinetic Sampling, Digestion, Inductively Coupled Plasma Method ⁽⁶⁾ 2) Absorption Sampling, Gas Chromatographic Method ⁽⁴⁾

ถึง ๒ ปี...

ตรวจวิเคราะห์ (ป่องระบบ) จำนวน 25 รายการ

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
1	Aldrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,4,11) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(10,22)
2	Antimony	Digestion, Inductively Coupled Plasma Method ^(6,12)
3	Arsenic	1) Waste Extraction, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^(2,8,13) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(6,12) 3) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^(5,13) 4) Digestion, Inductively Coupled Plasma Method ^(6,12)
4	Barium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(6,12) 2) Digestion, Inductively Coupled Plasma Method ^(6,12)
5	Beryllium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(6,12) 2) Digestion, Inductively Coupled Plasma Method ^(6,12)
6	Cadmium	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(2,6,11) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(6,12) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(2,14) 4) Digestion, Inductively Coupled Plasma Method ^(7,15)
7	Chlordane	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,8,21) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(10,22)
8	Chromium	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(2,6,11) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(6,12)

5) Digestion, ...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
9	Chromium (III)	3) Digestion, Flame Atomic Absorption Spectrometric Method ^(2,14) 4) Digestion, Inductively Coupled Plasma Method ^(7,15) 1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method, Waste Extraction, Colorimetric Method, Calculation ^(2,14,16) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method, Waste Extraction, Colorimetric Method, Calculation ^(2,14,16) 3) Digestion, Flame Atomic Absorption Spectrometric Method, Alkaline Digestion, Colorimetric Method, Calculation ^(1,8,14,16) 4) Digestion, Inductively Coupled Plasma Method, Alkaline Digestion, Colorimetric Method, Calculation ^(1,8,14,16)
10	Chromium (VI)	1) Waste Extraction, Colorimetric Method ^(2,16) 2) Alkaline Digestion, Colorimetric Method ^(6,16)
11	Cobalt	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(4,13) 2) Digestion, Inductively Coupled Plasma Method ^(6,12)
12	Copper	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(2,14) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(6,12) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(2,14) 4) Digestion, Inductively Coupled Plasma Method ^(7,15)
13	2,4-D	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,8,20) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(10,22)
14	DDD	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,8,20) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(10,22)

15 DDE...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
15	DDE	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
16	DDT	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
17	Dieldrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
18	Endrin	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
19	Heptachlor	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
20	Lead	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(2,6,14) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,14) 4) Digestion, Inductively Coupled Plasma Method ^(7,13)
21	Lindene	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
22	Mercury	1) Waste Extraction, Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ^(2,7) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13)

3) Digestion,...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
		3) Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ⁽¹⁴⁾ 4) Digestion, Inductively Coupled Plasma Method ^(7,13) 5) Thermal Decomposition Amalgamation and Atomic Absorption Spectrometric Method ⁽¹⁴⁾
23	Methoxychlor	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
24	Molybdenum	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 2) Digestion, Inductively Coupled Plasma Method ^(7,13)
25	Nickel	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(2,6,13) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,14) 4) Digestion, Inductively Coupled Plasma Method ^(7,13)
26	Polychlorinated Biphenyls - Aroclor 1016 - Aroclor 1221 - Aroclor 1232 - Aroclor 1242 - Aroclor 1248 - Aroclor 1254 - Aroclor 1260 - 2-Chlorobiphenyl - 2,3-Dichlorobiphenyl - 2,2',5-Trichlorobiphenyl - 2,4',5-Trichlorobiphenyl - 2,2',3,5'-Tetrachlorobiphenyl - 2,2',5,5'-Tetrachlorobiphenyl - 2,3',4,4'-Tetrachlorobiphenyl - 2,2',3,4,5'-Pentachlorobiphenyl	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)



IAE
INSTITUTIONAL ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

ดำเนินการถูกต้อง

- 2,2',4,5,5'...


ลำดับ	สารมลพิษ	วิธีวิเคราะห์
	- 2,2',4,5,5'-Pentachlorobiphenyl - 2,3',4',6-Pentachlorobiphenyl - 2,2',3,4,4',5'-Hexachlorobiphenyl - 2,2',3,4,5,5'-Hexachlorobiphenyl - 2,2',3,5,5',6-Hexachlorobiphenyl - 2,2',4,4',5,5'-Hexachlorobiphenyl - 2,2',3,3',4,4',5-Heptachlorobiphenyl - 2,2',3,4,4',5,5'-Heptachlorobiphenyl - 2,2',3,4,4',5,5',6-Heptachlorobiphenyl - 2,2',3,4',5,5',6-Heptachlorobiphenyl - 2,2',3,3',4,4',5,5',6-Nonachlorobiphenyl Pentachlorophenol	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic/Mass Spectrometric Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(19,27) Electrometric Method ^(11,30)
28	pH	
29	Selenium	1) Waste Extraction, Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^(2,6,20) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 3) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^(2,6,20) 4) Digestion, Inductively Coupled Plasma Method ^(7,13)

30 Silver...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
30	Silver	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 2) Digestion, Inductively Coupled Plasma Method ^(7,13)
31	Thallium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 2) Digestion, Inductively Coupled Plasma Method ^(7,13)
32	Toxaphene	1) Waste Extraction, Separatory Funnel Liquid-Liquid Extraction, Gas Chromatographic Method ^(2,5,22) 2) Ultrasonic Extraction, Gas Chromatographic Method ^(19,27)
33	Trichloroethylene	1) Waste Extraction, Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(2,12,23) 2) Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(11,25)
34	Vanadium	1) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 2) Digestion, Inductively Coupled Plasma Method ^(7,13)
35	Zinc	1) Waste Extraction, Digestion, Flame Atomic Absorption Spectrometric Method ^(2,6,14) 2) Waste Extraction, Digestion, Inductively Coupled Plasma Method ^(2,6,13) 3) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,14) 4) Digestion, Inductively Coupled Plasma Method ^(7,13)

ดิน จำนวน 125 รายการ

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
1	Acenaphthene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(19,24) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(19,24)
2	Acetone	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(2,12,23)



IAE
INSTITUTIONAL ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

ดำเนินการถูกต้อง

3 Aldrin...

ลำดับ	สารเคมี	วิธีวิเคราะห์
3	Aldrin	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,27) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(15,28)
4	Anthracene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(15,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,29)
5	Antimony	Digestion, Inductively Coupled Plasma Method ^(7,12)
6	Arsenic	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^(7,13) 2) Digestion, Inductively Coupled Plasma Method ^(7,13)
7	Atrazine	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(12,28)
8	Barium	Digestion, Inductively Coupled Plasma Method ^(7,12)
9	Benz(a)anthracene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
10	Benzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,29)
11	Benzo(b)fluoranthene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
12	Benzo(k)fluoranthene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
13	Benzoic acid	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
14	Benzo(a)pyrene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)

15 Benzo(g,h,i)perylene...

ลำดับ	สารเคมี	วิธีวิเคราะห์
15	Benzo(g,h,i)perylene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,29) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,29)
16	Beryllium	Digestion, Inductively Coupled Plasma Method ^(7,13)
17	Bis(2-chloroethyl)ether	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
18	Bis(2-ethylhexyl)phthalate	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
19	Bromodichloromethane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
20	Bromoform	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
21	Butanol	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
22	Butyl benzyl phthalate	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
23	Cadmium	1) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,14) 2) Digestion, Inductively Coupled Plasma Method ^(7,14)
24	Carbazole	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
25	Carbon disulfide	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
26	Carbon tetrachloride	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
27	Chlordane	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
28	p-Chloroaniline	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
29	Chlorobenzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
30	Chlorodichloromethane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)

31 Chloroform...

ลำดับ	สารเคมี	วิธีวิเคราะห์
31	Chloroform	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
32	2-Chlorophenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
33	Chromium	1) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,15) 2) Digestion, Inductively Coupled Plasma Method ^(7,15)
34	Chromium (III)	1) Digestion, Flame Atomic Absorption Spectrometric Method; Alkaline Digestion, Colorimetric Method, Calculation ^(7,15,16) 2) Digestion, Inductively Coupled Plasma Method; Alkaline Digestion, Colorimetric Method; Calculation ^(7,15,16)
35	Chromium (VI)	Alkaline Digestion, Colorimetric Method ^(10,16)
36	Chrysene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
37	Cyanide	Extraction, Distillation, Colorimetric Method ^(26,29,30)
38	2,4-D	Ultrasonic Extraction, Gas Chromatographic Method ^(12,28)
39	DDD	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
40	DDE	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
41	DDT	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
42	Dibenzo(a,h)anthracene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)

43 Di-n-butyl phthalate...

ลำดับ	สารเคมี	วิธีวิเคราะห์
43	Di-n-butyl phthalate	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
44	1,2-Dichlorobenzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
45	1,3-Dichlorobenzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
46	1,4-Dichlorobenzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
47	3,3'-Dichlorobenzidine	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
48	1,1-Dichloroethane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
49	1,2-Dichloroethane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
50	1,1-Dichloroethylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
51	cis-1,2-Dichloroethylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
52	trans-1,2-Dichloroethylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
53	2,4-Dichlorophenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
54	1,2-Dichloropropane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
55	1,3-Dichloropropane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
56	1,3-Dichloropropene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(12,29)
57	Dieldrin	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
58	Diethyl phthalate	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
59	2,4-Dimethylphenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)

60 2,4-Dinitrophenol...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
60	2,4-Dinitrophenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
61	2,4-Dinitrotoluene	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
62	2,6-Dinitrotoluene	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
63	Di-n-Octyl phthalate	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
64	Endosulfan	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
65	Endrin	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
66	Ethylbenzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
67	Fluoranthene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
68	Fluorene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
69	Heptachlor	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
70	Heptachlor epoxide	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)

71 Hexachlorobenzene...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
71	Hexachlorobenzene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
72	Hexachloro-1,3-butadiene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
73	n-Hexane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
74	α-HCH	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
75	β-HCH	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
76	γ-HCH	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
77	Hexachlorocyclopentadiene	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
78	Hexachloroethane	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
79	Indeno[1,2,3-cd]pyrene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
80	Isophorone	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
81	Lead	1) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,14) 2) Digestion, Inductively Coupled Plasma Method ^(7,14)
82	Manganese	1) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,14) 2) Digestion, Inductively Coupled Plasma Method ^(7,14)

83 Mercury...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
83	Mercury	1) Digestion, Cold-Vapor Atomic Absorption Spectrometric Method ^(7,14) 2) Digestion, Inductively Coupled Plasma Method ^(7,14) 3) Thermal Decomposition Amalgamation and Atomic Absorption Spectrometric Method ^(7,14)
84	Methanol	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
85	Methoxychlor	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
86	Methyl bromide	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
87	Methylene chloride	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
88	2-Methylphenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
89	2-Methylnaphthalene	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
90	Methyl tert-butyl ether	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
91	Naphthalene	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
92	Nickel	1) Digestion, Flame Atomic Absorption Spectrometric Method ^(7,14) 2) Digestion, Inductively Coupled Plasma Method ^(7,14)
93	Nitrobenzene	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
94	N-Nitrosodiphenylamine	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)
95	N-Nitrosodi-n-propylamine	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28)

96 Polychlorinated Biphenyls...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
96	Polychlorinated Biphenyls - Aroclor 1016 - Aroclor 1221 - Aroclor 1232 - Aroclor 1242 - Aroclor 1248 - Aroclor 1254 - Aroclor 1260 Polychlorinated Biphenyls - 2-Chlorobiphenyl - 2,3-Dichlorobiphenyl - 2,2',5'-Trichlorobiphenyl - 2,4',5'-Trichlorobiphenyl - 2,2',3,5'-Tetrachlorobiphenyl - 2,2',5,5'-Tetrachlorobiphenyl - 2,3',4,4'-Tetrachlorobiphenyl - 2,2',3,4,5'-Pentachlorobiphenyl - 2,2',4,5,5'-Pentachlorobiphenyl - 2,3',3',4,5'-Pentachlorobiphenyl - 2,2',3,4,4',5'-Hexachlorobiphenyl - 2,2',3,4,5,5'-Hexachlorobiphenyl - 2,2',3,5,5',6'-Hexachlorobiphenyl - 2,2',4,4',5,5'-Hexachlorobiphenyl - 2,2',3,3',4,4',5'-Heptachlorobiphenyl - 2,2',3,4,4',5,5'-Heptachlorobiphenyl - 2,2',3,4,4',5,6'-Heptachlorobiphenyl	1) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28) 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^(10,28) Ultrasonic Extraction, Gas Chromatographic Method ^(10,28)

- 2,2',3,4',5,5',6...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
97	- 2,2',3,4',5,5',6-Heptachlorobiphenyl - 2,2',3,3',4,4',5,5',6-Nonachlorobiphenyl Pentachlorophenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^{10,26}
98	Phenanthrene	1) Ultrasonic Extraction, Gas Chromatographic Method ^{10,29} 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^{10,26}
99	Phenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^{10,26}
100	Pyrene	1) Ultrasonic Extraction, Gas Chromatographic Method ^{10,24} 2) Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^{10,26}
101	Selenium	1) Digestion, Hydride Generation/Atomic Absorption Spectrometric Method ^{17,27} 2) Digestion, Inductively Coupled Plasma Method ^{17,31}
102	Silver	Digestion, inductively Coupled Plasma Method ^{17,32}
103	Styrene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
104	1,1,2,2-Tetrachloroethane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
105	Tetrachloroethylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
106	Toluene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
107	Toxaphene	Ultrasonic Extraction, Gas Chromatographic Method ^{10,30}
108	TPH (C ₁₀ -C ₁₉)	1) Purge and Trap, Gas Chromatographic Method ^{17,29} 2) Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
109	TPH (C ₁₀ -C ₁₉)	Ultrasonic Extraction, Gas Chromatographic Method ^{10,30}
110	TPH (C ₁₀ -C ₁₉)	Ultrasonic Extraction, Gas Chromatographic Method ^{10,30}
111	1,2,4-Trichlorobenzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}

112 1,1,1-Trichloroethane...

ลำดับ	สารมลพิษ	วิธีวิเคราะห์
112	1,1,1-Trichloroethane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
113	1,1,2-Trichloroethane	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
114	Trichloroethylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
115	2,4,5-Trichlorophenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^{10,26}
116	2,4,6-Trichlorophenol	Ultrasonic Extraction, Gas Chromatographic/Mass Spectrometric Method ^{10,26}
117	1,3,5-Trimethylbenzene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
118	Vanadium	Digestion, Inductively Coupled Plasma Method ^{17,33}
119	Vinyl acetate	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
120	Vinyl chloride	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
121	m-Xylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
122	o-Xylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
123	p-Xylene	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
124	Xylene (Total)	Purge and Trap, Gas Chromatographic/Mass Spectrometric Method ^{17,25}
125	Zinc	1) Digestion, Flame Atomic Absorption Spectrometric Method ^{17,34} 2) Digestion, Inductively Coupled Plasma Method ^{17,31}

เอกสารอ้างอิง

- กระทรวงอุตสาหกรรม. ประกาศกระทรวงอุตสาหกรรม, พ.ศ. 2549. เรื่อง กำหนดค่าปริมาณของสารเคมีอันตรายในอากาศที่ระบายออกจากบ่อฝังกลบขยะมูลฝอย. กรุงเทพฯ: กรมส่งเสริมการค้าระหว่างประเทศ. 4 ธันวาคม 2549. เล่มที่ 123 หน้า 125.
- กระทรวงอุตสาหกรรม. ประกาศกระทรวงอุตสาหกรรม, พ.ศ. 2548. เรื่อง กำหนดค่าปริมาณของสารเคมีอันตรายในอากาศที่ระบายออกจากบ่อฝังกลบขยะมูลฝอย. กรุงเทพฯ: กรมส่งเสริมการค้าระหว่างประเทศ. 25 มกราคม 2548. เล่มที่ 114 หน้า 114.

3. สมาคมวิศวกรรม...

- สมาคมวิศวกรรมสิ่งแวดล้อมแห่งประเทศไทย. คู่มือวิเคราะห์น้ำเสีย. พิมพ์ครั้งที่ 4. กรุงเทพฯ: เว็บบอร์ด. 2547.
- APHA, AWWA, WEF. Standard Methods for the Examination of Water and Wastewater, 25th ed. Washington, DC: APHA, 2017.
- United States Environmental Protection Agency. Standards of Performance for New Stationary Sources. 40 CFR 60, Appendix A, 2019.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. SW-846, 1997.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Acid Digestion of Sediments, Sludges, and Solids. SW-846 Method 3050B, 1996.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Alkaline Digestion for Hexavalent Chromium. SW-846 Method 3060A, 1996.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Separatory Funnel Liquid-Liquid Extraction. SW-846 Method 3510C, 1996.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Ultrasonic Extraction. SW-846 Method 3550C, 2007.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Purge and Trap for Aqueous Samples. SW-846 Method 5030C, 2003.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Closed System Purge and Trap and Extraction for Volatile Organics in Soil and Waste Sample. SW-846 Method 5035A, 2000.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Inductively Coupled Plasma-Optical Emission Spectrometry. SW-846 Method 6010D, 2014.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Flame Atomic Absorption Spectrophotometry. SW-846 Method 7000B, 2007.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Arsenic (Atomic Absorption Gaseous Hydride). SW-846 Method 7061A, 1992.

16. United States...

- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Chromium, Hexavalent (Colorimetric). SW-846 Method 7196A, 1992.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Liquid Waste (Manual Cold Vapor Technique). SW-846 Method 7470A, 1994.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Solid or Semisolid Waste (Manual Cold-Vapor Technique). SW-846 Method 7471B, 1998.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Mercury in Solids and Solutions by Thermal Decomposition, Amalgamation, and Atomic Absorption Spectrophotometry. SW-846 Method 7473, 2007.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Selenium (Atomic Absorption, Borohydride Reduction). SW-846 Method 7742, 1994.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Nonhalogenated Organics Using GC/FID. SW-846 Method 8015D, 2003.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Organochlorine Pesticides by Gas Chromatography. SW-846 Method 8081B, 2007.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Polychlorinated Biphenyls (PCBs) by Gas Chromatography. SW-846 Method 8082A, 2007.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Polynuclear Aromatic Hydrocarbons. SW-846 Method 8100, 1980.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Volatile Organic Compounds by Gas Chromatography/Mass Spectrometry. SW-846 Method 8260D, 2018.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Semivolatile Organic Compounds by Gas Chromatography/Mass Spectrometry. SW-846 Method 8270E, 2018.
- United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Chlorinated Paraffins by GC Using Methylation or Pentafluorobenzoylation Derivatization. SW-846 Method 8310A, 1996.

28. United States...

32. United States Environmental Protection Agency. Test Methods for Evaluation Solid Waste Physical/Chemical Methods. Soil and Waste pH. SW-846 Method 9045D, 2004.

UAE
UNITED ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

สำเนาถูกต้อง

ภาคผนวก ข

ประกาศสวนอุตสาหกรรมโรจนะ (อยุธยา) ฉบับที่ 1/2559
เรื่อง การปล่อยน้ำเสียของโรงงานภายในสวนอุตสาหกรรมโรจนะ
(อยุธยา) ประกาศ ณ วันที่ 31 สิงหาคม พ.ศ. 2559



บริษัท สวนอุตสาหกรรมโรจนะ จำกัด (มหาชน)

ROJANA INDUSTRIAL PARK PUBLIC COMPANY LIMITED
2034/115 ชั้น 26 อาคารอิตัลไทย ทาวเวอร์ ถนนเพชรบุรีตัดใหม่ แขวงบางกะปิ เขตห้วยขวาง กรุงเทพฯ 10310
2034/115 26TH FLOOR ITALTHAI TOWER, NEW PETCHBURI ROAD, BANGKOK, HUA WKANG, BANGKOK 10310 THAILAND
TEL : 0-2718-1750-5 FAX : 0-2718-1759

ประกาศ

ฉบับที่ 1/2559 เรื่องการปล่อยน้ำเสียของโรงงานภายในสวนอุตสาหกรรมโรจนะ (อุยยา)

เพื่อให้การระบายน้ำเสียและมาตรฐานน้ำเสียของโครงการสวนอุตสาหกรรมโรจนะ(อุยยา)เป็นมาตรฐานตามที่บริษัท สวนอุตสาหกรรมโรจนะ จำกัด (มหาชน) สามารถรองรับได้ จึงเห็นควรปรับปรุงแก้ไขแบบเดิม เพิ่มเติม บริษัท ฉบับที่ 1/2557 เรื่องการปล่อยน้ำเสียของโรงงานภายในสวนอุตสาหกรรมโรจนะ ลงวันที่ 17 มีนาคม 2557 ทั้งนี้ประกาศข้อกำหนด หลักเกณฑ์การปล่อยน้ำเสียสู่ระบบบำบัดน้ำเสียส่วนกลางฉบับนี้ อ้างอิงโดยใช้ข้อกำหนดและหลักเกณฑ์ ตามประกาศกระทรวงอุตสาหกรรม ฉบับที่ 2 (พ.ศ. 2539) เรื่อง กำหนดคุณลักษณะของน้ำทิ้งที่ระบายออกจากร่างงาน ลงวันที่ 14 มิถุนายน 2539 และ ลงวันที่ 18 กุมภาพันธ์ 2540 เพื่อให้ผู้ประกอบการถือปฏิบัติตามข้อกำหนดต่าง ๆ ดังนี้

1. น้ำเสีย ได้แก่ น้ำที่ผ่านการใช้แล้วทุกชนิด เช่น จากกระบวนการผลิต จากการผลิตสิ่งต่าง ๆ จากห้องทดลอง ห้องฆ่า ห้องเชื่อม รวมถึงน้ำเสียจากการใช้น้ำของถนนและกิจกรรมอื่น ๆ ในโรงงานอุตสาหกรรม โดยน้ำเสียต้องเป็นไปตามมาตรฐานความดูแลระบายน้ำเสีย ที่กำหนดไว้ในประกาศนี้
2. การระบายน้ำเสีย ผู้ประกอบการจะต้องก่อสร้างระบบระบายน้ำเสียเพื่อระบายน้ำเสียจากทุกส่วนของโรงงานลงสู่ท่อระบายน้ำเสียรวมของสวนอุตสาหกรรมโรจนะ โดยมีหลักเกณฑ์ ดังนี้
 - 2.1 น้ำเสียที่ระบายจะต้องมีความเร็วเพียงพอที่จะพัดพาสารปนเปื้อน ให้ไหลลงสู่ระบบน้ำเสียรวมของสวนอุตสาหกรรมฯ โดยไม่ต้องถัง
 - 2.2 ระบบระบายน้ำเสียต้องมีครีต สะอาด และไม่ส่งกลิ่นเหม็น
 - 2.3 ระบบระบายน้ำเสียต้องแยกการระบายน้ำฝนโดยเด็ดขาด ทั้งนี้ เพื่อป้องกันน้ำฝนไหลลงระบบบำบัดน้ำเสียรวมและไม่ให้น้ำเสียไหลลงบ่อเก็บน้ำฝน
 - 2.4 จะต้องปิดตรวจระบบ (MANHOLE) 1 บ่อ ก่อนที่จะปล่อยน้ำลงท่อระบายน้ำเสียส่วนกลาง ทั้งนี้ เพื่อประโยชน์สำหรับการเก็บตัวอย่างน้ำเสีย
 - 2.5 จะต้องปิดประตูเปิด-ปิด ก่อนที่จะระบายน้ำเสียลงสู่ท่อระบายน้ำเสียรวม
 - 2.6 การต่อท่อระบายน้ำเสียรวม จะต้องต่อทั้งตำแหน่งเปิดตรวจระบบที่เหมาะสมตามสวนอุตสาหกรรมโรจนะจัดเตรียมไว้
 - 2.7 ท่อต่อเชื่อมกับท่อระบายน้ำเสียรวมจะต้องอุดรอยต่อให้แน่นเพื่อป้องกันการรั่วซึมซึมออก
 - 2.8 ในกรณีที่น้ำเสียมีคุณภาพเปลี่ยนแปลงมาก ในช่วงเวลาหนึ่ง จะต้องจัดเตรียมบ่อเก็บกักขนาดให้เพียงพอที่จะปรับปรุงคุณภาพน้ำเสียให้คงที่

3. กำหนดมาตรฐานคุณภาพของน้ำเสียที่ระบายสู่ระบบบำบัดน้ำเสียส่วนกลาง ดังนี้
 - 3.1 ค่าความเป็นกรดค่า (pH) มีค่าไม่น้อยกว่า 5.5 และ ไม่มากกว่า 9.0
 - 3.2 อุณหภูมิของน้ำเสียที่ปล่อยต้องไม่เกิน 40 องศาเซลเซียส
 - 3.3 ค่าซีโอดี (COD) ไม่มากกว่า 750 มิลลิกรัมต่อลิตร (จีโอดี หรือ COD หมายถึง Chemical oxygen demand)
 - 3.4 ค่าบีโอดี (BOD) ที่อุณหภูมิ 20 องศาเซลเซียส เวลา 5 วัน ไม่มากกว่า 500 มิลลิกรัมต่อ ลิตร (บีโอดี หรือ BOD หมายถึง Biochemical Oxygen Demand)
 - 3.5 ค่าสารที่ละลายน้ำได้ (TDS หรือ Total Dissolved Solids) ไม่มากกว่า 3,000 มิลลิกรัมต่อลิตร
 - 3.6 ค่าสารแขวนลอย (Suspended solids) ไม่มากกว่า 200 มิลลิกรัมต่อลิตร
 - 3.7 น้ำมันและไขมัน (Oil & Grease) ไม่มากกว่า 10.0 มิลลิกรัมต่อลิตร
 - 3.8 ที่เคเอ็น (Total Kjeldahl Nitrogen) ไม่มากกว่า 100 มิลลิกรัมต่อลิตร
 - 3.9 สี (Color) ไม่มากกว่า 120 Pt-Co Unit
 - 3.10 กลิ่น (Odor) ไม่เป็นที่พึงรังเกียจ
 - 3.11 ฟอสฟอริกหรือสารซักล้าง (Surfactants) ไม่มากกว่า 30 มิลลิกรัมต่อลิตร
 - 3.12 แอมโมเนียมไนโตรเจน (Free ammonia) ไม่มากกว่า 50 มิลลิกรัมต่อลิตร
 - 3.13 แอมโมเนีย (Ammonia) ไม่มากกว่า 50 มิลลิกรัมต่อลิตร
 - 3.14 ฟลูออไรด์ (Fluoride) ไม่มากกว่า 5.0 มิลลิกรัมต่อลิตร
 - 3.15 ซัลไฟด์ (Sulfide) คิดเทียบเป็นไฮโดรเจนซัลไฟด์ (H₂S) ไม่มากกว่า 1.0 มิลลิกรัมต่อลิตร
 - 3.16 ฟอร์มัลดีไฮด์ (Formaldehyde) ไม่มากกว่า 1.0 มิลลิกรัมต่อลิตร
 - 3.17 สารประกอบฟีนอล (Phenols Compound) ไม่มากกว่า 1.0 มิลลิกรัมต่อลิตร
 - 3.18 คลอรีนอิสระ (Free Chlorine) ไม่มากกว่า 1.0 มิลลิกรัมต่อลิตร
 - 3.19 คลอไรด์ที่เทียบเท่ากับคลอรีน (Chloride as Cl₂) ไม่มากกว่า 2,000 mg/L
 - 3.20 ไซยาไนด์ (Cyanide) คิดเทียบเป็นไฮโดรเจนไซยาไนด์ (HCN) ไม่มากกว่า 0.2 มิลลิกรัมต่อลิตร
 - 3.21 สารพิษศัตรูพืช และ สัตว์ (Pesticide) ไม่มีเลย
 - 3.22 สารกัมมันตภาพรังสี (Radioactive compound) ไม่มีเลย
 - 3.23 น้ำมันหาร์ (Tar) ไม่มีเลย
 - 3.24 โลหะหนักต้องไม่เกินค่าที่กำหนด ดังนี้
 - 3.24.1 สังกะสี (Zinc) ไม่มากกว่า 5.0 มิลลิกรัมต่อลิตร
 - 3.24.2 โครเมียม (Chromium)
 - 3.25.2.1 Hexavalent Chromium ไม่มากกว่า 0.25 มิลลิกรัมต่อลิตร
 - 3.25.2.2 Trivalent Chromium ไม่มากกว่า 0.75 มิลลิกรัมต่อลิตร
 - 3.24.3 อาร์เซนิก (Arsenic) ไม่มากกว่า 0.25 มิลลิกรัมต่อลิตร
 - 3.24.4 ทองแดง (Copper) ไม่มากกว่า 2.0 มิลลิกรัมต่อลิตร
 - 3.24.5 ปรอท (Mercury) ไม่มากกว่า 0.005 มิลลิกรัมต่อลิตร
 - 3.24.6 แคดเมียม (Cadmium) ไม่มากกว่า 0.03 มิลลิกรัมต่อลิตร
 - 3.24.7 แบเรียม (Barium) ไม่มากกว่า 1.0 มิลลิกรัมต่อลิตร
 - 3.24.8 เซเลเนียม (Selenium) ไม่มากกว่า 0.02 มิลลิกรัมต่อลิตร
 - 3.24.9 ตะกั่ว (Lead) ไม่มากกว่า 0.2 มิลลิกรัมต่อลิตร

3.24.10 นิกเกิล (Nickel)	ไม่มากกว่า	1.0	มิลลิกรัมต่อลิตร
3.24.11 เหล็กทั้งหมด (Total Iron)	ไม่มากกว่า	10.0	มิลลิกรัมต่อลิตร
3.24.12 แมงกานีส (Manganese)	ไม่มากกว่า	5.0	มิลลิกรัมต่อลิตร
3.24.13 เงิน (Silver)	ไม่มากกว่า	1.0	มิลลิกรัมต่อลิตร
3.24.14 ดีบุก (Tin)	ไม่มากกว่า	1.0	มิลลิกรัมต่อลิตร
3.24.15 อลูมิเนียม (Aluminum)	ไม่มากกว่า	5.0	มิลลิกรัมต่อลิตร

3.25 น้ำเสียที่ปล่อยต้องไม่มีสารเหล่านี้เจือปน

3.25.1 สารละลายที่มีความหนืดสูง	
3.25.2 น้ำมันเชื้อเพลิงและตัวทำละลายที่ติดไฟได้	
3.25.3 สารละลาย ของแข็ง หรือแก๊สที่ติดไฟได้ ระเหยได้ หรือที่อันตราย	
3.25.4 เม็ดสีที่ไม่สามารถย่อยสลายได้โดยธรรมชาติ	
3.25.5 ของแข็งที่สามารถแยกตัวได้ง่าย สารที่ไม่สามารถย่อยสลายได้หรือสารที่ตกตะกอน	

ในท่อระบายน้ำให้ยุติ

3.25.6 ตะกอนของตะกอนตามไป

4. หากคุณสมบัติด้านสุขของผู้ประกอบการใด มีคุณสมบัติเกินกว่าที่กำหนดในข้อ 3 ผู้ประกอบการจะต้องจัดทำระบบบำบัดน้ำเสียเบื้องต้น ก่อนระบายน้ำเสียลงสู่ระบบบำบัดส่วนกลางของโครงการ หากพบว่าผู้ประกอบการไม่สามารถดำเนินการได้ภายในระยะเวลาขั้นต้น สวนอุตสาหกรรมโรจนะจะให้การปรับปรุงเพิ่มเติมค่าบริการบำบัดน้ำเสีย หรือลงบริการจ่ายน้ำประปาให้แล้วแต่กรณี และ/หรือเสนอให้ กรอ. (โดยผ่านอุตสาหกรรมจังหวัด) สืบตามพระราชบัญญัติโรงงาน สิ่งทำผิดดำเนินการในส่วนที่ก่อให้เกิดมลพิษอันชั่วครว
5. หากผู้ประกอบการใดปล่อยน้ำเสียจากโรงงานลงสู่รางระบายน้ำฝน จะต้องชำระค่าเสียหาย ค่าดำเนินการและการบำบัดน้ำที่สวนอุตสาหกรรมโรจนะกำหนด
6. ข้อกำหนดหรือมาตรฐานน้ำทิ้งตามประกาศฉบับนี้ อาจมีการเปลี่ยนแปลงได้ภายใต้เงื่อนไขของกรมโรงงานอุตสาหกรรม หรือ หน่วยงานอื่นที่เกี่ยวข้อง ทั้งนี้ ระเบียบฯ ซึ่งมีบังคับประกาศหรือคำสั่งใดๆ ของสวนอุตสาหกรรมโรจนะในส่วนที่กำหนดไว้ตามประกาศฉบับเดิมดังกล่าวข้างต้น ให้ใช้ต่อไปตามประกาศฉบับนี้ทุกประการ

ประกาศ ณ วันที่ 31 สิงหาคม พ.ศ. 2559

(นายดิเรก ธีรภูธร)
ประธานเจ้าหน้าที่บริหาร

สำเนา : ฝ่ายการตลาดสวนอุตสาหกรรมโรจนะ
(รับทราบและสำหรับอ้างอิงในการทักัดสัญญา)

ภาคผนวก ซ
ประกาศกระทรวงทรัพยากรธรรมชาติและสิ่งแวดล้อม
เรื่อง กำหนดมาตรฐานควบคุมการระบายน้ำทิ้งจากอาคาร
บางประเภทและบางขนาด พ.ศ. 2548

ประกาศกระทรวงทรัพยากรธรรมชาติและสิ่งแวดล้อม

เรื่อง กำหนดมาตรฐานความคุ้มครองระบบน้ำทิ้ง
จากอาคารบางประเภทและบางขนาด

โดยที่ได้มีการปฏิรูประบบราชการ โดยให้มีการจัดตั้งกระทรวงทรัพยากรธรรมชาติและสิ่งแวดล้อมขึ้นมา และให้อำนาจภารกิจของกระทรวงวิทยาศาสตร์ เทคโนโลยีและสิ่งแวดล้อม ในส่วนที่เกี่ยวข้องกับพระราชบัญญัติส่งเสริมและรักษาคุณภาพสิ่งแวดล้อมแห่งชาติ พ.ศ. ๒๕๓๕ ไปเป็นของกระทรวงทรัพยากรธรรมชาติและสิ่งแวดล้อม ประกอบกันเป็นการสมควรให้คณะกรรมการควบคุมมลพิษเป็นผู้พิจารณาเห็นชอบกับวิธีการตรวจหาค่ามาตรฐานการระบายน้ำทิ้ง นอกเหนือจากวิธีการที่กำหนดไว้แผนกรมควบคุมมลพิษ จึงสมควรแก้ไขปรับปรุงประกาศกระทรวงวิทยาศาสตร์ เทคโนโลยีและสิ่งแวดล้อม เรื่อง กำหนดมาตรฐานความคุ้มครองระบบน้ำทิ้งจากอาคารบางประเภทและบางขนาด

อาศัยอำนาจตามความในมาตรา ๕๕ แห่งพระราชบัญญัติส่งเสริมและรักษาคุณภาพสิ่งแวดล้อมแห่งชาติ พ.ศ. ๒๕๓๕ แก้ไขโดยมาตรา ๑๑๔ แห่งพระราชกฤษฎีกาแก้ไขบทบัญญัติให้สอดคล้องกับการโอนอำนาจหน้าที่ของส่วนราชการ ให้เป็นไปตามพระราชบัญญัติปรับปรุงกระทรวง ทบวง กรม พ.ศ. ๒๕๔๕ พ.ศ. ๒๕๔๕ อันเป็นพระราชบัญญัติที่มีบทบัญญัติบางประการเกี่ยวกับการจําการจํากัดสิทธิและเสรีภาพของบุคคล ซึ่งมาตรา ๒๕ ประกอบกับมาตรา ๓๕ มาตรา ๔๘ มาตรา ๕๐ และมาตรา ๕๑ ของรัฐธรรมนูญแห่งราชอาณาจักรไทยบัญญัติให้กระทำได้ โดยอาศัยอำนาจตามบทบัญญัติแห่งกฎหมาย รัฐมนตรีว่าการกระทรวงทรัพยากรธรรมชาติและสิ่งแวดล้อม โดยที่คณะรัฐมนตรีกรมการควบคุมมลพิษ และโดยความเห็นชอบของคณะกรรมการสิ่งแวดล้อมแห่งชาติ จึงออกประกาศไว้ ดังต่อไปนี้

ข้อ ๑ ให้ยกเลิกประกาศกระทรวงวิทยาศาสตร์ เทคโนโลยีและสิ่งแวดล้อม เรื่อง กำหนดมาตรฐานความคุ้มครองระบบน้ำทิ้งจากอาคารบางประเภทและบางขนาด ลงวันที่ ๑๐ มกราคม พ.ศ. ๒๕๓๖

ข้อ ๒ ในประกาศนี้

“อาคาร” หมายความว่า อาคารที่ก่อสร้างขึ้น ไม่ว่าจะลักษณะเป็นอาคารหลังเดียว หรือเป็นกลุ่มของอาคารซึ่งตั้งอยู่ภายในพื้นที่ซึ่งเป็นที่บริเวณเดียวกัน และไม่อาจมีท่อระบายน้ำท่อดียว หรือมีหลายท่อที่เชื่อมติดต่อกันระหว่างอาคารหรือไม่ก็ตาม ซึ่งได้แก่

(๑) อาคารชุด ตามกฎหมายว่าด้วยอาคารชุด

(๒) โรงแรม ตามกฎหมายว่าด้วยโรงแรม

(๓) หอพัก ตามกฎหมายว่าด้วยหอพัก

(๔) สถานบริการประเภทสถานอาบน้ำ นวดหรืออบตัว ซึ่งมีผู้ให้บริการแก่ลูกค้า ตามกฎหมายว่าด้วยสถานบริการ

(๕) โรงพยาบาลของทางราชการหรือสถานพยาบาล ตามกฎหมายว่าด้วยสถานพยาบาล

(๖) อาคารโรงเรียนเอกชน ตามกฎหมายว่าด้วยโรงเรียนเอกชน โรงเรียนของทางราชการ อาคารสถาบันอุดมศึกษาของเอกชน ตามกฎหมายว่าด้วยสถาบันอุดมศึกษาของเอกชนและสถาบันอุดมศึกษาของทางราชการ

(๗) อาคารที่ทำการของทางราชการ รัฐวิสาหกิจ หรือองค์การระหว่างประเทศและของเอกชน

(๘) อาคารของศูนย์การค้าหรือห้างสรรพสินค้า

(๙) ตลาด ตามกฎหมายว่าด้วยการสาธารณสุข แต่ไม่รวมถึง ทำเลียบเรือประมง สะพานปลา หรือกิจการแพปลา

(๑๐) กัดตากรหรือร้านอาหาร

“น้ำทิ้ง” หมายความว่า น้ำเสียที่ผ่านระบบบำบัดน้ำเสียแล้วจนเป็นไปตามมาตรฐานความคุมการระบายน้ำทิ้งตามที่กำหนดไว้ในประกาศนี้

ข้อ ๓ ให้แบ่งประเภทของอาคารตามข้อ ๒ ออกเป็น ๕ ประเภท คือ

(๑) อาคารประเภท ก.

(๒) อาคารประเภท ข.

(๓) อาคารประเภท ค.

(๔) อาคารประเภท ง.

(๕) อาคารประเภท จ.

ข้อ ๔ อาคารประเภท ก. หมายความว่า อาคารดังต่อไปนี้

(๑) อาคารชุดที่มีจำนวนห้องสำหรับใช้เป็นที่อยู่อาศัยรวมกันทุกชั้นของอาคาร หรือกลุ่มของอาคารตั้งแต่ ๕๐๐ ห้องขึ้นไป

(๒) โรงแรมที่มีจำนวนห้องสำหรับใช้เป็นที่พักรวมกันทุกชั้นของอาคาร หรือกลุ่มของอาคารตั้งแต่ ๒๐๐ ห้องขึ้นไป

(๓) โรงพยาบาลของทางราชการ รัฐวิสาหกิจหรือสถานพยาบาล ตามกฎหมายว่าด้วยสถานพยาบาล ที่มีเตียงสำหรับผู้ป่วยไว้ค้างคืนรวมกันทุกชั้นของอาคารหรือกลุ่มของอาคารตั้งแต่ ๓๐ เตียงขึ้นไป

(๔) อาคารโรงเรียนเอกชน โรงเรียนของทางการ สถาบันอุดมศึกษาของเอกชน หรือ สถาบันอุดมศึกษาของทางการที่มีพื้นที่ใช้สอยรวมกันทุกชั้นของอาคารหนึ่งอาคารตั้งแต่ ๒๕,๐๐๐ ตารางเมตรขึ้นไป

(๕) อาคารที่พักของทางราชการ รัฐบาลกิจ องค์การระหว่างประเทศ หรือของเอกชน

(๖) อธิการของศูนย์การศึกษารัฐบาลต่างประเทศที่จัดรวมกันทุกชั้นของอาคารหรือ
กลุ่มของอาคารตั้งแต่ ๒๕,๐๐๐ ตารางเมตรขึ้นไป

(๓) ตลาดหลักทรัพย์แห่งประเทศไทยขออาชญากรรมที่ ๒,๕๐๐ ตารางเมตร

(๘) กัดตาดพรออาหารที่มีพิษทั้งการกรมนกทุกชนิดของตำรวจภูธรเมืองอาสาร

ข้อ ๕ อาคารประเภท ข. หมายถึง อาคารดังต่อไปนี้

(๑) อัตรารัฐพนักงานท้องถิ่นหรือบุคลากร หรือกลุ่มของอาคาร

(๒) โรงแรมที่มีจำนวนห้องพักสำหรับใช้เป็นห้องพักนักฟุตบอลของอาคาร หรือกลุ่มของอาคาร ตั้งแต่ ๖๐ ห้อง แต่ไม่ถึง ๑๐๐ ห้อง

(๓) หอพักพิกังเงน^๑หรือหอสังหาร^๒ไว้เป็นหออยู่สำหรับ^๓ผู้^๔มา^๕พัก^๖ของ^๗อาคาร^๘หรือ^๙กลุ่ม^{๑๐}ของ^{๑๑}อาคาร^{๑๒}

(๔) สถานบริการพินทุเรศรวมกันทุกชั้นของอาคาร หรือกลุ่มของอาคารตั้งแต่ ๕,๐๐๐ ตารางเมตรขึ้นไป

(๕) โรงพยาบาลของทางราชการ วิทยาลัย หรือสถานพยาบาล ตามกฎหมายว่าด้วยสถานพยาบาล
ที่มิได้ตั้งสำหรับผู้ป่วย^๖ วิชา^๗ สันนิษฐานว่า^๘ เป็นของราชการหรือกลุ่มของราชการตั้งแต่ ๑๐ เตียง แต่ไม่ถึง
๓๐ เตียง

(๖) อาคารโรงเรียนเอกชน โรงเรียนอุดมศึกษาของเอกชน หรือสถาบันอุดมศึกษาของราชการที่มีพื้นที่ใช้สอยรวมกันทุกชั้นของอาคารหรือกลุ่มของอาคารตั้งแต่ ๕,๐๐๐ ตารางเมตร แต่ไม่ถึง ๒๕,๐๐๐ ตารางเมตร

(๗) อาคารที่ทำการของทางราชการ รัฐวิสาหกิจ องค์การระหว่างประเทศ หรือของเอกชน
ที่พื้นที่ได้สอยรวมกันทุกชั้นของอาคารที่กลุ่มของอาคารตั้งแต่ ๑๐,๐๐๐ ตารางเมตร แต่ไม่ถึง
๕๕,๐๐๐ ตารางเมตร

(๗) อาคารของศูนย์การค้าหรือห้างสรรพสินค้าที่มีพื้นที่ใช้สอยรวมกันทุกชั้นของอาคารหรือ

(๕) ตลอดสามปีที่ผ่านมากรุงเทพมหานครมีโครงการที่ ๑,๕๐๐ โครงการ
แต่ถึง ๒,๕๐๐ โครงการ

(๑๐) กัดดาจารย์^{๑๕}นำอาหารที่พบที่ปริวรรก^{๑๖}มณฑลพิษณุโลก^{๑๗}แห่งอาณาจักรสุโขทัย^{๑๘}มาถวาย

ข้อ ๖ อาคารประเภท ก. หมายถึง อาคารดังต่อไปนี้

(๑) อัครทูตมาทำงานนอกวิหารเพื่อช่วยร่วมกันทุกชนของอาการ หรือกลุ่มของอาการ

(๒) โรงพยาบาลบ้านหนองปลาไหล^๑ อำเภอวังน้อย^๒ จังหวัดพระนครศรีอยุธยา^๓ เปิดให้บริการ^๔ ตั้งแต่เดือนสิงหาคม^๕ ปี ๒๕๖๓^๖ ถึงเดือนสิงหาคม^๗ ปี ๒๕๖๔^๘ รวมระยะเวลาการให้บริการ^๙ ๑๒ เดือน^{๑๐}

(๓) หอพักที่มีจำนวนห้องสำหรับใช้เป็นสถานที่รวมกันทุกคนของอาคาร หรือกลุ่มของอาคาร

(๔) สถานบริการที่พบปัญหาเพื่อส่งมอบงานให้สถานประกอบการ หรือกลุ่มของอาคาร ตั้งแต่ ๑,๐๐๐ ตารางเมตร แต่ไม่เกิน ๕,๐๐๐ ตารางเมตร^{๑)}

(๕) อัตรากำไรของการทางราชการ รัฐวิสาหกิจ องค์การระหว่างประเทศ หรือของเอกชน
ที่มิได้ให้สอดคล้องกับทุกช่วงของการบริโภคของอากรตั้งแต่ ๕,๐๐๐ ตารางเมตร แต่ไม่ถึง ๑๐,๐๐๐ ตารางเมตร

(๖) ตลาดพัฒนาที่ใช้ประโยชน์ของอาคารหรือกลุ่มของอาคารตั้งแต่ ๑,๐๐๐ ตารางเมตร แต่ไม่เกิน ๑,๕๐๐ ตารางเมตร

(๗) กัดตาหรือรื้อเอาอาหารที่พบเพื่อให้บริการแก่บุคคลของอาคาร หรือกลุ่มของอาคาร

๙๓ ๘ การประมง : หมายความว่า การตั้งข้อปฏิบัติ

<div>เล่ม ๑๒๒ ตอนที่ ๑๒๕ ง</div> <div>หน้า ๘</div> <div>ราชกิจจานุเบกษา</div> <div>๒๕ ธันวาคม ๒๕๔๔</div>	<div>หน้า ๘</div> <div>ราชกิจจานุเบกษา</div> <div>๒๕ ธันวาคม ๒๕๔๔</div> <div><p>(๑) หอพักที่มีจำนวนห้องสำหรับใช้เป็นที่อยู่อาศัยรวมกันทุกชั้นของอาคาร หรือกลุ่มของอาคาร ตั้งแต่ ๑๐ ห้อง แต่ไม่ถึง ๕๐ ห้อง</p><p>(๒) ตลาดที่มีพื้นที่ใช้สอยรวมกันทุกชั้นของอาคาร หรือกลุ่มของอาคารตั้งแต่ ๕๐๐ ตารางเมตร แต่ไม่ถึง ๑,๐๐๐ ตารางเมตร</p><p>(๓) กิจตาคารหรือร้านอาหารที่มีพื้นที่ให้บริการรวมกันทุกชั้นของอาคาร หรือกลุ่มของอาคาร ตั้งแต่ ๑๐๐ ตารางเมตร แต่ไม่ถึง ๒๕๐ ตารางเมตร</p><p>ข้อ ๘ อาคารประเภท ก. หมายความว่า กิจตาคารหรือร้านอาหารที่มีพื้นที่ให้บริการรวมกันทุกชั้นไม่ถึง ๑๐๐ ตารางเมตร</p><p>ข้อ ๙ มาตรฐานความปลอดภัยของน้ำทิ้งจากอาคาร ประเภท ก. ต้องมีค่าดังต่อไปนี้</p><p>(๑) ความเป็นกรดและด่าง (PH) ต้องมีค่าระหว่าง ๕-๙</p><p>(๒) บีโอดี (BOD) ต้องมีค่าไม่เกิน ๒๐ มิลลิกรัมต่อลิตร</p><p>(๓) สารแขวนลอย (Suspended Solids) ต้องมีค่าไม่เกิน ๓๐ มิลลิกรัมต่อลิตร</p><p>(๔) ซัลไฟด์ (Sulfide) ต้องมีค่าไม่เกิน ๑.๐ มิลลิกรัมต่อลิตร</p><p>(๕) สารที่ละลายได้ทั้งหมด (Total Dissolved Solids) ต้องมีค่าเพิ่มขึ้นจากปริมาณสารละลายในน้ำใช้ตามปกติไม่เกิน ๕๐๐ มิลลิกรัมต่อลิตร</p><p>(๖) ตะกอนหนัก (Settleable Solids) ต้องมีค่าไม่เกิน ๐.๕ มิลลิกรัมต่อลิตร</p><p>(๗) น้ำมันและไขมัน (Fat Oil and Grease) ต้องมีค่าไม่เกิน ๒๐ มิลลิกรัมต่อลิตร</p><p>(๘) ทีเคเอ็น (TKN) ต้องมีค่าไม่เกิน ๓๕ มิลลิกรัมต่อลิตร</p><p>ข้อ ๑๐ มาตรฐานความปลอดภัยของน้ำทิ้งจากอาคาร ประเภท ข. ต้องเป็นไปตามข้อ ๘</p><p>เว้นแต่</p><p>(๑) บีโอดี ต้องมีค่าไม่เกิน ๓๐ มิลลิกรัมต่อลิตร</p><p>(๒) สารแขวนลอย ต้องมีค่าไม่เกิน ๔๐ มิลลิกรัมต่อลิตร</p><p>ข้อ ๑๑ มาตรฐานความปลอดภัยของน้ำทิ้งจากอาคาร ประเภท ก. ต้องเป็นไปตามข้อ ๘</p><p>เว้นแต่</p><p>(๑) บีโอดี ต้องมีค่าไม่เกิน ๔๐ มิลลิกรัมต่อลิตร</p><p>(๒) สารแขวนลอย ต้องมีค่าไม่เกิน ๕๐ มิลลิกรัมต่อลิตร</p></div>
<div>เล่ม ๑๒๒ ตอนที่ ๑๒๕ ง</div> <div>หน้า ๙</div> <div>ราชกิจจานุเบกษา</div> <div>๒๕ ธันวาคม ๒๕๔๔</div>	<p>(๓) ซัลไฟด์ ต้องมีค่าไม่เกิน ๓.๐ มิลลิกรัมต่อลิตร</p> <p>(๔) ค่าทีเคเอ็น ต้องมีค่าไม่เกิน ๔๐ มิลลิกรัมต่อลิตร</p> <p>ข้อ ๑๒ มาตรฐานความปลอดภัยของน้ำทิ้งจากอาคาร ประเภท จ. ต้องเป็นไปตามข้อ ๘</p> <p>เว้นแต่</p> <p>(๑) บีโอดี ต้องมีค่าไม่เกิน ๕๐ มิลลิกรัมต่อลิตร</p> <p>(๒) สารแขวนลอย ต้องมีค่าไม่เกิน ๕๐ มิลลิกรัมต่อลิตร</p> <p>(๓) ซัลไฟด์ ต้องมีค่าไม่เกิน ๔.๐ มิลลิกรัมต่อลิตร</p> <p>(๔) ค่าทีเคเอ็น ต้องมีค่าไม่เกิน ๔๐ มิลลิกรัมต่อลิตร</p> <p>ข้อ ๑๓ มาตรฐานความปลอดภัยของน้ำทิ้งจากอาคาร ประเภท จ. ต้องมีค่าดังต่อไปนี้</p> <p>(๑) ความเป็นกรดและด่างต้องมีค่าระหว่าง ๕-๙</p> <p>(๒) บีโอดี ต้องมีค่าไม่เกิน ๒๐๐ มิลลิกรัมต่อลิตร</p> <p>(๓) สารแขวนลอย ต้องมีค่าไม่เกิน ๖๐ มิลลิกรัมต่อลิตร</p> <p>(๔) น้ำมันและไขมัน ต้องมีค่าไม่เกิน ๑๐๐ มิลลิกรัมต่อลิตร</p> <p>ข้อ ๑๔ การตรวจสอบมาตรฐานการระบายน้ำทิ้งจากอาคาร ให้ใช้วิธีการดังต่อไปนี้</p> <p>(๑) การตรวจสอบค่าความเป็นกรดและด่างให้กระทำโดยใช้เครื่องวัดความเป็นกรดและด่างของน้ำ (PH Meter)</p> <p>(๒) การตรวจสอบค่าบีโอดีให้กระทำโดยใช้วิธีการอะไซด์โมดิฟิเคชัน (Azide Modification) ที่อุณหภูมิ ๒๐ องศาเซลเซียส เป็นเวลา ๕ วัน ติดต่อกันหรือวิธีการอื่นที่คณะกรรมการควบคุมมลพิษให้ความเห็นชอบ</p> <p>(๓) การตรวจสอบค่าสารแขวนลอยให้กระทำโดยใช้วิธีการกรองผ่านกระดาษกรองใยแก้ว (Glass Fibre Filter Disc)</p> <p>(๔) การตรวจสอบค่าซัลไฟด์ให้กระทำโดยใช้วิธีการไทเตรต (Titrate)</p> <p>(๕) การตรวจสอบค่าสารที่ละลายได้ทั้งหมดให้กระทำโดยใช้วิธีการระเหยแห้งระหว่างอุณหภูมิ ๑๐๓ องศาเซลเซียส ถึงอุณหภูมิ ๑๐๕ องศาเซลเซียส ในเวลา ๑ ชั่วโมง</p> <p>(๖) การตรวจสอบค่าตะกอนหนักให้กระทำโดยใช้วิธีการกรวยอิมฮอฟฟ์ (Imhoff cone) ขนาดบรรจุ ๑,๐๐๐ ลูกบาศก์เซนติเมตร ในเวลา ๑ ชั่วโมง</p>

(๘) การตรวจสอบค่าน้ำหนักและไขมันให้กระทำโดยใช้วิธีการสกัดด้วยตัวทำละลาย แล้วแยกหาน้ำหนักของน้ำและไขมัน

(๘) การตรวจสอบค่าที่เคอื่นให้กระทำโดยใช้วิธีการเจลด้าห์ล (Kjeldahl)

ข้อ ๑๕ การคิดคำนวณพื้นที่ใช้สอย จำนวนอาคารและจำนวนห้องของอาคาร หรือกลุ่มของอาคารให้เป็นไปตามวิธีการที่คณะกรรมการควบคุมลพิษกำหนด โดยประกาศในราชกิจจานุเบกษา

ข้อ ๑๖ วิธีการเก็บตัวอย่างน้ำ ความถี่ และระยะเวลาในการเก็บตัวอย่างน้ำ ให้เป็นไปตามที่คณะกรรมการควบคุมลพิษกำหนด โดยประกาศในราชกิจจานุเบกษา

ข้อ ๑๗ ประกาศนี้ให้ใช้บังคับตั้งแต่วันถัดจากวันประกาศในราชกิจจานุเบกษาเป็นต้นไป

ประกาศ ณ วันที่ ๘ พฤศจิกายน พ.ศ. ๒๕๔๘

ชงยุทธ คิยะไพรัช

รัฐมนตรีว่าการกระทรวงทรัพยากรธรรมชาติและสิ่งแวดล้อม



UNITED ANALYST AND ENGINEERING
CONSULTANT COMPANY LIMITED

บริษัท ยูไนเต็ต แอนนาลิสต์ แอนด์ เอ็นจิเนียริง คอนซัลแตนท์ จำกัด
3 ซอยอุดมสุข 41 ถนนสุขุมวิท แขวงบางจาก เขตพระโขนง กรุงเทพมหานคร 10260
โทรศัพท์ 02 763 2828 Email: uae@uaeconsultant.com

